

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	A	Powertrain	(F) 2.2L L4 L61/(X) 2.0L L4 LNF/(B) 2.4L L4 LE5	Automatic/Manual	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Body Control				●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	A	Body	Passenger Presence System				○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Personal Audio Link Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	A	Body	Radio				●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Remote Control Door Lock				●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	A/L	Body	Supplemental Inflatable Restraint				●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Theft Deterrent Module				●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	A	Body	Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	A	Chassis	With VSES (RPO JL4) (0000C2A7)/(0000C2A9)	Electronic Brake Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	J	Powertrain	(Z) 2.0L L4 L34	(MFA) 4 Speed Automatic/Manual	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	J	Body	IS09141_PROTOCOL/ KW82_PROTOCOL	Immobilizer/Remote Function Actuation Supplemental Inflatable			○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	J/N	Chassis	YES/NO	YES/NO	Electronic Brake Control Module/Power Steering Control Module/Tire Pressure		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	K	Powertrain	(4) 0.8L L3 LBF	4 Speed Automatic	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	K	Powertrain	(0) 1.0L L4 L11	Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	K	Body	Immobilizer				○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	K	Body	Remote Function Actuation				○	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	K	Body	Supplemental Inflatable Restraint				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	K	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	L	Powertrain	(R) 2.0L L4 LLW	5 Speed Automatic	Engine Control Module/Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	L	Powertrain	(R) 2.0L L4 LLW/(K) 2.0L L6 LBM/(L) 2.5L L6 LBK	Manual	Engine Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	L	Powertrain	(K) 2.0L L6 LBM/(L) 2.5L L6 LBK	6 Speed Automatic	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	L	Body	Supplemental Inflatable Restraint/ISU				●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	L	Chassis	YES/NO	Power Steering Control Module/Electronic Brake Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	N	Powertrain	(7) 1.4L L4 L95	Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	N	Powertrain	(6) 1.6L L4 L91/(6) 1.6L L4 LXT	(ML4/MLQ) 4 Speed Automatic/(M92) 4 Speed	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	N	Powertrain	(3) 1.8L L4 L79/(B) 1.8L L4 LDA/(Z) 2.0L L4 L34/(D) 2.0L L4 LMN/(U) 2.0L L4 LMN	Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	N	Powertrain	(D) 2.0L L4 LMN	5 Speed Automatic	Engine Control Module/Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	S	Chevy	Body	Immobilizer			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	S	Aveo	Powertrain	(D) 1.2L L4 LMU/(Y) 1.5L L4 LV8/(T) 1.2L L4 LY4/(7) 1.4L L4 L95(7) 1.4L L4 L95/(T) 1.2L/(X) 1.6L L4 LLQ	Manual/Automatic	Engine Control Module/Transmission Control Module/Engine Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet/Pontiac	S/T	Aveo/G3/Wave	Body	(5) Four-Door Sedan/(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL / IS09141_PROTOCOL / KW82_PROTOCOL	Immobilizer	○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet/Pontiac	S/T	Aveo/G3/Wave	Body	(5) Four-Door Sedan	KW2000_PROTOCOL	Remote Function Actuation	○	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet/Pontiac	S/T	Aveo/G3/Wave	Body	(5) Four-Door Sedan/(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL/ISO9141_PROTOCOL/KW82_PROTOCOL	Supplemental Inflatable Restraint	●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	S	Aveo	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	S	Aveo	Chassis	Tire Pressure Monitor			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	T	Powertrain	(D) 1.2L L4 LMU	Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	T	Powertrain	(T) 1.2L L4 LY4	Automatic, Manual	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	T	Powertrain	(M) 1.4L L4 L95	Delphi MR140/Delphi MT80	(ML4/MLQ) 4 Speed Automatic	Engine Control Module/Transmission Control	●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet,Buick,Holden	T	Powertrain	(6) 1.6L L4 L91	Automatic, Manual, (ML4/MLQ) 4 Speed Automatic, (M92)	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	T	Powertrain	(6) 1.6L L4 LXT	Automatic, Manual	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan		KW2000_PROTOCOL	Remote Function Actuation/Immobilizer/Supplemental Inflatable Restraint	○	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan	IS09141_PROTOCOL	Immobilizer/Remote Function Actuation		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan	IS09141_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan	KW82_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan	KW82_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(5) Four-Door Sedan	KW82_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	T	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	T	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	T	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	T	Chassis	Tire Pressure Monitor				●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	U	Powertrain	(Z) 2.0L L4 L34	(MFA) 4 Speed Automatic	Euro II/ECE 83/Euro III/Euro IV	Engine Control Module/Transmission Control Module/Engine Control Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	U	Body	Immobilizer				○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	U	Body	Remote Function Actuation				○	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	U	Body	Supplemental Inflatable Restraint				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	U	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	W	Powertrain	(N) 3.5L V6 LZ4	Without Air Pump, With Air Pump	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Powertrain	(K) 3.5L V6 LZE/(3) 3.9L V6 LZG/(C) 5.3L V8 LS4	Engine Control Module/Transmission Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Heated Seat Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Passenger Presence System/Radio			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	W	Body	CJ3 Dual Zone HVAC, Manual	Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Digital Radio Receiver			●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Heated Seat Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Passenger Presence System			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Radio			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	W	Body	C67, Single Zone HVAC, Manual	Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	W	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Powertrain	6 Speed Automatic	Engine Control Module, Transmission Control			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Powertrain	6 Speed Automatic	Exhaust Flow Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Powertrain	Manual	Engine Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Powertrain	Manual	Exhaust Flow Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	CD Changer			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Digital Radio Receiver			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Driver Door Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Driver Door Switch			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Driver Position Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Folding Top Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Head Up Display			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	HVAC Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Passenger Door Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Steering Column Lock Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Supplemental Inflatable Restraint/Radio/Remote Control Door Lock Receiver			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Uplevel Radio	Vehicle Comm.			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Body Control			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	CD Changer			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Driver Position Module/Driver Door Module/Driver Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Folding Top Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	HVAC Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Instrument Panel Cluster/Head Up Display/Passeng			●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Navigation			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Remote Control Door Lock Receiver/Supplemental Inflatable			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Steering Column Lock Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Body	Navigation Radio	Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Y	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Y	Chassis	Electronic Suspension				●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Powertrain	(F) 2.2L L4 L61/(N) 3.5L V6 LZ4	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic/Malibu/Malibu	Body	Automatic/Manual	Body Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic	Disc Player and Video Display/Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic	HVAC Control Module/Instrument Panel		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Automatic/Manual	Theft Deterrent Module		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Manual	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Manual	Disc Player and Video Display/Instrument Panel		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Manual	Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Body	Manual	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Classic	Chassis	Power Steering Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Powertrain	(B) 2.4L L4 LE5/(T) 1.2L L4 LY4/(6) 1.6L L4 L91	6 Speed Automatic/4 Speed Automatic	Transmission Control Module/Engine Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Powertrain	(N) 3.5L V6 LZ4/(7) 3.6L V6 LY7	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	HVAC Control Module/Instrument Panel		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	Personal Audio Link Module/Vehicle Comm. Interface Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Automatic	Theft Deterrent Module/Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Supplemental Inflatable Restraint/Radio/Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Body	Manual	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu	Chassis	Power Steering Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet/Saturn	Z	Malibu Hybrid/Aura Hybrid	Powertrain	(5) 2.4L L4 LAT	Battery Energy Control Module		○	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Powertrain	(5) 2.4L L4 LAT	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Powertrain	(5) 2.4L L4 LAT	Starter/Generator Control		○	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Powertrain	(5) 2.4L L4 LAT	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic	HVAC Control Module/Instrument Panel		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic/Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic/Manual	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic/Manual	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Automatic/Manual	Theft Deterrent Module/Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Manual	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Manual	HVAC Control Module/Instrument Panel		●	●	●	●	○	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Body	Manual	Radio		●	●	●	●	●	●
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Chevrolet	Z	Malibu Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	A	Powertrain	(F) 2.2L L4 L61	Automatic,Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	A	Powertrain	(F) 2.2L L4 L61	Automatic	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	A,M,Z	Powertrain	(B) 2.4L L4 LE5	Automatic,Manual	Engine Control Module/Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	A	Body	Body Control Module,Remote Control Door Lock Receiver,Supplemental Inflatable Restraint,Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	A	Body	Digital Radio Receiver				●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	A	Body	Instrument Panel Cluster/Personal Audio Link Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	A	Body	Passenger Presence System				○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	A	Body	Radio/Theft Deterrent Module				●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	A	Chassis	With VSES (RPO JL4) (0000C2A7)/Without VSES (RPO JL4)	Electronic Brake Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	E,Z	Powertrain	(7) 3.6L V6 LY7	Engine Control Module/Transmission Control			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	E	Powertrain	(Y) 6.0L V8 L76	6 Speed Automatic	Engine Control Module,Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	E	Body	Auto. HVAC/Manual HVAC	Body Control Module,Vehicle Comm. Interface Module,Supplemental Inflatable Restraint,Remote Control Door Lock Receiver,Passen			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	E	Body	Auto. HVAC/Manual HVAC	Driver Information Center,Radio,Personal Audio Link Module,Instrument Panel Cluster,HVAC			●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	E	Body	Auto. HVAC	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	E	Body	Manual HVAC	Radio			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	E	Body	Manual HVAC	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	E	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	M	Powertrain	(X) 2.0L L4 LNF	Automatic, Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	M	Powertrain	(X) 2.0L L4 LNF, (B) 2.4L L4 LE5	Automatic	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	M	Body	Body Control Module, Radio, Remote Control Door Lock Receiver, Supplemental Inflatable Restraint, Vehicle Comm. Interface				●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	M	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	Passenger Car	Pontiac	M	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	M	Body	Passenger Presence System				○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	M	Body	Personal Audio Link Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	M	Body	Theft Deterrent Module				●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	M	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Powertrain	4 Speed Automatic	(8) 1.8L L4 LV6	Powertrain Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Powertrain	Manual	(8) 1.8L L4 LV6	Engine Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Body	Cruise Control				○	●	○	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Body	Digital Radio Receiver, Vehicle Comm. Interface Module				●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	S	Body	Immobilizer				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Body	Radio				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Body	Supplemental Inflatable Restraint				●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	S	Chassis	YES	Without All Wheel Drive	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	YES	Without All Wheel Drive	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	YES	With All Wheel Drive	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	YES	With All Wheel Drive	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	NO	Without All Wheel Drive	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	NO	Without All Wheel Drive	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	NO	With All Wheel Drive	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	S	Chassis	NO	With All Wheel Drive	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	T	G3	Powertrain	(T) 1.2L L4 LY4/(6) 1.6L L4 L91/(6) 1.6L L4 LXT	Automatic/Manual	Engine Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	T	G3	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	T	G3	Chassis	Tire Pressure Monitor			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	T	Wave	Powertrain	(T) 1.2L L4 LY4/(6) 1.6L L4 L91/(6) 1.6L L4 LXT	Automatic/Manual	Engine Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	T	Wave	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	T	Wave	Chassis	Tire Pressure Monitor			●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	W	Powertrain	(2) 3.8L V6 L26	Powertrain Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	W	Powertrain	(C) 5.3L V8 LS4	Engine Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	W	Powertrain	(C) 5.3L V8 LS4	Transmission Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	W	Body	Automatic	Body Control Module,Digital Radio Receiver,Remote Control Door Lock Receiver,Vehicle Comm.			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	W	Body	Automatic	Driver Information Center,Instrument Panel			●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	W	Body	Automatic	Head Up Display			●	●	○	○	○	○
(8) 2008	Passenger Car	Pontiac	W	Body	Automatic	HVAC Control Module,Navigation Radio,Radio,Supplemental Inflatable			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Automatic	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Body Control Module,Digital Radio Receiver,Remote Control Door Lock Receiver,Vehicle Comm.			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Driver Information Center			●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Head Up Display			●	●	○	○	○	○
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Navigation			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Radio			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Body	Manual	Supplemental Inflatable Restraint			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	W	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	Z	Powertrain	(N) 3.5L V6 LZ4	Engine Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	Z	Powertrain	(N) 3.5L V6 LZ4	Transmission Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car,LD Trk, MPV, Incomplete	Pontiac,Pontiac APV,Chevrolet	Z	Powertrain	(1) 3.9L V6 LZ9	Engine Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car,LD Trk, MPV, Incomplete	Pontiac,Pontiac APV,Chevrolet	Z	Powertrain	(1) 3.9L V6 LZ9	Transmission Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	Body Control Module,Supplemental Inflatable Restraint,Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	Folding Top Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	HVAC Control Module,Instrument Panel			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Automatic	Radio, Theft Deterrent			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Body Control Module, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Folding Top Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Passenger Presence System			○	●	○	●	○	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Radio			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	Z	Body	Manual	Theft Deterrent Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Pontiac	Z	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Pontiac	Z	Chassis	Power Steering Control Module				●	●	●	●	○	●
(8) 2008	Passenger Car	Buick	H	Powertrain	(2) 3.8L V6 L26	Without Air Pump	Powertrain Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	H	Powertrain	(9) 4.6L V8 L37/(Y) 4.6L V8 LD8	Engine Control Module, Transmission Control			●	●	●	●	●	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Buick	H	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Driver Door Switch/HVAC Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Left Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Memory Seat Module/Park Assist Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Passenger Presence System/Radio			●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	H	Body	Manual	Right Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	H	Body	Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	H	Body	Manual	Vehicle Comm. Interface Module/Veh Direction Alert Alarm Warn Mod			●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	H	Body	Manual	Veh Direction Alert Alarm Warn Mod			●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	H	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	H	Chassis	Electronic Suspension				●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	J	Powertrain	(3) 1.8L L4 LDA	Manual, (MFA) 4 Speed Automatic	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Buick	J	Powertrain	(3) 1.8L L4 LDA	(MFA) 4 Speed Automatic	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	J	Powertrain	(U) 2.0L L4 LMN	5 Speed Automatic, Manual	Engine Control Module, Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	J	Body	ISO9141_PROTOCOL/ KW82_PROTOCOL	Immobilizer			○	●	○	●	○	●
(8) 2008	Passenger Car	Buick	J	Body	ISO9141_PROTOCOL/ KW82_PROTOCOL	Remote Function Actuation			○	●	●	●	○	●
(8) 2008	Passenger Car	Buick	J	Body	ISO9141_PROTOCOL/ KW82_PROTOCOL	Supplemental Inflatable Restraint			●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	J	Chassis	YES/NO	YES/NO	Electronic Brake Control Module/Power Steering Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Buick	J	Chassis	YES/NO	YES/NO	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	W	Allure	Powertrain	(7) 3.6L V6 LY7/(C) 5.3L V8 LS4	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	Allure	Powertrain	(7) 3.6L V6 LY7/(C) 5.3L V8 LS4	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Powertrain	(2) 3.8L V6 L26	Without Air Pump/With Air Pump	Powertrain Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Buick/Saturn	W	Allure	Body	Automatic	Body Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	HVAC Control Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic	Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Remote Control Door Lock Receiver		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	Passenger Car	Buick	W	Allure/LaCrosse	Body	Automatic/Manual	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	Allure	Body	Manual	Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Buick	W	Allure	Chassis	Electronic Brake Control			○	●	●	●	○	○
(8) 2008	Passenger Car	Buick	W	LaCrosse	Powertrain	(7) 3.6L V6 LY7/(C) 5.3L V8 LS4	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Buick	W	LaCrosse	Powertrain	(7) 3.6L V6 LY7/(C) 5.3L V8 LS4	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Buick	W	LaCrosse	Chassis	Electronic Brake Control			○	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Powertrain	(T) 2.8L V6 LP1	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Powertrain	(T) 2.8L V6 LP1	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Powertrain	(7) 3.6L V6 LY7/(V) 3.6L V6 LLT	YES/NO	Engine Control Module/Transmission Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Amplifier			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Body Control Module (aux.)			●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Driver Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Headlamp Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	HVAC Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Infotainment Faceplate			○	●	●	○	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Memory Seat Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Park Assist Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Passenger Presence System			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Pedestrian Impact			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Radio			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	TV Antenna			●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Body	Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	CTS	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(T) 2.8L V6 LP1	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(T) 2.8L V6 LP1	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(7) 3.6L V6 LY7	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(7) 3.6L V6 LY7	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(A) 4.6L V8 LH2	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Powertrain	(A) 4.6L V8 LH2	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated/Non-	Amplifier		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Driver Door Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Driver Door Switch		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Driver Position Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Headlamp Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	HVAC Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Instrument Panel Cluster		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Instrument Panel Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Left Rear Door Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Passenger Door Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Rear Integration		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Remote Control Door Lock Receiver		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Right Rear Door Module		●	●	●	●	○	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Heated	TV Antenna Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Driver Door Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Driver Door Switch		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Driver Position Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Headlamp Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	HVAC Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Instrument Panel Cluster		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Instrument Panel Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Left Rear Door Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Passenger Door Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Radio		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Rear Integration		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Remote Control Door Lock Receiver		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Right Rear Door Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	Supplemental Inflatable Restraint		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	SLS	Body	Non-Heated	TV Antenna Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	SLS	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(V) 3.6L V6 LLT	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(V) 3.6L V6 LLT	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(D) 4.4L V8 LC3	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(D) 4.4L V8 LC3	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(A) 4.6L V8 LH2	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Powertrain	(A) 4.6L V8 LH2	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Digital Radio Receiver	●	●	●	○	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Distance Sensing Cruise Control	●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Driver Door Module	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Driver Door Switch	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Driver Position Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Headlamp Control Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Head Up Display	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	HVAC Control Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Instrument Panel Cluster/Left Rear Door Module	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Left Side Object Detection Module	●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Passenger Door Module	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Passenger Presence System	○	●	○	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Radio	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Rear Integration Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Remote Control Door Lock Receiver	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Right Rear Door Module	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Right Side Object Detection Module	●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Supplemental Inflatable Restraint	●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	TV Antenna Module	●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Vehicle Comm. Interface Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Veh Direction Alert Alarm Warn Mod	●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Uplevel Radio/Navigation Radio	(D) 4.4L V8 LC3/(A) 4.6L V8 LH2/(V) 3.6L V6 LLT	Amplifier (Bose)	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	D	STS	Body	Navigation Radio	(V) 3.6L V6 LLT/(D) 4.4L V8 LC3/(A) 4.6L V8 LH2	Navigation Radio	●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	With (RPO JL7) (0000CDAD)	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	With (RPO JL7) (0000CDAD)	Electronic Suspension Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	With (RPO JL7) (0000CDAD)	Power Steering Control Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	With (RPO JL7) (0000CDAD)	Vehicle Stability Control Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	Without (RPO JL7) (0000CDAC)	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	D	STS	Chassis	Without (RPO JL7) (0000CDAC)	Electronic Suspension Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Powertrain	Engine Control Module				●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Powertrain	Transmission Control Module				●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Amplifier (Bose)			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Climate Control Seat Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Digital Radio Receiver/Distance Sensing Cruise Control			●	●	●	○	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Driver Door Switch/Driver Position Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	HVAC Control Module			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Inside Rear View Mirror			●	●	○	○	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Left Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Park Assist Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Passenger Presence System			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Rear Heated Seat Module/Radio/Right Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Right Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	TV Antenna Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ2 Dual Zone HVAC, Auto	Veh Direction Alert Alarm Warn Mod			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Amplifier (Bose)			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Aux. HVAC Control Module			○	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Body Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Climate Control Seat Module			●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Distance Sensing Cruise			●	●	●	○	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Driver Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Driver Position Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	HVAC Control Module			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Inside Rear View Mirror			●	●	○	○	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Left Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Park Assist Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Passenger Presence System			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Radio			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Rear Heated Seat Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Right Side Object			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	TV Antenna Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Vehicle Comm. Interface			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	K	Body	CJ4 Tri Zone HVAC, Auto	Veh Direction Alert Alarm Warn Mod			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	K	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	K	Chassis	Electronic Suspension				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Powertrain	(D) 4.4L V8 LC3	Engine Control Module			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	Y	Powertrain	(D) 4.4L V8 LC3	Exhaust Flow Control Module			●	●	●	●	●	○
(8) 2008	Passenger Car,LD Trk, MPV, Incomplete	Cadillac	Y,E	Powertrain	(A) 4.6L V8 LH2	Engine Control Module,Transmission Control			●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Amplifier (Bose)				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Body Control				●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	Y	Body	CD Changer				●	●	●	○	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Digital Radio Receiver				●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Distance Sensing Cruise Control				●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Driver Door				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Driver Door				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Driver Position Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Folding Top				●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Headlamp Control Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Head Up Display				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	HVAC Control				●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Navigation Radio				●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Passenger Door Module				●	●	●	●	○	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Passenger Presence System				○	●	○	●	○	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Cadillac	Y	Body	Remote Control Door Lock				●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Steering Column Lock Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	Y	Body	Supplemental Inflatable Restraint				●	●	●	●	○	●
(8) 2008	Passenger Car	Cadillac	Y	Body	Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	Passenger Car	Cadillac	Y	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Cadillac	Y	Chassis	Electronic Suspension				●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	M	Powertrain	(X) 2.0L L4 LNF	Automatic,Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	M	Powertrain	(X) 2.0L L4 LNF	Automatic	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	M	Powertrain	(B) 2.4L L4 LE5	Automatic,Manual	Engine Control Module,Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	M	Body	Body Control Module,Radio,Remote Control Door Lock Receiver,Supplemental Inflatable Restraint,Vehicle Comm. Interface				●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	M	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	Passenger Car	Saturn	M	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	M	Body	Passenger Presence System				○	●	○	●	○	●
(8) 2008	Passenger Car	Saturn	M	Body	Personal Audio Link Module				●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Saturn	M	Body	Theft Deterrent Module				●	●	●	●	○	●
(8) 2008	Passenger Car	Saturn	M	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Powertrain	(B) 2.4L L4 LE5, (N) 3.5L V6 LZ4, (7) 3.6L V6 LY7	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Powertrain	(B) 2.4L L4 LE5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Powertrain	(N) 3.5L V6 LZ4	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Powertrain	(7) 3.6L V6 LY7	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura/Aura Hybrid	Body	Automatic/Manual	Body Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	HVAC Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Radio, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Automatic	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Radio, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Body	Manual	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura	Chassis	Power Steering Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Powertrain	(5) 2.4L L4 LAT	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Powertrain	(5) 2.4L L4 LAT	Starter/Generator Control		○	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Powertrain	(5) 2.4L L4 LAT	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	HVAC Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Radio, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Automatic	Theft Deterrent Module		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	Personal Audio Link Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	ORadio, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Body	Manual	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	●
(8) 2008	Passenger Car	Holden	L	Powertrain	(R) 2.0L L4 LLW	5 Speed Automatic, Manual	Engine Control Module, Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	L	Powertrain	(K) 2.0L L6 LBM	6 Speed Automatic, Manual	Engine Control Module, Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	L	Powertrain	(L) 2.5L L6 LBK	6 Speed Automatic, Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	L	Powertrain	(L) 2.5L L6 LBK	6 Speed Automatic	Transmission Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	L	Body	ISU				●	●	●	●	○	●
(8) 2008	Passenger Car	Holden	L	Body	Supplemental Inflatable Restraint				●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Holden	L	Chassis	Teves	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	L	Chassis	Mando	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	N	Powertrain	(7) 1.4L L4 L95	Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	N	Powertrain	(6) 1.6L L4 LXT	(ML4/MLQ) 4 Speed Automatic,(M92) 4 Speed Automatic, Autom	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	N	Powertrain	(6) 1.6L L4 LXT	(ML4/MLQ) 4 Speed Automatic,(M92) 4 Speed Automatic, Autom	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	N	Powertrain	(B) 1.8L L4 LDA	Manual/(MFA) 4 Speed Automatic,(MFA) 4 Speed	Viva	Engine Control Module	●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	N	Body	IS09141_PROTOCOL	Immobilizer			○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	N	Body	IS09141_PROTOCOL	Remote Function Actuation			○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	N	Body	IS09141_PROTOCOL	Supplemental Inflatable Restraint			●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Body	KW82_PROTOCOL	Immobilizer			○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	N	Body	KW82_PROTOCOL	Remote Function Actuation			○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	N	Body	KW82_PROTOCOL	Supplemental Inflatable Restraint			●	●	●	○	●	○
(8) 2008	Passenger Car	Holden	N	Chassis	YES	YES	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	YES	YES	Power Steering Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	YES	YES	Tire Pressure Monitor		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Holden	N	Chassis	YES	NO	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	YES	NO	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	YES	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	YES	Power Steering Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	YES	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	NO	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	NO	Power Steering Control Module		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	N	Chassis	NO	NO	Tire Pressure Monitor		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	S	Powertrain	(T) 1.2L L4 LY4	Automatic, Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Passenger Car	Holden	S	Powertrain	(T) 1.2L L4 LY4	Automatic	Transmission Control Module		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door	KW2000_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	KW2000_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	KW2000_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door	IS09141_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	IS09141_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	IS09141_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	○	○
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door	KW82_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	KW82_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(5) Four-Door Sedan	KW82_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Passenger Car	Holden	S	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Immobilizer		○	●	○	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Remote Function Actuation		○	●	●	●	○	●
(8) 2008	Passenger Car	Holden	S	Body	(6) Four-Door Hatchback/Liftback	KW2000_PROTOCOL, IS09141_PROTOCOL, KW82_PROTOCOL	Supplemental Inflatable Restraint		●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	S	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	Passenger Car	Holden	S	Chassis	Tire Pressure Monitor				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR/HHR Panel	Powertrain	(X) 2.0L L4 LNF/(D) 2.2L L4 L61/(P) 2.4L L4 LE5	Automatic/Manual	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR/HHR Panel	Powertrain	(X) 2.0L L4 LNF/(D) 2.2L L4 L61/(P) 2.4L L4 LE5	Automatic	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR/HHR Panel	Body	Body Control Module Body Control Module Supplemental Inflatable Restraint Body Control Module Vehicle Comm. Interface Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Passenger Presence System			○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Personal Audio Link Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	Body	Theft Deterrent Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR/HHR Panel	Chassis	With VSES (RPO JL4) (0000C2A7)/Without VSES (RPO JL4) (0000C2A9)	(X) 2.0L L4 LNF/(D) 2.2L L4 L61/(P) 2.4L L4 LE5	Electronic Brake Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR/HHR Panel	Chassis	With VSES (RPO JL4) (0000C2A7)Without VSES (RPO JL4) (0000C2A9)	(X) 2.0L L4 LNF/(D) 2.2L L4 L61/(P) 2.4L L4 LE5	Power Steering Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Passenger Presence System			○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Personal Audio Link Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	Body	Theft Deterrent Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A/C	Tracker	Powertrain	(J) 2.0L L4 L34	Automatic	Powertrain Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	Tracker	Body	Immobilizer			○	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	Tracker	Body	Supplemental Inflatable Restraint			●	●	○	○	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	A	Tracker	Chassis	Electronic Brake Control			●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Avalanche/Silverado/Suburban/Tahoe	Body	Auto. HVAC/Manual HVAC	Amplifier (Bose)		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Avalanche/Silverado/Suburban/Tahoe	Body	Auto. HVAC/Manual HVAC	Assist Step Controller		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Avalanche/Silverado/Suburban/Tahoe	Body	Auto. HVAC/Manual HVAC	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C	Captiva/Typhoon	Powertrain	(R) 2.0L L4 LLW/(F) 2.4L L4 LD9/(G) 3.2L V6 LU1	5 Speed Automatic/Manual	With All Wheel Drive	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C	Captiva/Typhoon	Powertrain	(R) 2.0L L4 LLW/(F) 2.4L L4 LD9/(G) 3.2L V6 LU1	Manual/5 Speed Automatic	Without All Wheel Drive/With All Wheel Drive	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Auto. HVAC/Manual	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Auto. HVAC	Remote Control Door Lock Receiver, Supplemental Inflatable		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Manual HVAC	Remote Control Door Lock Receiver, Supplemental Inflatable		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	Chassis	Power Steering Control Module			●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (3) 5.3L V8 LC9, (M) 5.3L V8 LH6, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (3) 5.3L V8 LC9, (M) 5.3L V8 LH6, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(C) 4.8L V8 LY2	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Powertrain	(6) 6.6L V8 LMM Diesel	6 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C	Silverado/Sierra	Powertrain	(6) 6.6L V8 LMM Diesel	6 Speed Automatic	Glow Plug Control Module	●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Silverado/Sierra	Chassis	Under 8600 GVW	With VSES (RPO JL4) (0000C2A7)/Without VSES (RPO JL4) (0000C2A9)	Electronic Brake Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C/K	Silverado/Sierra	Chassis	Under 8600 GVW	With VSES (RPO JL4) (0000C2A7)/Without VSES (RPO JL4) (0000C2A9)	Electronic Suspension Control	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Silverado/Sierra	Chassis	Under 8600 GVW/Equal to or Over 8600 GVW	With VSES (RPO JL4) (0000C2A7)/Without VSES (RPO JL4) (0000C2A9)/With (RPO JH7) (0000D25F)/Without (RPO JH7) (0000D260)	Trailer Brake Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Silverado	Chassis	Equal to or Over 8600 GVW	With (RPO JH7) (0000D25F)/Without (RPO JH7) (0000D260)	Electronic Brake Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C/K	Silverado	Chassis	Equal to or Over 8600 GVW	With (RPO JH7) (0000D25F)/Without (RPO JH7) (0000D260)	Electronic Suspension Control	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Under 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Under 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Under 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Equal to or Over 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Equal to or Over 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Suburban	Chassis	Equal to or Over 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Powertrain	(C) 4.8L V8 LY2, (O) 5.3L V8 LMG, (J) 5.3L V8 LY5	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Powertrain	(C) 4.8L V8 LY2	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Powertrain	(C) 4.8L V8 LY2, (O) 5.3L V8 LMG, (J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Powertrain	(O) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●



# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C/K	Tahoe Hybrid/Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Accessory Power Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C/K	Tahoe Hybrid/Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Battery Energy Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Hybrid Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Motor Control Modules		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	C/K	Tahoe Hybrid/Yukon Hybrid	Body	Auto. HVAC	A/C Compressor Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Tahoe Hybrid	Body	Auto. HVAC	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C/K	Tahoe Hybrid	Body	Auto. HVAC	Body Control Module (aux.)		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Body	Auto. HVAC	Serial Data Gateway Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tracker	Body	Immobilizer			○	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tracker	Body	Supplemental Inflatable Restraint			●	●	○	○	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tracker	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6, (6) 6.6L V8 LMM Diesel	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	G	Express/Savana/Express Access/Savana Pro	Powertrain	(6) 6.6L V8 LMM Diesel	Auxiliary Heater Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(6) 6.6L V8 LMM Diesel	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Powertrain	(6) 6.6L V8 LMM Diesel	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	G/H	Express/Savana/Express Access/Savana Pro	Chassis	Without VSES (RPO JL4) (0000C2A9)	With (RPO JH7)/Without (RPO JH7)	Electronic Brake Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6, (6) 6.6L V8 LMM Diesel	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(6) 6.6L V8 LMM Diesel	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Powertrain	(6) 6.6L V8 LMM Diesel	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Body	Theft Deterrent Module			●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express/Savana	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	Engine Control Module, Engine Control Module, Engine Control Module, Engine Control Module	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Body	Radio			●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	H	Express Access/Savana Pro	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(3) 5.3L V8 LC9	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(3) 5.3L V8 LC9	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(0) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(0) 5.3L V8 LMG	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(J) 5.3L V8 LY5	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Powertrain	(Y) 6.0L V8 L76	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Powertrain	(X) 4.3L V6 LU3/(C) 4.8L V8 LY2/(3) 5.3L V8 LC9/(M) 5.3L V8 LH6/(O) 5.3L V8 LMG/(J) 5.3L V8 LY5/(Y) 6.0L V8 L76/(K) 6.0L V8 LY6	YES/NO	Engine Control Module	●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Powertrain	(X) 4.3L V6 LU3/(C) 4.8L V8 LY2/(3) 5.3L V8 LC9/(M) 5.3L V8 LH6/(O) 5.3L V8 LMG/(J) 5.3L V8 LY5/(Y) 6.0L V8 L76/(K) 6.0L V8 LY6	YES/NO	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	K	Silverado/Sierra	Powertrain	(X) 4.3L V6 LU3/(C) 4.8L V8 LY2/(3) 5.3L V8 LC9/(M) 5.3L V8 LH6/(O) 5.3L V8 LMG/(J) 5.3L V8 LY5/(Y) 6.0L V8 L76/(K) 6.0L V8 LY6	YES	Transfer Case Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	K	Silverado/Sierra	Powertrain	(C) 4.8L V8 LY2/(M) 5.3L V8 LH6/(Y) 6.0L V8 L76	YES/NO	Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC	K	Silverado/Sierra	Powertrain	(6) 6.6L V8 LMM Diesel	YES/NO	6 Speed Automatic	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Driver Position Module, Park Assist Module, Radio, Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(3) 5.3L V8 LC9	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(3) 5.3L V8 LC9	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(0) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(0) 5.3L V8 LMG	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(J) 5.3L V8 LY5	Transfer Case Control Module		●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(Y) 6.0L V8 L76	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Powertrain	(K) 6.0L V8 LY6	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Passenger Presence Sensor, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Radio		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Under 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Under 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Under 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Equal to or Over 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Equal to or Over 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	Chassis	Equal to or Over 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(C) 4.8L V8 LY2, (O) 5.3L V8 LMG, (J) 5.3L V8 LY5	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(C) 4.8L V8 LY2	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(O) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(O) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(O) 5.3L V8 LMG	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Powertrain	(J) 5.3L V8 LY5	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Hybrid Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Motor Control Modules		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Powertrain	(5) 6.0L V8 LFA	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K/C	Tahoe Hybrid	Body	Auto. HVAC	Amplifier (Bose)		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Serial Data Gateway Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Powertrain	(P) 2.4L L4 LE5	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Powertrain	(P) 2.4L L4 LE5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport/Equinox	Powertrain	(7) 3.6L V6 LY7/(F) 3.4L V6 LNJ	Without All Wheel Drive/With All	Transmission Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Auto. HVAC/Manual	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Auto. HVAC	HVAC Control Module, Passenger Presence System, Radio, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Manual HVAC	Passenger Presence System, Radio, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	Chassis	Power Steering Control Module			●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox/Captiva Sport	Powertrain	(F) 3.4L V6 LNJ/(7) 3.6L V6 LY7	Without All Wheel Drive/With All	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	L	Equinox/VUE/Captiva Sport	Powertrain	(F) 3.4L V6 LNJ/(7) 3.6L V6 LY7	With All Wheel Drive	Rear Drive System	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Heated Seat Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	HVAC Control Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	Chassis	Power Steering Control Module			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Powertrain	(9) 2.9L L4 LLV	4 Speed Automatic/Manual	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	Colorado/Traillazer	Powertrain	(9) 2.9L L4 LLV/(E) 3.7L L5 LLR/(L) 5.3L V8 LH8	4 Speed Automatic	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Powertrain	(E) 3.7L L5 LLR/(L) 5.3L V8 LH8	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Base Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Body	Uplevel Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Chassis	Without Traction	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Colorado	Chassis	With Traction Control	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	TrailBlazer	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	TrailBlazer	Powertrain	(M) 5.3L V8 LH6, (H) 6.0L V8 LS2	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	TrailBlazer	Powertrain	(M) 5.3L V8 LH6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	TrailBlazer	Powertrain	(H) 6.0L V8 LS2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	TrailBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Body Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TrailBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	TrailBlazer	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display	●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TrailBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto	Driver Door Module	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Driver Seat Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Generator Battery Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	HVAC Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Liftgate Module	●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Passenger Door Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Passenger Presence System	○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Radio	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	TraillBlazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Rear Seat Audio	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	Traiblazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Theft Deterrent Module	●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	S/T	Traiblazer/Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Vehicle Comm. Interface Module	●	●	●	●	●	●
														○
														○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S/T	Traiblazer/Envoy	Body	Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Navigation Radio	●	●	●	●	○	●
														○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	S	Traiblazer	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Powertrain	(9) 2.9L L4 LLV	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Powertrain	(9) 2.9L L4 LLV/(E) 3.7L L5 LLR/(L) 5.3L V8 LH8	4 Speed Automatic/Manual	Transfer Case Control Module	●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Powertrain	(9) 2.9L L4 LLV	Manual	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado/Traiblazer	Powertrain	(L) 5.3L V8 LH8/(S) 4.2L L6 LL8/(E) 3.7L L5 LLR	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Generator Battery Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Base Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Body	Uplevel Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	Colorado	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck/GMC Truck	T	TrailBlazer/Envoy	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Transfer Case Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	TrailBlazer	Powertrain	(M) 5.3L V8 LH6, (H) 6.0L V8 LS2	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	TrailBlazer	Powertrain	(M) 5.3L V8 LH6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	TrailBlazer	Powertrain	(M) 5.3L V8 LH6	Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	TrailBlazer	Powertrain	(H) 6.0L V8 LS2	Transmission Control Module		●	●	●	●	●	○
														○
														○
														○
														○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet Truck	T	TrailBlazer	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (3) 5.3L V8 LC9, (M) 5.3L V8 LH6, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(C) 4.8L V8 LY2	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(3) 5.3L V8 LC9	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(M) 5.3L V8 LH6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(0) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(K) 6.0L V8 LY6, (8) 6.2L V8 L92	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Powertrain	(6) 6.6L V8 LMM Diesel/(X) 4.3L V6 LU3/(C) 4.8L V8 LY2/(3) 5.3L V8 LC9/(0) 5.3L V8 LMG/(J) 5.3L V8 LY5/(Y) 6.0L V8 L76/(K) 6.0L	6 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C/K	Sierra/Yukon/Yukon XL	Body	Auto. HVAC/Manual	Amplifier (Bose)		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra/Yukon/Yukon XL	Body	Auto. HVAC	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C/K	Sierra/Yukon/Yukon XL	Body	Auto. HVAC/Manual	Body Control Module (aux.)		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Sierra	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual HVAC	Uplevel Radio	Body Control Module, Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental Inflatable Restraint	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual	Uplevel Radio	Body Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual HVAC	Uplevel Radio	Front Display Interface	●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC	Uplevel Radio	HVAC Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual	Uplevel Radio	Instrument Panel	●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual	Uplevel Radio	Park Assist Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Body	Auto. HVAC/Manual HVAC	Uplevel Radio	Theft Deterrent Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Typhoon	Chassis	Power Steering Control Module			●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(C) 4.8L V8 LY2, (O) 5.3L V8 LMG, (J) 5.3L V8 LY5, (8) 6.2L V8 L92		Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(C) 4.8L V8 LY2		Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(C) 4.8L V8 LY2		Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(O) 5.3L V8 LMG		Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(O) 5.3L V8 LMG		Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(J) 5.3L V8 LY5		Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(J) 5.3L V8 LY5		Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(8) 6.2L V8 L92		Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Powertrain	(8) 6.2L V8 L92		Transmission Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C/K	Yukon/Yukon XL	Body	Auto. HVAC/Manual	Assist Step Controller		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Hybrid Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Motor Control Modules		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C/K	Yukon Hybrid	Body	Auto. HVAC	Amplifier (Bose)		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C/K	Yukon Hybrid	Body	Auto. HVAC	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Body Control Module (aux.)		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Radio		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Serial Data Gateway Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon Hybrid	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6, (8) 6.2L V8 L92	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(3) 5.3L V8 LC9	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(0) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(K) 6.0L V8 LY6, (8) 6.2L V8 L92	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Under 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Under 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Under 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Equal to or Over 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Equal to or Over 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	C	Yukon XL	Chassis	Equal to or Over 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6, (6) 6.6L V8 LMM Diesel	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(6) 6.6L V8 LMM Diesel	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Powertrain	(6) 6.6L V8 LMM Diesel	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6, (6) 6.6L V8 LMM Diesel	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(6) 6.6L V8 LMM Diesel	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Powertrain	(6) 6.6L V8 LMM Diesel	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Roll-over Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express/Savana	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3, (C) 4.8L V8 LY2, (5) 5.3L V8 LMF, (K) 6.0L V8 LY6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(X) 4.3L V6 LU3	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(5) 5.3L V8 LMF	Transmission Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Body	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Body	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Body	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	H	Express Access/Savana Pro	Chassis	With VSES (RPO JL4) (0000C2A7)	Electronic Brake Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Powertrain	(X) 4.3L V6 LU3/(C) 4.8L V8 LY2/(3) 5.3L V8 LC9/(J) 5.3L V8 LY5/(Y) 6.0L V8 L76/(K) 6.0L V8 LY6/(M) 5.3L V8 LH6/(O) 5.3L V8 LMG	YES	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Powertrain	(8) 6.2L V8 L92	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Powertrain	(8) 6.2L V8 L92	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(C) 4.8L V8 LY2, (O) 5.3L V8 LMG, (J) 5.3L V8 LY5, (8) 6.2L V8 L92	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(C) 4.8L V8 LY2	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module		●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(O) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(O) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(O) 5.3L V8 LMG	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(J) 5.3L V8 LY5	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Powertrain	(8) 6.2L V8 L92	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Hybrid Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Motor Control Modules		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Powertrain	(5) 6.0L V8 LFA	Transfer Case Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Serial Data Gateway Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Chassis	Electronic Suspension Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	Chassis	Trailer Brake Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(3) 5.3L V8 LC9, (0) 5.3L V8 LMG, (J) 5.3L V8 LY5, (Y) 6.0L V8 L76, (K) 6.0L V8 LY6, (8) 6.2L V8 L92	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(3) 5.3L V8 LC9	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(3) 5.3L V8 LC9	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(3) 5.3L V8 LC9	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(0) 5.3L V8 LMG	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(0) 5.3L V8 LMG	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(0) 5.3L V8 LMG	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(J) 5.3L V8 LY5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(J) 5.3L V8 LY5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(J) 5.3L V8 LY5	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(Y) 6.0L V8 L76	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(Y) 6.0L V8 L76	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(Y) 6.0L V8 L76	Transfer Case Control Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(K) 6.0L V8 LY6, (8) 6.2L V8 L92	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(K) 6.0L V8 LY6	Transfer Case Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Rear Heated Seat Module		●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Driver Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Driver Position Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Passenger Door Switch		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Personal Audio Link Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Radio		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Rear Heated Seat Module		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Rear HVAC/RSA		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Under 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Under 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Under 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Equal to or Over 8600 GVW	Electronic Brake Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Equal to or Over 8600 GVW	Electronic Suspension Control		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	Chassis	Equal to or Over 8600 GVW	Trailer Brake Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Powertrain	(F) 2.4L L4 LD9	5 Speed Automatic/Manual	Without All Wheel Drive	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Powertrain	(F) 2.4L L4 LD9	5 Speed Automatic	Without All Wheel Drive/With All	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC/Manual HVAC	Uplevel Radio	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC/Manual HVAC	Uplevel Radio	Body Control Module (aux.)		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC	Uplevel Radio	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC	Uplevel Radio	Headlamp Control Module, Supplemental Inflatable Restraint, Remote Control Door Lock		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC	Uplevel Radio	HVAC Control Module, Instrument Panel		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC	Uplevel Radio	Park Assist Module		●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Auto. HVAC	Uplevel Radio	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Manual HVAC	Uplevel Radio	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Manual HVAC	Uplevel Radio	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Manual HVAC	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Manual HVAC	Uplevel Radio	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Body	Manual HVAC	Uplevel Radio	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	L	Chassis	Power Steering Control Module				●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Powertrain	Engine Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Automatic	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Automatic	Digital Radio Receiver			●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Automatic	Driver Door Switch, Head Up Display, Instrument Panel Cluster, Passenger Door Switch, Rear			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Automatic	HVAC Control Module, Liftgate Module, Personal Audio Link Module,			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Automatic	Memory Seat Module, Park Assist Module, Radio, Theft Deterrent Module,			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Driver Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Head Up Display			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Liftgate Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Memory Seat Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Personal Audio Link Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Rear HVAC/RSA			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Body	Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	R	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Canyon	Powertrain	(9) 2.9L L4 LLV	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Canyon	Powertrain	(9) 2.9L L4 LLV/(E) 3.7L L5 LLR/(L) 5.3L V8 LH8/(S) 4.2L L6 LL8	4 Speed Automatic	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Powertrain	(E) 3.7L L5 LLR	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Canyon	Powertrain	(L) 5.3L V8 LH8	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Canyon	Body	Base Radio/Uplevel Radio	Body Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Digital Radio Receiver		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Base Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Radio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Body	Uplevel Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Chassis	Without Traction	Electronic Brake Control		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	Chassis	With Traction Control	Electronic Brake Control		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Envoy	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Envoy	Powertrain	(M) 5.3L V8 LH6	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Envoy	Powertrain	(M) 5.3L V8 LH6	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S/T	Envoy	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display	●	●	○	○	●	○
														○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck/Chevrolet Truck	S/T	Envoy/Traillazer	Body	Uplevel Radio/Navigation Radio	CJ2 Dual Zone HVAC, Auto/CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint	●	●	●	●	○	●
														○
														○
														○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	S	Envoy	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Powertrain	(E) 3.7L L5 LLR	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Body	Base Radio	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Body	Base Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Body	Base Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Body	Base Radio	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Canyon	Body	Base Radio	Radio		●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	T	Envoy	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Powertrain	Engine Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Automatic	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Automatic	Memory Seat Module, Park Assist Module, Radio, Theft Deterrent Module			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Automatic	Driver Door Switch, Head Up Display, Instrument Panel Cluster, Passenger Door Switch, Rear			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Automatic	HVAC Control Module, Liftgate Module, Personal Audio Link Module,			●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Driver Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Head Up Display			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Liftgate Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Memory Seat Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Personal Audio Link Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Rear HVAC/RSA			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Body	Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	GMC Truck	V	Chassis	Electronic Brake Control Module				●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Powertrain	Engine Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Headlamp Control Module				●	●	●	○	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	HVAC Control Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Liftgate Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Memory Seat Module, Park Assist Module, Radio, Theft				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Personal Audio Link Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	R	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Powertrain	Engine Control Module				●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Headlamp Control Module				●	●	●	○	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	HVAC Control Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Liftgate Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Memory Seat Module, Park Assist Module, Radio, Theft				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Personal Audio Link Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Buick	V	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C,K	Powertrain	(8) 6.2L V8 L92	Engine Control Module, Transmission Control			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C,K	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module			●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C,E,K	Body	Amplifier (Bose)				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C,K	Body	Assist Step Controller				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Body Control Module (aux.), Climate Control Seat Module, Driver Position Module, Park Assist				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	HVAC Control Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Inside Rear View Mirror Module				●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Liftgate Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Personal Audio Link Module				●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Rear Heated Seat Module				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Chassis	Electronic Suspension				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	C	Chassis	Trailer Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Powertrain	(7) 3.6L V6 LY7	Engine Control Module, Transmission Control			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Body Control Module, Passenger Presence System, Radio, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Body Control Module (aux.), Memory Seat Module, Park Assist Module, Rear Seat				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Headlamp Leveling Modules				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	HVAC Control Module				●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Liftgate Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Body	TV Antenna Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	E	Chassis	Electronic Suspension				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Body Control Module (aux.), Climate Control Seat Module, Driver Position Module, Park Assist				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	HVAC Control Module				●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Inside Rear View Mirror Module				●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Liftgate Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Personal Audio Link Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Rear Heated Seat Module				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Chassis	Electronic Suspension				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac	K	Chassis	Trailer Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(P) 2.4L L4 LE5, (N) 3.5L V6 LZ4	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(P) 2.4L L4 LE5	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(P) 2.4L L4 LE5	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(N) 3.5L V6 LZ4	Fuel Pump Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(N) 3.5L V6 LZ4	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(N) 3.5L V6 LZ4	Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(7) 3.6L V6 LY7	Without All Wheel Drive	Engine Control Module	●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(7) 3.6L V6 LY7	Without All Wheel Drive/With All	Fuel Pump Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Powertrain	(7) 3.6L V6 LY7	Without All Wheel Drive/With All	Transmission Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE/VUE Hybrid	Body	Auto. HVAC/Manual	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Auto. HVAC	HVAC Control Module, Passenger Presence System, Radio, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Manual HVAC	Passenger Presence System, Radio, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Powertrain	Battery Energy Control Module			○	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Powertrain	Engine Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Powertrain	Fuel Pump Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Powertrain	Starter/Generator Control			○	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Powertrain	Transmission Control Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Auto. HVAC	Digital Radio Receiver		●	●	●	○	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Auto. HVAC	HVAC Control Module, Passenger Presence System, Radio, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Auto. HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Auto. HVAC	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Manual HVAC	Digital Radio Receiver		●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Manual HVAC	HVAC Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Manual HVAC	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Manual HVAC	Passenger Presence System, Radio, Remote Control Door Lock Receiver, Roll over Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Body	Manual HVAC	Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Chassis	Electronic Brake Control			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	L	VUE Hybrid	Chassis	Power Steering Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Powertrain	Engine Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Automatic	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Automatic	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Automatic	Driver Door Switch, Instrument Panel Cluster, Passenger Door Switch, Rear			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Automatic	HVAC Control Module, Liftgate Module, Personal Audio Link			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Automatic	Memory Seat Module, Park Assist Module, Radio, Theft Deterrent Module			●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Driver Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Liftgate Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Memory Seat Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Personal Audio Link Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Rear HVAC/RSA			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Body	Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	R	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Powertrain	Engine Control Module				●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Automatic	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Automatic	Digital Radio Receiver			●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Automatic	Driver Door Switch, Instrument Panel Cluster, Passenger Door Switch, Rear			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Automatic	HVAC Control Module, Liftgate Module, Personal Audio Link			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Automatic	Memory Seat Module, Park Assist Module, Radio, Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Digital Radio Receiver			●	●	●	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Driver Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	HVAC Control Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Liftgate Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Memory Seat Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Passenger Door Switch			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Personal Audio Link Module			●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Radio			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Rear HVAC/RSA			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Body	Manual	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Saturn	V	Chassis		Electronic Brake Control Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Powertrain		Engine Control Module, Transmission Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse, Limousine	Body		Amplifier (Bose)			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body		Body Control Module, Passenger Presence System, Radio, Supplemental Inflatable Restraint, Vehicle Comm. Interface			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	Driver Position Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	HVAC Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	Rear Heated Seat Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body	Theft Deterrent Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Chassis	Air Suspension Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Powertrain	Engine Control Module, Transmission Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Aux. HVAC Control Module				○	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Body Control Module, Passenger Presence System, Radio, Supplemental Inflatable Restraint, Vehicle Comm. Interface				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Driver Position Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	HVAC Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Instrument Panel Cluster				●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Rear Heated Seat Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	Theft Deterrent Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis	Air Suspension Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(F) 3.4L V6 LNJ	Without All Wheel Drive	Engine Control Module, Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(F) 3.4L V6 LNJ	With All Wheel Drive	Engine Control Module, Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(F) 3.4L V6 LNJ	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(7) 3.6L V6 LY7	Without All Wheel Drive	Engine Control Module, Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(7) 3.6L V6 LY7	With All Wheel Drive	Engine Control Module, Transmission Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain	(7) 3.6L V6 LY7	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Body Control Module, Passenger Presence System, Remote Control Door Lock Receiver, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Heated Seat Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	HVAC Control Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Radio				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Body	Theft Deterrent Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	L	Chassis	Power Steering Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV, Chevrolet MPV	U, V	Powertrain	(W) 3.9L V6 LGD	Engine Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV, Chevrolet MPV	U, V	Powertrain	(W) 3.9L V6 LGD	Transmission Control Module			●	●	●	●	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	U	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV/Chevrolet MPV	V/U	Body	Base Radio/Uplevel Radio/Navigation Radio	CJ3 Dual Zone HVAC, Manual/C60 Single Zone	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Pontiac APV	V	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Supplemental Inflatable Restraint Right Power Sliding		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Base Radio	C60 Single Zone HVAC, Manual	Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Navigation Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Navigation Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio/Uplevel Radio/Navigation Radio	CJ3 Dual Zone HVAC, Manual/C60 Single Zone	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	CJ3 Dual Zone HVAC, Manual	Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Base Radio	C60 Single Zone HVAC, Manual	Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	CJ3 Dual Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Left Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Uplevel Radio	C60 Single Zone HVAC, Manual	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Navigation Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	CJ3 Dual Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Digital Radio Receiver, Remote Control Door Lock Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	HVAC Control Module, Instrument Panel Cluster, Left Power Sliding Door Module, Right Power Sliding Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Navigation Radio, Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Body	Navigation Radio	C60 Single Zone HVAC, Manual	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	(8) 6.2L V8 L92	Engine Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	(8) 6.2L V8 L92	Fuel Pump Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	(8) 6.2L V8 L92	Transmission Control Module			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	(8) 6.2L V8 L92	Transfer Case Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Amplifier (Bose)				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Body Control Module, Passenger Presence System, Rollover Sensor, Supplemental Inflatable Restraint, Vehicle Comm. Interface Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Digital Radio Receiver				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Driver Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Driver Position Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	HVAC Control Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Passenger Door Switch				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Personal Audio Link Module				●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Radio				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Rear Heated Seat Module				●	●	●	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Rear HVAC/RSA				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	Theft Deterrent Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Chassis	Air Suspension Control Module				●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT/ADM	Powertrain	(E) 3.7L L5 LLR	4 Speed Automatic	Engine Control Module	●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT/ADM	Powertrain	(E) 3.7L L5 LLR	4 Speed Automatic/Manual	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT/ADM	Powertrain	(E) 3.7L L5 LLR	4 Speed Automatic/Manual	Transfer Case Control Module	●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Powertrain	(L) 5.3L V8 LH8	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Powertrain	(L) 5.3L V8 LH8	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Powertrain	(L) 5.3L V8 LH8	Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT/ADM	Body	Uplevel Radio/Navigation Radio	Body Control Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Uplevel Radio	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Uplevel Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Uplevel Radio	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Uplevel Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Navigation Radio	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Navigation Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Navigation Radio	Instrument Panel Cluster		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Navigation Radio	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Body	Navigation Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GT	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Powertrain	(L) 5.3L V8 LH8	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Powertrain	(L) 5.3L V8 LH8	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Powertrain	(L) 5.3L V8 LH8	Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Uplevel Radio	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Uplevel Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Uplevel Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Uplevel Radio	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Uplevel Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Navigation Radio	Digital Radio Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Navigation Radio	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Navigation Radio	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Navigation Radio	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Body	Navigation Radio	Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	Chassis	Electronic Brake Control			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Engine Control Module			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Transmission Control Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(S) 4.2L L6 LL8	4 Speed Automatic	Transfer Case Control Module			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(M) 5.3L V8 LH6, (H) 6.0L V8 LS2	Engine Control Module				●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(M) 5.3L V8 LH6	Transmission Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Powertrain	(M) 5.3L V8 LH6	Transfer Case Control Module				●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio/Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Body Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Seat Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Presence System		○	●	○	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Rear Seat Audio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Seat Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Rear Seat Audio		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Seat Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Rear Seat Audio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	Without HID Headlamps	CJ2 Dual Zone HVAC, Auto	Theft Deterrent Module		●	●	●	●	○	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Digital Radio Receiver, Vehicle Comm. Interface		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Disc Player and Video Display		●	●	○	○	●	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Driver Seat Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Generator Battery Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Liftgate Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Navigation Radio		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Door Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Passenger Presence System		○	●	○	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Rear Seat Audio		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Supplemental Inflatable Restraint		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio	With HID Headlamps	CJ2 Dual Zone HVAC, Auto	Theft Deterrent Module		●	●	●	●	○	●
(8) 2008	LD Trk, MPV, Incomplete	SAAB	Chassis	Electronic Brake Control Module					●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva/Captiva Maxx	Powertrain	(G) 3.2L V6 LU1	5 Speed Automatic/Manual	Without All Wheel Drive	Engine Control Module	●	●	●	●	●	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva/Captiva Maxx	Powertrain	(G) 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive/With All	Transmission Control Module	●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Auto. HVAC	Body Control Module, Supplemental Inflatable Restraint, Remote Control Door Lock Receiver			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Auto. HVAC	Body Control Module (aux.), Theft Deterrent			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Auto. HVAC	HVAC Control Module, Instrument Panel			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Body Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Body Control Module (aux.)			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Remote Control Door Lock Receiver			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Body	Manual HVAC	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva	Chassis	Power Steering Control Module				●	●	○	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Auto. HVAC	Body Control Module, Supplemental Inflatable Restraint, Remote Control Door Lock Receiver, Radio, Headlamp			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Auto. HVAC	Body Control Module (aux.), Theft Deterrent Module, Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Auto. HVAC	Front Display Interface			●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Auto. HVAC	HVAC Control Module, Instrument Panel			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Body Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Body Control Module (aux.)			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Front Display Interface			●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Headlamp Control Module			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Instrument Panel Cluster			●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Park Assist Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Radio			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Remote Control Door Lock Receiver			●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Supplemental Inflatable Restraint			●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	Manual HVAC	Theft Deterrent Module			●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Chassis	Electronic Brake Control Module				●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Chassis	Power Steering Control Module				●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(R) 2.0L LLW L4	5 Speed Automatic	Without All Wheel Drive,With All Wheel Drive	Engine Control Module,Transmission Control Module,Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(R) 2.0L LLW L4	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(R) 2.0L LLW L4	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(R) 2.0L LLW L4	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(U) 2.0L LMN L4	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(U) 2.0L LMN L4	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(U) 2.0L LMN L4	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L LD9 L4	5 Speed Automatic	Without All Wheel Drive,With All	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L LD9 L4	5 Speed Automatic	Without All Wheel Drive,With All	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L LD9 L4	5 Speed Automatic	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L LD9 L4	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L LD9 L4	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(F) 2.4L L4 LD9	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive,With All	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive,With All	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	5 Speed Automatic	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Powertrain	(P) 3.2L V6 LU1	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Headlamp Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Radio		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Remote Control Door Lock Receiver		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Auto. HVAC	Uplevel Radio	YES	Theft Deterrent Module		●	●	●	●	●	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Manual HVAC	Navigation Radio	NO	Supplemental Inflatable Restraint		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Opel	Body	Manual HVAC	Navigation Radio	NO	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Chassis	Electronic Brake Control Module					●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Opel	Chassis	Power Steering					●	●	○	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW, (F) 2.4L L4 LD9, (P) 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive, With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW, (F) 2.4L L4 LD9, (P) 3.2L V6 LU1	5 Speed Automatic	Without All Wheel Drive, With All Wheel Drive	Transmission Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW	5 Speed Automatic	With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW, (F) 2.4L L4 LD9, (P) 3.2L V6 LU1	5 Speed Automatic	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2.0L L4 LLW	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(U) 2.0L L4 LMN	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(U) 2.0L L4 LMN	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(U) 2.0L L4 LMN	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(F) 2.4L L4 LD9	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(F) 2.4L L4 LD9	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(F) 2.4L L4 LD9	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(P) 3.2L V6 LU1	Manual	Without All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(P) 3.2L V6 LU1	Manual	With All Wheel Drive	Engine Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(P) 3.2L V6 LU1	Manual	With All Wheel Drive	Rear Drive System		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall/Opel	Body	Auto. HVAC/Manual HVAC	Uplevel Radio/Navigation Radio	YES/NO	Body Control Module		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall/Opel	Body	Auto. HVAC	Uplevel Radio/Navigation Radio	YES/NO	Body Control Module (aux.)		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall/Opel	Body	Auto. HVAC	Uplevel Radio/Navigation Radio	YES	Cellular Telephone		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	YES	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	Front Display Interface		●	●	○	○	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Uplevel Radio	NO	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	YES	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	Front Display Interface		●	●	○	○	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	HVAC Control Module		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Auto. HVAC	Navigation Radio	NO	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	YES	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	YES	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	YES	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	YES	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	YES	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	NO	Front Display Interface		●	●	○	○	●	●



# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	NO	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	NO	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	NO	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Uplevel Radio	NO	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	YES	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	YES	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	YES	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	YES	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	YES	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	NO	Front Display Interface		●	●	○	○	●	●
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	NO	Headlamp Control Module, Radio, Remote Control Door Lock Receiver, Supplemental		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	NO	Instrument Panel Cluster		●	●	●	●	○	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	NO	Park Assist Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Body	Manual HVAC	Navigation Radio	NO	Theft Deterrent Module		●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Chassis	Electronic Brake Control Module					●	●	●	●	●	○
(8) 2008	LD Trk, MPV, Incomplete	Vauxhall	Chassis	Power Steering					●	●	○	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(6) 5.2L L4 Diesel	Automatic,Manual	Engine Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(6) 5.2L L4 Diesel	Automatic	Transmission Control Module		●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Engine Control Module		●	●	●	●	●	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Transmission Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Transfer Case Control Module		●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(B) 7.8L L6 LF8	Automatic,Manual	Engine Control Module		●	●	●	●	●	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(G) 8.1L V8 L18	5 Speed Automatic,Manual	Powertrain Control Module		●	●	●	●	●	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(G) 8.1L V8 L18	5 Speed Automatic,Manual	Transmission Control Module,Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - WT5500	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	T - B7 Chassis	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	Chime				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	Radio				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	Serial Data Gateway (If				●	●	●	○	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	Supplemental Inflatable Restraint				●	●	●	●	○	●
(8) 2008	Medium Duty Truck	Chevrolet Truck	D - C Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - T Series	Body	Chime				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - T Series	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - T Series	Body	Serial Data Gateway (If				●	●	●	○	○	○
(8) 2008	Medium Duty Truck	Chevrolet Truck	C - T Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Medium Duty Truck	Chevrolet Truck	B - W4 Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(6) 5.2L L4 Diesel	Manual,Automatic	Engine Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Engine Control Module		●	●	●	●	●	●
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Glow Plug Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Transmission Control Module		●	●	●	●	○	●
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(9) 6.6L V8 LMM Diesel	6 Speed Automatic	Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(B) 7.8L L6 LF8	Automatic	Engine Control Module		●	●	●	●	●	●
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500,T - B7 Chassis,D - C Series,C - T Series,B - W4	Powertrain	(G) 8.1L V8 L18	5 Speed Automatic,Manual	Powertrain Control Module		●	●	●	●	●	●

# MaxiDAS\_GM\_V2.00 Function List

**NOTES:**

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500, T - B7 Chassis, D - C Series, C - T Series, B - W4	Powertrain	(G) 8.1L V8 L18	5 Speed Automatic, Manual	Transmission Control Module, Transfer Case Control Module		●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - WT5500	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	T - B7 Chassis, D - C Series, C - T Series, B - W4 Series	Powertrain	(6) 5.2L L4 Diesel	Automatic	Transmission Control Module		●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	T - B7 Chassis	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Body	Chime				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Body	Radio				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Body	Serial Data Gateway (If				●	●	●	○	○	○
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Body	Supplemental Inflatable Restraint				●	●	●	●	○	●
(8) 2008	Medium Duty Truck	GMC Truck	D - C Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - T Series	Body	Chime				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - T Series	Body	Instrument Panel Cluster				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - T Series	Body	Serial Data Gateway (If				●	●	●	○	○	○
(8) 2008	Medium Duty Truck	GMC Truck	C - T Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Medium Duty Truck	GMC Truck	B - W4 Series	Chassis	Electronic Brake Control Module				●	●	●	●	○	○
(8) 2008	Workhorse	6 - W20 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	6 - W20 Series	Powertrain	(G) 8.1L V8 L18	Transmission Control Module				●	●	●	●	○	○



# MaxiDAS\_GM\_V2.00 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

MENU_01	MENU_02	MENU_03	MENU_04	MENU_05	MENU_06	MENU_07	MENU_08	MENU_09	Read Codes	Erase Codes	Live Data	Active Test	Ecu Info.	Module Setup
(8) 2008	Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18	Transmission Control Module				●	●	●	●	○	○
(8) 2008	Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18	Transmission Control Module				●	●	●	●	○	○
(8) 2008	Workhorse	D - W42 Series	Powertrain	(C) 4.8L V8 LY2, (K) 6.0L V8 LY6	Engine Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	D - W42 Series	Powertrain	(C) 4.8L V8 LY2	Transmission Control Module				●	●	●	●	●	○
(8) 2008	Workhorse	D - W42 Series	Powertrain	(K) 6.0L V8 LY6	Transmission Control Module				●	●	●	●	●	○
(8) 2008	Workhorse	E - W16 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	E - W18 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	F - R26 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●
(8) 2008	Workhorse	F - R26 Series	Powertrain	(G) 8.1L V8 L18	Transmission Control Module				●	●	●	●	○	○
(8) 2008	Workhorse	G - W62 Series	Powertrain	(G) 8.1L V8 L18	Powertrain Control Module				●	●	●	●	●	●