

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	4X4	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	ABS	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	GEM	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	PAM	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	PCM	●	●	●	●
(All MY05)	2.3L	DURATEC-HE / I4	2005 MY	RCM	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	4X4	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	ABS	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	GEM	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	IC	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	PAM	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	PCM	●	●	●	●
(All MY05)	3.0L	4V	2005 MY	RCM	●	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	2000 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	1997 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	1999 MY	ABS	●	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	1999 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	ABS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	2001 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 MY	ABS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	RF-T	2000 MY	ABS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	1997 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	2000 MY	PCM	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	2001 MY	ABS/TCS	●	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	2001 MY	PCM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	ABS	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	EATC	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	EPS	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	IC	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	ICCM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	MPM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	PCM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RCM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RKE	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RVM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	TCM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	ABS	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	EATC	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	EPS	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	IC	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	ICCM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	MPM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	PCM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RCM	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RKE	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RVM	●	●	●	●
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	TCM	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	ABS	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	AFS	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	BCM/GEM	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	EATC	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	EPS	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	IC	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	ICCM	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	MPM	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	PCM	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	RCM	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	RKE	●	●	●	●
ATENZA / MAZDA6	1.8L	L8	Other	RVM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ATENZA / MAZDA6	1.8L	L8	Other	TCM	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	ABS	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	AFS	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	BCM/GEM	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	EATC	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	EPS	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	IC	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	ICCM	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	MPM	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	PCM	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	RCM	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	RKE	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	RVM	●	●	●	●
ATENZA / MAZDA6	2.0L	LF	Other	TCM	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	ABS	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	AFS	●	●	●	○
ATENZA / MAZDA6	2.2L	R2_T	Other	BCM/GEM	●	●	●	○
ATENZA / MAZDA6	2.2L	R2_T	Other	EATC	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	EPS	●	●	●	○
ATENZA / MAZDA6	2.2L	R2_T	Other	IC	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	ICCM	●	●	●	○
ATENZA / MAZDA6	2.2L	R2_T	Other	MPM	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	PCM	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	RCM	●	●	●	○
ATENZA / MAZDA6	2.2L	R2_T	Other	RKE	●	●	●	●
ATENZA / MAZDA6	2.2L	R2_T	Other	RVM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ATENZA / MAZDA6	2.2L	R2_T	Other	TCM	●	●	●	
ATENZA / MAZDA6	2.5L	L5	Other	ABS	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	AFS	●	●	●	○
ATENZA / MAZDA6	2.5L	L5	Other	BCM/GEM	●	●	●	○
ATENZA / MAZDA6	2.5L	L5	Other	EATC	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	EPS	●	●	●	○
ATENZA / MAZDA6	2.5L	L5	Other	IC	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	ICCM	●	●	●	○
ATENZA / MAZDA6	2.5L	L5	Other	MPM	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	PCM	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	RCM	●	●	●	○
ATENZA / MAZDA6	2.5L	L5	Other	RKE	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	RVM	●	●	●	●
ATENZA / MAZDA6	2.5L	L5	Other	TCM	●	●	●	
ATENZA / MAZDA6	3.7L	CA	Other	ABS	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	AFS	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	BCM/GEM	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	EATC	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	EPS	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	IC	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	ICCM	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	MPM	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	PCM	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	RCM	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	RKE	●	●	●	●
ATENZA / MAZDA6	3.7L	CA	Other	RVM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ATENZA / MAZDA6	3.7L	CA	Other	TCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	ABS/TCS	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	IC	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	LHID	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	PCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	RCM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2002 MY	RHID	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	ABS/TCS	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	GEM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	IC	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	LHID	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	PCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RCM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RHID	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	RKE	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.0L	LF	2005 MY	TCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	IC	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	LHID	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	PCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	RCM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2002 MY	RHID	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	GEM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	IC	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	LHID	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	PCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RCM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RHID	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RKE	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	TCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	ABS/TCS	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	GEM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	IC	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	LHID	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	PCM	●	●	●	●
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	RCM	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	RHID	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3_T	2005 MY	RKE	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	ABS	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	AFS	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	EATC	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	EPS	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	IC	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	MID#1	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	
AXELA / MAZDA3	1.5L	ZY	Other	RCM	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	RKE	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	RVM	●	●	●	●
AXELA / MAZDA3	1.5L	ZY	Other	TCM	●	●	●	
AXELA / MAZDA3	1.6L	Y6	Other	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AXELA / MAZDA3	1.6L	Y6	Other	AFS	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	EATC	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	EPS	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	FACM	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	IC	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	MID#1	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	PCM	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	RCM	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	RKE	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	RVM	●	●	●	●
AXELA / MAZDA3	1.6L	Y6	Other	TCM	●	●	●	
AXELA / MAZDA3	1.6L	Z6	Other	ABS	●	●	●	●
AXELA / MAZDA3	1.6L	Z6	Other	AFS	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	EATC	●	●	●	●
AXELA / MAZDA3	1.6L	Z6	Other	EPS	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	IC	●	●	●	●
AXELA / MAZDA3	1.6L	Z6	Other	MID#1	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	
AXELA / MAZDA3	1.6L	Z6	Other	RCM	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	RKE	●	●	●	●
AXELA / MAZDA3	1.6L	Z6	Other	RVM	●	●	●	●
AXELA / MAZDA3	1.6L	Z6	Other	TCM	●	●	●	
AXELA / MAZDA3	2.0L	LF	Other	ABS	●	●	●	●
AXELA / MAZDA3	2.0L	LF	Other	AFS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AXELA / MAZDA3	2.0L	LF	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	EATC	●	●	●	●
AXELA / MAZDA3	2.0L	LF	Other	EPS	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	IC	●	●	●	●
AXELA / MAZDA3	2.0L	LF	Other	MID#1	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	
AXELA / MAZDA3	2.0L	LF	Other	RCM	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	RKE	●	●	●	●
AXELA / MAZDA3	2.0L	LF	Other	RVM	●	●	●	●
AXELA / MAZDA3	2.0L	LF	Other	TCM	●	●	●	
AXELA / MAZDA3	2.2L	R2_T	Other	ABS	●	●	●	●
AXELA / MAZDA3	2.2L	R2_T	Other	AFS	●	●	●	○
AXELA / MAZDA3	2.2L	R2_T	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	2.2L	R2_T	Other	EATC	●	●	●	●
AXELA / MAZDA3	2.2L	R2_T	Other	EPS	●	●	●	○
AXELA / MAZDA3	2.2L	R2_T	Other	FFH	●	●	●	
AXELA / MAZDA3	2.2L	R2_T	Other	IC	●	●	●	●
AXELA / MAZDA3	2.2L	R2_T	Other	MID#1	●	●	●	○
AXELA / MAZDA3	2.2L	R2_T	Other	PCM	●	●	●	
AXELA / MAZDA3	2.2L	R2_T	Other	RCM	●	●	●	○
AXELA / MAZDA3	2.2L	R2_T	Other	RKE	●	●	●	●
AXELA / MAZDA3	2.2L	R2_T	Other	RVM	●	●	●	●
AXELA / MAZDA3	2.2L	R2_T	Other	TCM	●	●	●	
AXELA / MAZDA3	2.3L	L3_T	Other	ABS	●	●	●	●
AXELA / MAZDA3	2.3L	L3_T	Other	AFS	●	●	●	○
AXELA / MAZDA3	2.3L	L3_T	Other	BCM/GEM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AXELA / MAZDA3	2.3L	L3_T	Other	EATC	●	●	●	●
AXELA / MAZDA3	2.3L	L3_T	Other	EPS	●	●	●	○
AXELA / MAZDA3	2.3L	L3_T	Other	IC	●	●	●	●
AXELA / MAZDA3	2.3L	L3_T	Other	MID#1	●	●	●	○
AXELA / MAZDA3	2.3L	L3_T	Other	PCM	●	●	●	
AXELA / MAZDA3	2.3L	L3_T	Other	RCM	●	●	●	○
AXELA / MAZDA3	2.3L	L3_T	Other	RKE	●	●	●	●
AXELA / MAZDA3	2.3L	L3_T	Other	RVM	●	●	●	●
AXELA / MAZDA3	2.3L	L3_T	Other	TCM	●	●	●	
AXELA / MAZDA3	2.5L	L5	Other	ABS	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	AFS	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	BCM/GEM	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	EATC	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	EPS	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	IC	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	MID#1	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	RCM	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	RKE	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	RVM	●	●	●	●
AXELA / MAZDA3	2.5L	L5	Other	TCM	●	●	●	
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	PCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	TCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T		ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T		RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1999 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1999 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	ABS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T		ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T		RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1999 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1999 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2000 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2000 MY	RCM	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2001 MY	ABS	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2001 MY	RCM	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	ABS	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	RCM	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	ABS	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	RCM	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	ABS	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	RCM	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2003 MY	ABS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AZ-WAGON (MJ)	660cc	K6A T	2003 MY	RCM	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2005 MY	ABS	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2005 MY	RCM	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	ABS	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	BCM#1	●	●	●	●
AZ-WAGON / CAROL	660cc	K6A	Other	EATC	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	EPS	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	PCM	●	●	●	●
AZ-WAGON / CAROL	660cc	K6A	Other	RCM	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	TCM	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	ABS	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	BCM#1	●	●	●	●
AZ-WAGON / CAROL	660cc	K6A T	Other	EATC	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	EPS	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	PCM	●	●	●	●
AZ-WAGON / CAROL	660cc	K6A T	Other	RCM	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	TCM	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	ABS	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	RCM	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	ABS	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	RCM	●	●	●	○
AZ OFFROAD	660cc	K6A T	2003 MY	ABS	●	●	●	○
AZ OFFROAD	660cc	K6A T	2003 MY	RCM	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	ABS	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	RCM	●	●	●	○
AZ OFFROAD	660cc	K6A T	2008 MY	ABS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
AZ OFFROAD	660cc	K6A_T	2008 MY	PCM	●	●	●	●
AZ OFFROAD	660cc	K6A_T	2008 MY	RCM	●	●	●	○
AZ OFFROAD	660cc	K6A_T	2008 MY	TCM	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2001 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2002 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2002 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2005 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1999 MY	ABS	●	●	●	
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.9L	W9	2002 MY	ABS	●	●	●	
Biante(Japan)	2.0L	LF	2008 MY	ABS	●	●	●	●
Biante(Japan)	2.0L	LF	2008 MY	EATC	●	●	●	●
Biante(Japan)	2.0L	LF	2008 MY	EPS	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	GEM	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	IC	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	LPSDM	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	PCM	●	●	●	●
Biante(Japan)	2.0L	LF	2008 MY	RCM	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	RKE	●	●	●	

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Biante(Japan)	2.0L	LF	2008 MY	RPSDM	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	TCM	●	●	●	
Biante(Japan)	2.3L	L3	2008 MY	ABS	●	●	●	●
Biante(Japan)	2.3L	L3	2008 MY	EATC	●	●	●	●
Biante(Japan)	2.3L	L3	2008 MY	EPS	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	GEM	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	IC	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	LPSDM	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	PCM	●	●	●	●
Biante(Japan)	2.3L	L3	2008 MY	RCM	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	RKE	●	●	●	
Biante(Japan)	2.3L	L3	2008 MY	RPSDM	●	●	●	○
Biante(Japan)	2.3L	L3	2008 MY	TCM	●	●	●	
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	1999 MY	ABS	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	ABS/TCS	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	PCM	●	●	●	
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	TCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	PCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	TCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	PCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	TCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	ABS/TCS	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	PCM	●	●	●	●
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	TCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
BONGO / BONGO BRAUNY / SPECTRON	2.2L	R2	1999 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	1.8L	F8	1999 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1997 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1998 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1999 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	ABS/TCS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	PCM	●	●	●	
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	TCM	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.2L	R2	1999 MY	ABS	●	●	●	●
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.5L	WL	1999 MY	ABS	●	●	●	●
BT-50 / Ranger	2.2L	F2	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	2.2L	F2	2007 MY	PCM	●	●	●	
BT-50 / Ranger	2.2L	F2	2007 MY	RCM	●	●	●	○
BT-50 / Ranger	2.5L	WL	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	2.5L	WL	2007 MY	PCM	●	●	●	
BT-50 / Ranger	2.5L	WL	2007 MY	RCM	●	●	●	○
BT-50 / Ranger	2.5L	WL_CD	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	2.5L	WL_CD	2007 MY	PCM	●	●	●	●
BT-50 / Ranger	2.5L	WL_CD	2007 MY	RCM	●	●	●	○
BT-50 / Ranger	2.5L	WL_CD	2007 MY	TCM	●	●	●	●
BT-50 / Ranger	2.6L	G6	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	2.6L	G6	2007 MY	PCM	●	●	●	
BT-50 / Ranger	2.6L	G6	2007 MY	RCM	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007 MY	PCM	●	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
BT-50 / Ranger	3.0L	WE-CD	2007 MY	TCM	●	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ABS/TCS	●	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	ESOF	●	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	PCM	●	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007 MY	RCM	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	1999 MY	ABS	●	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	1999 MY	ABS	●	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.5L	KL	1999 MY	ABS	●	●	●	●
CAROL	660cc	F6A		ABS	●	●	●	○
CAROL	660cc	F6A		RCM	●	●	●	○
CAROL	660cc	F6A	1998 MY	ABS	●	●	●	○
CAROL	660cc	F6A	1998 MY	RCM	●	●	●	○
CAROL	660cc	K6A		ABS	●	●	●	○
CAROL	660cc	K6A		RCM	●	●	●	○
CAROL	660cc	K6A	1998 MY	ABS	●	●	●	○
CAROL	660cc	K6A	1998 MY	RCM	●	●	●	○
CAROL	660cc	K6A	1999 MY	ABS	●	●	●	○
CAROL	660cc	K6A	1999 MY	RCM	●	●	●	○
CAROL	660cc	K6A	2000 MY	ABS	●	●	●	○
CAROL	660cc	K6A	2000 MY	RCM	●	●	●	○
CAROL	660cc	K6A	2001 MY	ABS	●	●	●	○
CAROL	660cc	K6A	2001 MY	RCM	●	●	●	○
CAROL	660cc	K6A	2002 MY	ABS	●	●	●	○
CAROL	660cc	K6A	2002 MY	RCM	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2003 MY	ABS	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2003 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CAROL (2003 / 9 -)	660cc	K6A	2004 MY	ABS	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2004 MY	RCM	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	ABS	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	RCM	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	ABS	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	RCM	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	ABS	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EATC	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	EPS	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	FFH	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	GEM	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	IC	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	MID#1	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	PCM	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RCM	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RKE	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	RVM	●	●	●	●
CX-7 (Europe / General Specs.)	2.2L	R2_T	2009 MY	SCR CU	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	ABS	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	EATC	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	IC	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	RCM	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	EATC	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	GEM	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	IC	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	MID#1	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	PCM	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RCM	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RKE	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	RVM	●	●	●	●
CX-7 (Europe / General Specs.)	2.3L	L3_T	2009 MY	TCM	●	●	●	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ABS	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	EATC	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	IC	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	ICCM	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RCM	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2006 MY	TCM	●	●	●	
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ABS	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	EATC	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	GEM	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	IC	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	ICCM	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	MID#1	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	PCM	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RKE	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	RVM	●	●	●	●
CX-7 (Japan / General Specs.)	2.3L	L3_T	2009 MY	TCM	●	●	●	
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ABS	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	EATC	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	GEM	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	IC	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ICCM	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	MID#1	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	PCM	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RCM	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RKE	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RVM	●	●	●	●
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	TCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	ABS	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	EATC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	GEM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	IC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	PCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RCM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	RKE	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2007 MY	TCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	ABS	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	EATC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	GEM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	IC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	PCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RCM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	RKE	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2008 MY	TCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	ABS	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	EATC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	GEM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	IC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	PCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	RCM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	RKE	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2009 MY	TCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	ABS	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSML	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	BSMR	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	EATC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	GEM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	IC	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	MID#1	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	PCM	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RCM	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	RKE	●	●	●	●
CX-7 (North America / General Specs.)	2.3L	L3_T	2010 MY	TCM	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ABS	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSML	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSMR	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	EATC	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	GEM	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	IC	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	MID#1	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	PCM	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RCM	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RKE	●	●	●	●
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	TCM	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY		ABS	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY		GEM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY		IC	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY		LTM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY		PCM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY		RCM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY		RKE	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE	●	●	●	●
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSML	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSMR	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	4X4	●	●	●	
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE	●	●	●	●
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	4X4	●	●	●	
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	ABS	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	EPS	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	IC	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	PCM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	RCM	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	RKE	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	TCM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	ABS	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	EPS	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	IC	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	PCM	●	●	●	●
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	RCM	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	RKE	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	TCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ		4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ		ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ		IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ		RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ		RKE	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2002 MY	RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2004 MY	RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	EPS	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.3L	ZJ	2005 MY	RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY		4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY		ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY		IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY		RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY		RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2002 MY	RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2004 MY	RKE	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	4X4	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	ABS/TCS	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	EPS	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	IC	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	PCM	●	●	●	●
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	RCM	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2	1.5L	ZY	2005 MY	RKE	●	●	●	●
DEMIO / 121 DEMIO / 121	1.3L	B3	1996 MY	ABS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	ABS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	PCM	●	●	●	●
DEMIO / 121 DEMIO / 121	1.5L	B5	1996 MY	ABS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	ABS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	ABS/TCS	●	●	●	●
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	PCM	●	●	●	●
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1996 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1999 MY	ABS	●	●	●	●
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000 MY	PCM	●	●	●	●
DEMIO / FESTIVA MINI WAGON	1.5L	B5	1996 MY	ABS	●	●	●	●
DEMIO / FESTIVA MINI WAGON	1.5L	B5	1999 MY	ABS	●	●	●	●
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	ABS	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	BCM/GEM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	EPS	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RCM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RKE	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	TCM	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	ABS	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	BCM/GEM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	EPS	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RCM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RKE	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	TCM	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	ABS	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	BCM/GEM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	EPS	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RCM	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RKE	●	●	●	
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	TCM	●	●	●	
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS	●	●	●	●
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM	●	●	●	●
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM	●	●	●	●
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM	●	●	●	●
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	ABS	●	●	●	●
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	GEM	●	●	●	●
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	IC	●	●	●	○
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	PCM	●	●	●	
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	IC	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	IC	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	IC	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	IC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	4X4	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	ABS	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	IC	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	4X4	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	ABS	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	IC	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2002 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2002 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2002 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2002 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape / Tribute / Maverick	3.0L	4V	2002 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	ABS/TCS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2004 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	4X4	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	ABS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 MY	RCM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	4X4	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	ABS	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	GEM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	IC	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PAM	●	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape / Tribute / Maverick	3.0L	4V	2007 MY	RCM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ACM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	RCM	●	●	●	●
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ACM	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	BCM	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	RCM	●	●	●	
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	TCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	4X4	●	●	●	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ABS	●	●	●	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM	●	●	●	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FDIM	●	●	●	
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	RCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GPSM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PAM	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	RCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM	●	●	●	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	BCM	●	●	●	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FDIM	●	●	●	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	RCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	TCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACCM#2	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	BCM	●	●	●	
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GPSM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	IC	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PAM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	RCM	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	TCM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ACM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	IC	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2008 MY	RCM	●	●	●	

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape /Tribute / Mariner	3.0L	4V	2008 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	4X4	●	●	●	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ABS	●	●	●	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM	●	●	●	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FDIM	●	●	●	
Escape /Tribute / Mariner	3.0L	4V	2009 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	IC	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PAM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2009 MY	RCM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	SDARS	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	4X4	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ABS	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ACM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	APIM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FCIM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FDIM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GEM / SJB	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GPSM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	HVAC	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	IC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escape /Tribute / Mariner	3.0L	4V	2010 MY	OCSM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PAM	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PCM	●	●	●	●
Escape /Tribute / Mariner	3.0L	4V	2010 MY	RCM	●	●	●	○
FAMILIA / LASER	1.3L	B3	1998 MY	ABS	●	●	●	●
FAMILIA / LASER	1.5L	ZL	1998 MY	ABS	●	●	●	●
FAMILIA / LASER	1.5L	ZL	2000 MY	ABS	●	●	●	●
FAMILIA / LASER	1.5L	ZL	2000 MY	ABS/TCS	●	●	●	●
FAMILIA / LASER	1.5L	ZL	2000 MY	PCM	●	●	●	●
FAMILIA / LASER	1.5L	ZL	2002 MY	ABS/TCS	●	●	●	●
FAMILIA / LASER	1.5L	ZL	2002 MY	PCM	●	●	●	●
FAMILIA / LASER	1.8L	FP	1998 MY	ABS	●	●	●	●
FAMILIA / LASER	2.0L	FS	1999 MY	ABS	●	●	●	●
FAMILIA / LASER	2.0L	FS	2000 MY	ABS	●	●	●	●
FAMILIA / LASER	2.0L	FS	2002 MY	ABS/TCS	●	●	●	●
FAMILIA / LASER	2.0L	FS	2002 MY	PCM	●	●	●	●
FAMILIA / LASER	2.0L	RF	1998 MY	ABS	●	●	●	●
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	ABS	●	●	●	●
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	EPS	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	GEM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IC	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IPDM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	PCM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	ABS	●	●	●	●
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	EPS	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	GEM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IC	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IPDM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	PCM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	ABS	●	●	●	●
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	EPS	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	GEM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IC	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IPDM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	PCM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	ABS	●	●	●	●
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	EPS	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	GEM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IC	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IPDM	●	●	●	●
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	PCM	●	●	●	●
FAMILIA WAGON/VAN (B*Y11_500000)	1.3L	QG13	1999 MY	PCM	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.3L	QG13	2002 MY	ABS	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.3L	QG13	2002 MY	PCM	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.5L	QG15	1999 MY	PCM	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.5L	QG15	2002 MY	ABS	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.5L	QG15	2002 MY	PCM	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.8L	QG18	1999 MY	PCM	●	●	●	
FAMILIA WAGON/VAN (B*Y11_500000)	1.8L	QG18	2002 MY	PCM	●	●	●	
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	HEC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996.75 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1997.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1997.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1997.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1997.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996.75 MY	ABS/TCS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996.75 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996.75 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996.75 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1997.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1997.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1997.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1997.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	19985 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	19985 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	19985 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	19985 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	ABS/TCS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.75 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.75 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.75 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.75 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997.5 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	19985 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	19985 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	19985 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	19985 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1999.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	GEM	●	●	●	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	PATS	●	●	●	
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	FIP	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PATS	●	●	●	
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	PATS	●	●	●	
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	PATS	●	●	●	

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1994.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1994.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1994.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1996 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1996 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1996 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1996 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1997.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1997.5 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1997.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1997.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	19985 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	19985 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	19985 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	19985 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	CSM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	PCM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	ABS/TCS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	CSM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	ECS	●	●	●	○
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	GEM	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	HEC	●	●	●	●
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	PATS	●	●	●	
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	2000 MY	PCM	●	●	●	●
FRIENDEE / FREDA / BONGO FRIENDEE	2.0L	FE	2002 MY	PCM	●	●	●	
FRIENDEE / FREDA / BONGO FRIENDEE	2.0L	FE	2002 MY	TCM	●	●	●	●
LAPUTA	660cc	F6A-T		ABS	●	●	●	○
LAPUTA	660cc	F6A-T		RCM	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	ABS	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	RCM	●	●	●	○
LAPUTA	660cc	F6A-T	1999 MY	ABS	●	●	●	○
LAPUTA	660cc	F6A-T	1999 MY	RCM	●	●	●	○
LAPUTA	660cc	F6A-T	2001 MY	ABS	●	●	●	○
LAPUTA	660cc	F6A-T	2001 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A		ABS	●	●	●	○
LAPUTA	660cc	K6A		RCM	●	●	●	○
LAPUTA	660cc	K6A	2000 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A	2000 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A	2001 MY	ABS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
LAPUTA	660cc	K6A	2001 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A	2001.5 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A	2001.5 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A	2002 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A	2002 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A T		ABS	●	●	●	○
LAPUTA	660cc	K6A T		RCM	●	●	●	○
LAPUTA	660cc	K6A T	1999 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A T	1999 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A T	2001 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A T	2001 MY	RCM	●	●	●	○
LAPUTA	660cc	K6A T	2001.5 MY	ABS	●	●	●	○
LAPUTA	660cc	K6A T	2001.5 MY	RCM	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3		ABS	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	1996 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	1998 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	2000 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	2000 MY	PCM	●	●	●	●
LASER / 323 / TIERRA	1.3L	B3	2001 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.5L	Z5		ABS	●	●	●	○
LASER / 323 / TIERRA	1.5L	Z5	1996 MY	ABS	●	●	●	○
LASER / 323 / TIERRA	1.5L	ZL		ABS	●	●	●	●
LASER / 323 / TIERRA	1.5L	ZL	1998 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.6L	B6		ABS	●	●	●	○
LASER / 323 / TIERRA	1.6L	B6	1996 MY	ABS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
LASER / 323 / TIERRA	1.6L	ZM		ABS	●	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	1998 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	ABS/TCS	●	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	PCM	●	●	●	●
LASER / 323 / TIERRA	1.8L	BP		ABS	●	●	●	○
LASER / 323 / TIERRA	1.8L	BP	1996 MY	ABS	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP		ABS	●	●	●	●
LASER / 323 / TIERRA	1.8L	FP	1998 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	1.8L	FP	2000 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000 MY	PCM	●	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2001 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	2.0L	RF		ABS	●	●	●	●
LASER / 323 / TIERRA	2.0L	RF	1998 MY	ABS	●	●	●	●
LASER / 323 / TIERRA	2.0L	RF-T	2000 MY	ABS	●	●	●	●
MAZDA2 (China)	1.3L	ZJ	2007 MY	ABS	●	●	●	●
MAZDA2 (China)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●
MAZDA2 (China)	1.3L	ZJ	2007 MY	EPS	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	IC	●	●	●	●
MAZDA2 (China)	1.3L	ZJ	2007 MY	PCM	●	●	●	●
MAZDA2 (China)	1.3L	ZJ	2007 MY	RCM	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	RKE	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	ABS	●	●	●	●
MAZDA2 (China)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA2 (China)	1.5L	ZY	2007 MY	EPS	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	IC	●	●	●	●
MAZDA2 (China)	1.5L	ZY	2007 MY	PCM	●	●	●	●
MAZDA2 (China)	1.5L	ZY	2007 MY	RCM	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	RKE	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2002 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2002 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2002 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2002 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2002 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2006 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2006 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2006 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2006 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ_CD_DI	2006 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	TCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	RCM	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	ABS/TCS	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	IC	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	PCM	●	●	●	●
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	RCM	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	ABS	●	●	●	●
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	EPS	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	IC	●	●	●	●
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	PCM	●	●	●	●
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RCM	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RKE	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	VSM	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM	●	●	●	●
MAZDA2 (Europe)	1.4L	Y4	2007 MY	EPS	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	IC	●	●	●	●
MAZDA2 (Europe)	1.4L	Y4	2007 MY	PCM	●	●	●	
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RCM	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RKE	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	VSM	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	ABS	●	●	●	●
MAZDA2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●
MAZDA2 (Europe)	1.5L	ZY	2007 MY	EPS	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	IC	●	●	●	●
MAZDA2 (Europe)	1.5L	ZY	2007 MY	PCM	●	●	●	●
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RCM	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RKE	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	VSM	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	ABS	●	●	●	●
MAZDA2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM	●	●	●	●
MAZDA2 (Europe)	1.6L	Y6	2008 MY	EPS	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	IC	●	●	●	●
MAZDA2 (Europe)	1.6L	Y6	2008 MY	PCM	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RCM	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RKE	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	VSM	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	ABS	●	●	●	●
MAZDA3 (China / General)	1.6L	Z6	2007 MY	GEM	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	IC	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (China / General)	1.6L	Z6	2007 MY	PCM	●	●	●	●
MAZDA3 (China / General)	1.6L	Z6	2007 MY	RCM	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	RKE	●	●	●	●
MAZDA3 (China / General)	2.0L	LF	2007 MY	ABS	●	●	●	●
MAZDA3 (China / General)	2.0L	LF	2007 MY	EPS	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	GEM	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	IC	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	PCM	●	●	●	●
MAZDA3 (China / General)	2.0L	LF	2007 MY	RCM	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2003 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2003 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2003 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2003 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2003 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.3L	ZJ	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	FACM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	IC	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2003 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	FACM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Y6	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2003 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1.6L	Z6	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2003 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	FFH	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.0L	RF-T	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2003 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	EPS	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3	2006 MY	RKE	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	ABS	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	IC	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	RCM	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	IC	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	RKE	●	●	●	●
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2004 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2004 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2005 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	IC	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (North America / General)	2.0L	LF	2005 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2005 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2006 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2006 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	RKE	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2006 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2007 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2007 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2008 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2008 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2008 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2009 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (North America / General)	2.0L	LF	2009 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.0L	LF	2009 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2004 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2004 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2005 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2005 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2006 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2006 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (North America / General)	2.3L	L3	2006 MY	RKE	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2006 MY	TCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2006 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2007 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2007 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	TCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2007 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2008 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2008 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2008 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	TCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2008 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2009 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2009 MY	EPS	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3	2009 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	TCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA3 (North America / General)	2.3L	L3	2009 MY	TPM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2007 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2008 MY	TPM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	ABS	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	GEM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	IC	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	PCM	●	●	●	●
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	RCM	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3_T	2009 MY	TPM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	EATC	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	EPS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	GEM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	LPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	PCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	RKE	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2005 MY	RPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	EATC	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	EPS	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	LPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	PCM	●	●	○	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	RKE	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	1.8L	L8	2007 MY	RPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	EATC	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	EPS	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	GEM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	PCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2005 MY	RKE	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	EATC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	EPS	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	GEM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	PCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	RKE	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	LF	2007 MY	TCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	EATC	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	FFH	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	GEM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	PCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2005 MY	RKE	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	ABS	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	EATC	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	FFH	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	GEM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	IC	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	LPSDM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	PCM	●	●	●	●
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	RCM	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	RKE	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (EURO STG3/4/5 and General_Specs.) / i-MAX	2.0L	RF-T	2007 MY	RPSDM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	ABS	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EATC	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EPS	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	GEM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	IC	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	PCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	RCM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	TPM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	ABS	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EATC	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EPS	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	GEM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	IC	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	PCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	RCM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	TPM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	ABS	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EATC	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EPS	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	GEM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	IC	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	PCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	RCM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TPM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	ABS	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EATC	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EPS	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	GEM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	IC	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	PCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	RCM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TPM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	ABS	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EATC	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EPS	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	GEM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	IC	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	PCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	RCM	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TCM	●	●	●	●
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TPM	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	ABS	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	EATC	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	EPS	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	IC	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	PCM	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (China)	2.0L	LF	2007 MY	RKE	●	●	●	●
MAZDA6 (China)	2.0L	LF	2007 MY	TCM	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	ABS	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	EATC	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	EPS	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	IC	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	PCM	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	RCM	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	RKE	●	●	●	●
MAZDA6 (China)	2.5L	L5	2007 MY	TCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	GEM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RKE	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	FFH	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	PCM	●	●	●	
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	FFH	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	FFH	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	FFH	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	GEM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RKE	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	IC	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	TCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	ABS/TCS	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	GEM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	IC	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	LHID	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	PCM	●	●	●	●
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RCM	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RHID	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3_T	2005 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	ABS	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	EPS	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	PCM	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RCM	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	ABS	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	EPS	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	PCM	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RCM	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	TCM	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	ABS	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	EPS	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	FFH	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	PCM	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RCM	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	EPS	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	FFH	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	PCM	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	RCM	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2007 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	ABS	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	EPS	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	FFH	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	PCM	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	RCM	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	2.2L	R2_T	2008 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	ABS	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	EATC	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	EPS	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	IC	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	PCM	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RKE	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RVM	●	●	●	●
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	TCM	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	ABS	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BCM/GEM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BSML	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BSMR	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	EATC	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	IC	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	LCM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	PCM	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	RCM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	RKE	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	TCM	●	●	●	
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	ABS	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BCM/GEM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BSML	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BSMR	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	EATC	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	IC	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	LCM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	PCM	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	RCM	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	RKE	●	●	●	●
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	TCM	●	●	●	
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BCM/GEM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BSML	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BSMR	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	EATC	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	IC	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	LCM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	PCM	●	●	●	
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	RCM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	RKE	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	TCM	●	●	●	
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	ABS	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BCM/GEM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BSML	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BSMR	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	EATC	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	IC	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	LCM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	PCM	●	●	●	
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	RCM	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	RKE	●	●	●	●
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	TCM	●	●	●	
MAZDA6 (North America / General)	2.5L	L5	2009 MY	ABS	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BCM/GEM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BSML	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BSMR	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	EATC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (North America / General)	2.5L	L5	2009 MY	IC	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	LCM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	PCM	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	RCM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	RKE	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2009 MY	TCM	●	●	●	
MAZDA6 (North America / General)	2.5L	L5	2010 MY	ABS	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BCM/GEM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BSML	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BSMR	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	EATC	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	IC	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	LCM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	PCM	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	RCM	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	RKE	●	●	●	●
MAZDA6 (North America / General)	2.5L	L5	2010 MY	TCM	●	●	●	
MAZDA6 (North America / General)	3.7L	CA	2009 MY	ABS	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BCM/GEM	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BSML	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BSMR	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	EATC	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	IC	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	LCM	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	PCM	●	●	●	
MAZDA6 (North America / General)	3.7L	CA	2009 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6 (North America / General)	3.7L	CA	2009 MY	RKE	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2009 MY	TCM	●	●	●	
MAZDA6 (North America / General)	3.7L	CA	2010 MY	ABS	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BCM/GEM	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BSML	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BSMR	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	EATC	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	IC	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	LCM	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	PCM	●	●	●	
MAZDA6 (North America / General)	3.7L	CA	2010 MY	RCM	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	RKE	●	●	●	●
MAZDA6 (North America / General)	3.7L	CA	2010 MY	TCM	●	●	●	
MAZDA6(North America/General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2003 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2003 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	TCM	●	●	●	
MAZDA6(North America/General)	2.3L	L3	2004 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2004 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2004 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2004 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2004 MY	TCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2005 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6(North America/General)	2.3L	L3	2005 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	TCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2006 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2006 MY	GEM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2006 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	TCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2007 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2007 MY	GEM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2007 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2007 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2007 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2007 MY	TCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2008 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2008 MY	GEM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2008 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2008 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2008 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2008 MY	TCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3	2008 MY	TPM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6(North America/General)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	GEM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	IC	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	PCM	●	●	●	●
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	RCM	●	●	●	○
MAZDA6(North America/General)	2.3L	L3_T	2007 MY	RKE	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ		ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ		IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ		RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2003 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2003 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2003 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2003 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2003 MY	TCM	●	●	●	
MAZDA6(North America/General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2004 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2004 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2004 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2004 MY	TCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2005 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2005 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2005 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2005 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2005 MY	TCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2006 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MAZDA6(North America/General)	3.0L	AJ	2006 MY	GEM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2006 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2006 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2006 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2006 MY	TCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2007 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2007 MY	GEM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2007 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2007 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2007 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2007 MY	TCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2008 MY	ABS/TCS	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2008 MY	GEM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2008 MY	IC	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2008 MY	PCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2008 MY	RCM	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2008 MY	TCM	●	●	●	●
MAZDA6(North America/General)	3.0L	AJ	2008 MY	TPM	●	●	●	○
Millenia	2.3L	KJ	1997 MY	PCM	●	●	●	●
Millenia	2.3L	KJ	1998 MY	PCM	●	●	●	●
Millenia	2.3L	KJ	1999 MY	PCM	●	●	●	●
Millenia	2.3L	KJ	2000 MY	ABS/TCS	●	●	●	●
Millenia	2.3L	KJ	2000 MY	PCM	●	●	●	●
Millenia	2.3L	KJ	2001 MY	ABS/TCS	●	●	●	●
Millenia	2.3L	KJ	2001 MY	PCM	●	●	●	●
Millenia	2.5L	KL	1997 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Millenia	2.5L	KL	1998 MY	PCM	●	●	●	●
Millenia	2.5L	KL	1999 MY	PCM	●	●	●	●
Millenia	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●
Millenia	2.5L	KL	2000 MY	PCM	●	●	●	●
Millenia	2.5L	KL	2001 MY	ABS/TCS	●	●	●	●
Millenia	2.5L	KL	2001 MY	PCM	●	●	●	●
MILLENNIA / EUNOS 800	2.0L	KF	1998 MY	ABS	●	●	●	●
MILLENNIA / EUNOS 800	2.0L	KF	2000 MY	ABS	●	●	●	
MILLENNIA / EUNOS 800	2.3L	KJ	1998 MY	ABS	●	●	●	●
MILLENNIA / EUNOS 800	2.3L	KJ	2000 MY	ABS	●	●	●	
MILLENNIA / EUNOS 800	2.5L	KL	1998 MY	ABS	●	●	●	●
MILLENNIA / EUNOS 800	2.5L	KL	2000 MY	ABS	●	●	●	
MILLENNIA / EUNOS 800	2.5L	KL	2002 MY	ABS/TCS	●	●	●	●
MILLENNIA / EUNOS 800	2.5L	KL	2002 MY	PCM	●	●	●	●
MPV (Europe/General)	2.0L	FS	1999 MY	ABS	●	●	●	●
MPV (Europe/General)	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.0L	FS	2000 MY	PCM	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2002 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2002 MY	FFH	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2002 MY	PCM	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2003 MY	FFH	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2003 MY	PCM	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2004 MY	FFH	●	●	●	●
MPV (Europe/General)	2.0L	RF-T	2004 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MPV (Europe/General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.3L	L3	2002 MY	PCM	●	●	●	●
MPV (Europe/General)	2.5L	GY	1999 MY	ABS	●	●	●	●
MPV (Europe/General)	2.5L	GY	1999 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.5L	GY	1999 MY	PCM	●	●	●	●
MPV (Europe/General)	2.5L	GY	2000 MY	ABS	●	●	●	●
MPV (Europe/General)	2.5L	GY	2000 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	2.5L	GY	2000 MY	PCM	●	●	●	●
MPV (Europe/General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●
MPV (Europe/General)	3.0L	AJ	2002 MY	PCM	●	●	●	●
MPV (Europe/General)	3.0L	AJ	2002 MY	TCM	●	●	●	●
MPV (JPN/General)	2.0L	FS	1999 MY	ABS	●	●	●	●
MPV (JPN/General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●
MPV (JPN/General)	2.3L	L3	2002 MY	PCM	●	●	●	●
MPV (JPN/General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●
MPV (JPN/General)	2.3L	L3	2003 MY	PCM	●	●	●	●
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS	●	●	●	●
MPV (JPN/General)	2.3L	L3	2004 MY	PCM	●	●	●	●
MPV (JPN/General)	2.5L	GY	1999 MY	ABS	●	●	●	●
MPV (JPN/General)	2.5L	GY	1999 MY	PCM	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2002 MY	PCM	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2002 MY	TCM	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2004 MY	PCM	●	●	●	●
MPV (JPN/General)	3.0L	AJ	2004 MY	TCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MPV (North America / General)	2.5L	GY	2000 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	2.5L	GY	2000 MY	PCM	●	●	●	●
MPV (North America / General)	2.5L	GY	2001 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	2.5L	GY	2001 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	3.0L	AJ	2002 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2002 MY	TCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2003 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	3.0L	AJ	2003 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2003 MY	TCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	3.0L	AJ	2004 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2004 MY	RCM	●	●	●	○
MPV (North America / General)	3.0L	AJ	2004 MY	TCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	3.0L	AJ	2005 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2005 MY	RCM	●	●	●	○
MPV (North America / General)	3.0L	AJ	2005 MY	TCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2006 MY	ABS/TCS	●	●	●	●
MPV (North America / General)	3.0L	AJ	2006 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	AJ	2006 MY	RCM	●	●	●	○
MPV (North America / General)	3.0L	AJ	2006 MY	TCM	●	●	●	●
MPV (North America / General)	3.0L	JE	1997 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	JE	1998 MY	PCM	●	●	●	●
MPV (North America / General)	3.0L	JE	1999 MY	PCM	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC	●	●	●	
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ABS	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	GEM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	HCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	IC	●	●	●	
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	ICCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	LTM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	PCM	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RCM	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	RKE	●	●	●	●
MPV / Mazda8 (JPN/General)	2.3L	L3_T	2006 MY	TCM	●	●	●	
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	ABS	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	IC	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	PCM	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RCM	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RHT	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RKE	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	IC	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	PCM	●	●	●	●
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RCM	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RHT	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RKE	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	ABS	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	IC	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	PCM	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RCM	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RHT	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RKE	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	TCM	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF		ABS	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF		IC	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF		PCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF		RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF		RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	TCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	ABS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	IC	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	PCM	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RCM	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RHT	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RKE	●	●	●	●
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	TCM	●	●	●	●
MX-5 MIATA	1.8L	BP	1997 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	1999 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	2000 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	2001 MY	ABS/TCS	●	●	●	●
MX-5 MIATA	1.8L	BP	2001 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	2003 MY	ABS/TCS	●	●	●	
MX-5 MIATA	1.8L	BP	2003 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS	●	●	●	
MX-5 MIATA	1.8L	BP	2004 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP	2005 MY	ABS/TCS	●	●	●	
MX-5 MIATA	1.8L	BP	2005 MY	PCM	●	●	●	●
MX-5 MIATA	1.8L	BP Turbo	2004 MY	ABS/TCS	●	●	●	●
MX-5 MIATA	1.8L	BP Turbo	2004 MY	PCM	●	●	●	●
MX 5	1.6L	B6	2000 MY	ABS/TCS	●	●	●	●
MX 5	1.6L	B6	2000 MY	PCM	●	●	●	●
MX 5	1.8L	BP	2000 MY	ABS/TCS	●	●	●	●
MX 5	1.8L	BP	2000 MY	PCM	●	●	●	●
PREMACY	1.8L	FP	1999 MY	ABS	●	●	●	●
PREMACY	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●
PREMACY	1.8L	FP	2000 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
PREMACY	2.0L	FS	2001 MY	ABS	●	●	●	●
PREMACY	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●
PREMACY	2.0L	FS	2001 MY	PCM	●	●	●	●
PREMACY	2.0L	RF-T	1999 MY	ABS	●	●	●	●
PREMACY	2.0L	RF-T	2000 MY	ABS	●	●	●	●
PREMACY	2.0L	RF-T	2000 MY	ABS/TCS	●	●	●	●
PREMACY	2.0L	RF-T	2000 MY	PCM	●	●	●	●
PREMACY	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●
PREMACY	2.0L	RF-T	2003 MY	PCM	●	●	●	●
PREMACY / IXION	1.8L	FP	1999 MY	ABS	●	●	●	●
PREMACY / IXION	1.8L	FP	2002 MY	ABS/TCS	●	●	●	●
PREMACY / IXION	1.8L	FP	2002 MY	PCM	●	●	●	●
PREMACY / IXION	1.8L	FP_DE	1999 MY	ABS	●	●	●	●
PREMACY / IXION	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●
PREMACY / IXION	2.0L	FS	2001 MY	PCM	●	●	●	●
PREMACY / IXION	2.0L	RF-T	1999 MY	ABS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	EATC	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	EPS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	GEM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	LPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	RPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM	●	●	●	
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	ABS	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	EATC	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	EPS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	GEM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	IC	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	LPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	PCM	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	RCM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	RKE	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	RPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.0L	LF	2007 MY	TCM	●	●	●	
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	ABS	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	EATC	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	EPS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	GEM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	IC	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	RCM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2005 MY	RKE	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	ABS	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	EATC	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	EPS	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	GEM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	IC	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	LPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	PCM	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	RCM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	RKE	●	●	●	●
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	RPSDM	●	●	●	○
PREMACY / MAZDA5 (Japan / General Specs.)	2.3L	L3	2007 MY	TCM	●	●	●	
PROBE / MX-6	2.0L	Other	1996 MY	PCM	●	●	●	●
PROBE / MX-6	2.0L	Other	1997 MY	PCM	●	●	●	●
PROBE / MX-6	2.5L	KL	1996 MY	PCM	●	●	●	●
PROBE / MX-6	2.5L	KL	1997 MY	PCM	●	●	●	●
PROTEGE	1.5L	Z5	1997 MY	PCM	●	●	●	●
PROTEGE	1.5L	Z5	1998 MY	PCM	●	●	●	●
PROTEGE	1.6L	ZM	1999 MY	PCM	●	●	●	●
PROTEGE	1.6L	ZM	2000 MY	ABS/TCS	●	●	●	●
PROTEGE	1.6L	ZM	2000 MY	PCM	●	●	●	●
PROTEGE	1.6L	ZM	2001 MY	ABS/TCS	●	●	●	●
PROTEGE	1.6L	ZM	2001 MY	PCM	●	●	●	●
PROTEGE	1.8L	BP	1997 MY	PCM	●	●	●	●
PROTEGE	1.8L	BP	1998 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
PROTEGE	1.8L	FP	1999 MY	PCM	●	●	●	●
PROTEGE	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●
PROTEGE	1.8L	FP	2000 MY	PCM	●	●	●	●
PROTEGE	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●
PROTEGE	2.0L	FS	2001 MY	PCM	●	●	●	●
PROTEGE	2.0L	FS	2002 MY	ABS/TCS	●	●	●	●
PROTEGE	2.0L	FS	2002 MY	PCM	●	●	●	●
PROTEGE	2.0L	FS	2003 MY	ABS/TCS	●	●	●	●
PROTEGE	2.0L	FS	2003 MY	PCM	●	●	●	●
PROTEGE	2.0L	FS_T	2003 MY	ABS/TCS	●	●	●	●
PROTEGE	2.0L	FS_T	2003 MY	PCM	●	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	ABS/TCS	●	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	ESOF	●	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4.0L	V6 SOHC	2003 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier			2004 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier			2004 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier			2004 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier			2004 MY	IC	●	●	●	○
Ranger / Mazda B Series / Courier			2004 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier			2004 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	RCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	TPM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	OCSM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM	●	●	●	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	ABS/TCS	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	IAB	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	PATS	●	●	○	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	RCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PATS	●	●	○	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	PATS	●	●	○	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	PATS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	PATS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	ABS/TCS	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	PATS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	4X4	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	PATS	●	●	○	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	IC	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	ABS/TCS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	TPM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	RCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	ABS/TCS	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	IAB	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	PATS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	RCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	PATS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	PATS	●	●	○	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	RAP	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	4X4	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	IC	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	TPM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	GEM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	ABS/TCS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	RCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	SDARS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	4X4	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	ABS	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	GEM / SJB	●	●	●	
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	IC	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	OCSM	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	PCM	●	●	●	●
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	RCM	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	SDARS	●	●	●	●
ROADSTER / MX-5	1.6L	B6	2000 MY	ABS	●	●	●	●
ROADSTER / MX-5	1.6L	B6	2002 MY	ABS/TCS	●	●	●	

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
ROADSTER / MX-5	1.6L	B6	2002 MY	PCM	●	●	●	●
ROADSTER / MX-5	1.8L	BP	2000 MY	ABS	●	●	●	●
ROADSTER / MX-5	1.8L	BP	2002 MY	ABS/TCS	●	●	●	
ROADSTER / MX-5	1.8L	BP	2002 MY	PCM	●	●	●	●
ROADSTER / MX-5	1.8L	BP Turbo	2003 MY	ABS/TCS	●	●	●	●
ROADSTER / MX-5	1.8L	BP Turbo	2003 MY	PCM	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RHT	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	TCM	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS/TCS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	EPS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	IC	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	PCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	TCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	EPS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	IC	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	PCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RCM	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	TCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	ABS/TCS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	EPS	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	IC	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	PCM	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	RCM	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	RKE	●	●	●	●
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	ABS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	LCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2009 MY	TPM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
RX-8 (North America Specs)	654x2cc	13B	2010 MY	ABS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	LCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B	2010 MY	TPM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	EPS	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	PCM	●	●	●	●

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	TPM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	ABS/TCS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	EPS	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	IC	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	PCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	RCM	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	RKE	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	TCM	●	●	●	●
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	TPM	●	●	●	○
SCRUM	660cc	F6A		ABS	●	●	●	○
SCRUM	660cc	F6A		RCM	●	●	●	○
SCRUM	660cc	F6A	1999 MY	ABS	●	●	●	○
SCRUM	660cc	F6A	1999 MY	RCM	●	●	●	○
SCRUM	660cc	F6A-T		ABS	●	●	●	○
SCRUM	660cc	F6A-T		RCM	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	ABS	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	RCM	●	●	●	○
SCRUM	660cc	K6A		ABS	●	●	●	○
SCRUM	660cc	K6A		RCM	●	●	●	○
SCRUM	660cc	K6A	2001 MY	ABS	●	●	●	○
SCRUM	660cc	K6A	2001 MY	RCM	●	●	●	○
SCRUM	660cc	K6A	2005 MY	ABS	●	●	●	○
SCRUM	660cc	K6A	2005 MY	RCM	●	●	●	○

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
SCRUM	660cc	K6A_T		ABS	●	●	●	○
SCRUM	660cc	K6A_T		RCM	●	●	●	○
SCRUM	660cc	K6A_T	2001 MY	ABS	●	●	●	○
SCRUM	660cc	K6A_T	2001 MY	RCM	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	ABS	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	RCM	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005 MY	ABS	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005 MY	RCM	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	2003 MY	ABS	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	2003 MY	RCM	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A_T	2003 MY	ABS	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A_T	2003 MY	RCM	●	●	●	○
TITAN_DASH	2.0L	FE	2002 MY	PCM	●	●	●	
TITAN_DASH	2.0L	FE	2002 MY	TCM	●	●	●	●
TITAN_DASH	2.0L	FE LPG	2002 MY	PCM	●	●	●	○
TITAN_DASH	2.0L	FE LPG	2002 MY	TCM	●	●	●	●
TITAN_DASH	2.0L	RF-T	2004 MY	PCM	●	●	●	●
TITAN_DASH	2.0L	RF-T	2004 MY	TCM	●	●	●	●
TITAN_DASH	2.0L	RF-T	2004.5 MY	PCM	●	●	●	●
TITAN_DASH	2.0L	RF-T	2004.5 MY	TCM	●	●	●	●
XEDOS9	2.0L	KF	1996 MY	ABS	●	●	●	●
XEDOS9	2.3L	KJ	1996 MY	ABS	●	●	●	●
XEDOS9	2.3L	KJ	1998 MY	ABS	●	●	●	●
XEDOS9	2.5L	KL	1996 MY	ABS	●	●	●	●
XEDOS9	2.5L	KL	1998 MY	ABS	●	●	●	●
XEDOS9	2.5L	KL	2000 MY	ABS	●	●	●	

MaxiDAS_Mazda_V1.10 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
XEDOS9	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●
XEDOS9	2.5L	KL	2000 MY	PCM	●	●	●	●