

MaxiDAS_Mitsubishi_V2.01 Fuction List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

YEAR	System Name	Ecu Information	Read Code	Erase Codes	Live Data	Freeze Frame	Active Test
2005	MFI	●	●	●	●	●	●
2005	IMMOBILIZER	●	●	●	●		
2005	ELC-A/T	●	●	●	●	●	●
2005	SS411	●	●	●	●		●
2005	TCL	●	●	●	●		●
2005	CRUISE CONTROL	●	●	●	●		
2005	ECS	●	●	●	●		●
2005	ABS/ASC/ASTC	●	●	●	●		●
2005	HBB	●	●	●	●		●
2005	ACD	●	●	●	●		●
2005	SRS-AIR BAG	●	●	●	●		●
2005	AIR Conditioner	●	●	●	●		●
2005	SWS	●	●	●	●		●
2005	ETACS	●	●	●			●
2005	TPMS	●	●	●	●		●
2005	Meter	●	●	●	●		●
2005	Display	●	●	●			●
2005	Steering Angle Sensor	●	●	●			
2006	ABS/ASC/ASTC/WSS	●	●	●	●		●
2006	ACD	●	●	●	●		●
2006	AFS/ACL	●	●	●	●		●
2006	CAN/LIN/SWS converter	●	●	●	●		●
2006	AND	●	●	●			
2006	AUDIO	●	●	●	●		
2006	Air Conditioner	●	●	●	●		●
2006	CRUISE CONTROL	●	●	●	●		
2006	Camera	●	●	●	●		
2006	Display	●	●	●	●		●
2006	ECPS/4WS	●	●	●	●		●
2006	ECS	●	●	●	●		●
2006	ELC-AT/CVT/TC-SST	●	●	●	●	●	●

MaxiDAS_Mitsubishi_V2.01 Fuction List

NOTES:

- This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

YEAR	System Name	Ecu Information	Read Code	Erase Codes	Live Data	Freeze Frame	Active Test
2006	ELECTRIC SLIDE DOOR L	●	●	●	●		●
2006	ELECTRIC SLIDE DOOR R	●	●	●	●		●
2006	ETACS	●	●	●	●		●
2006	F.A.S.T./IMMO/Keyless/TPMS	●	●	●	●		●
2006	HBB	●	●	●	●		●
2006	HFM	●	●	●	●		●
2006	IMMOBILIZER	●	●	●	●		
2006	Keyless Operation	●	●	●	●		●
2006	LIN		●	●	●		
2006	MFI	●	●	●	●	●	●
2006	Meter	●	●	●	●		●
2006	Multi Select 4WD	●	●	●	●		
2006	OCM	●	●	●	●		
2006	Power Gate	●	●	●	●		●
2006	SATELLITE RADIO	●	●	●			
2006	SRS AIR BAG	●	●	●	●		●
2006	SS4II	●	●	●	●		●
2006	SWS	●	●	●	●		●
2006	Shift Lever	●	●	●	●		●
2006	Steering Angle Sensor	●					
2006	TCL	●	●	●	●		●
2006	TPMS	●	●	●	●		●
2006	Topstack	●	●	●	●		●