

MaxiSys_BMW_V8.20 Function List (Note:For reference only)

NOTES:

● This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	E81/E82/E87/E88	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Body	AHM Trailer module	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	AMP Amplifier	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CA Comfort access system	●	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Body	CAN communication analysis	●	●	●	○	○	○	○
1 Series	E81/E82/E87/E88	Body	CCC-A Applications	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-BO User interface	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CCC-GW Gateway	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CDC CD Changer	●	●	●	●	○	●	●
1 Series	E81/E82/E87/E88	Body	CIC Car Information Computer	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CIC-GW Gateway	●	●	●	●	○	●	●
1 Series	E81/E82/E87/E88	Body	CID Central information display	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CON Controller	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FRM footwell module	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FRM2 footwell module 2	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	FZD Function centre, roof	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHKR Heater and A/C control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	IHR Integrated heater control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JBE Junction-box electronics	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	JNAV Navigation system, Japan	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-BO User interface	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	M-ASK-NAV Navigation system	●	●	●	●	●	●	○
1 Series	E81/E82/E87/E88	Body	MOST system analysis	●	●	●	●	○	○	○
1 Series	E81/E82/E87/E88	Body	PDC Park distance control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD Radio	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD2-BO User interface	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RAD2-GW Gateway	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
1 Series	E81/E82/E87/E88	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	E81/E82/E87/E88	Body	SMBF Seat memory, front passenger							
1 Series	E81/E82/E87/E88	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	TCU Telematic control unit	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	AL active front steering(AFS70)	●	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Chassis	AL active steering	●	●	●	●	●	○	●
1 Series	E81/E82/E87/E88	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	CAS Car Access System	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
1 Series	E81/E82/E87/E88	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
3 Series	E30	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
3 Series	E30	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
3 Series	E30	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
3 Series	E30	Body	KOM(Instrument cluster)	●	●	○	●			
3 Series	E30	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
3 Series	E30	Drive	GSR(Cruise control)	●	●	○	●	●	○	
3 Series	E30	Body	AB(airbag)	●	●	○	●	●	○	
3 Series	E30	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
3 Series	E30	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
3 Series	E30	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
3 Series	E30	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
3 Series	E30	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
3 Series	E30	Chassis	ABS/ASC tester	●	●	○	●	●	○	
3 Series	E36[<9803]	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
3 Series	E36[<9803]	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
3 Series	E36[<9803]	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
3 Series	E36[<9803]	Body	KOM(Instrument cluster)	●	●	○	●			
3 Series	E36[<9803]	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
3 Series	E36[<9803]	Drive	GSR(Cruise control)	●	●	○	●	●	○	
3 Series	E36[<9803]	Body	AB(airbag)	●	●	○	●	●	○	
3 Series	E36[<9803]	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
3 Series	E36[<9803]	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
3 Series	E36[<9803]	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
3 Series	E36[<9803]	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
3 Series	E36[<9803]	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
3 Series	E36[<9803]	Chassis	ABS/ASC tester	●	●	○	●	●	○	

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E36[>9803]	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
3 Series	E36[>9803]	Body	BCO/MID On-board computer/MID			○				
3 Series	E36[>9803]	Body	CVM/CVM2 Convertible top module	●	●	○	●	●	●	●
3 Series	E36[>9803]	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
3 Series	E36[>9803]	Body	IR Radio/infrared locking system							
3 Series	E36[>9803]	Body	KOM Instrument cluster	●	●	○	●	●	●	○
3 Series	E36[>9803]	Body	PDC Park distance control	●	●	○	●	●	●	●
3 Series	E36[>9803]	Body	URS Rollover sensor	●	●	○	●	●	●	○
3 Series	E36[>9803]	Body	ZKE Central body electronics	●	●	○	●	●	●	○
3 Series	E36[>9803]	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
3 Series	E36[>9803]	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
3 Series	E36[>9803]	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
3 Series	E36[>9803]	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
3 Series	E36[>9803]	Drive	GR Cruise control	●	●	○	●	●	●	○
3 Series	E36[>9803]	Drive	TOENS Thermal oil-level sensor	●	●	○	●	●	●	○
3 Series	E46	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
3 Series	E46	Body	AHL Adaptive directional headlights	●	●	○	●	●	●	●
3 Series	E46	Body	AIC Automatic Interval control	●	●	○	●	●	○	○
3 Series	E46	Body	BIT Basis Interface Telephone	●	●	○	●	●	○	○
3 Series	E46	Body	BM On-board monitor	●	●	○	●	●	●	○
3 Series	E46	Body	CVM/CVM2 Convertible top module	●	●	○	●	●	●	●
3 Series	E46	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
3 Series	E46	Body	IHKR Heater and A/C control	●	●	○	●	●	●	●
3 Series	E46	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○
3 Series	E46	Body	KOM Instrument cluster	●	●	○	●	●	●	○
3 Series	E46	Body	LSZ Light switching centre	●	●	○	●	●	●	○
3 Series	E46	Body	MIR Multi-Information Radio	●	●	○	●	●	○	○
3 Series	E46	Body	NAJ Navigation computer, Japan	●	●	○	●	●	●	○
3 Series	E46	Body	NAR Navigation radio	●	●	○	●	○	●	○
3 Series	E46	Body	NAV Navigation computer	●	●	○	●	●	●	○
3 Series	E46	Body	NAV Navigation computer MKII	●	●	○	●	●	○	○
3 Series	E46	Body	PDC Park distance control	●	●	○	●	●	●	●
3 Series	E46	Body	RAD Radio	●	●	○	●	●	●	●
3 Series	E46	Body	RLS Rain/Light Sensor	●	●	○	●	●	○	●
3 Series	E46	Body	SES Language-input system	●	●	○	●	○	●	○
3 Series	E46	Body	SHD Sliding/tilting sunroof	●	●	○	●	●	●	●
3 Series	E46	Body	SMB Entrance aid, passenger	●	●	○	●	●		○
3 Series	E46	Body	SMF Entrance aid, driver	●	●	○	●	●	●	○
3 Series	E46	Body	SMF Seat memory, driver	●	●	○	●	●	●	○
3 Series	E46	Body	SPMBT Mirror memory, passenger	●	●	○	●	●	●	○
3 Series	E46	Body	SPMFT Mirror memory, driver	●	●	○	●	●	●	○
3 Series	E46	Body	SZM Switching centre, centre console	●	●	○	●	●	●	●
3 Series	E46	Body	TCU Telematic control unit	●	●	○	●	●	●	●
3 Series	E46	Body	TEL Telephone interface	○	○	○	○	●	●	○
3 Series	E46	Body	ULF Universal charging and hands-free facility	●	●	○	●	●	●	●
3 Series	E46	Body	URS Rollover sensor	●	●	○	●	●	○	○
3 Series	E46	Body	VID Video module	●	●	○	●	○	○	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E46	Body	VID Video module III	●	●	○	●	○	○	○
3 Series	E46	Body	ZKE Central body electronics	●	●	○	●	●	●	○
3 Series	E46	Body	ZUH Auxiliary heater	●	●	○	●	●	●	○
3 Series	E46	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
3 Series	E46	Chassis	DDS Deflation Detection System	●	●	○	●	●	○	○
3 Series	E46	Chassis	LWS Steering angle sensor	●	●	○	●	●	○	○
3 Series	E46	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
3 Series	E46	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
3 Series	E46	Drive	DME/DDE (Engine Electronics)	●	●	○	●	●	●	●
3 Series	E46	Drive	EGS/AGS (Transmission Control)	●	●	○	●	●	●	●
3 Series	E46	Drive	EKP Fuel pump	●	●	○	●	●	●	○
3 Series	E46	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
3 Series	E46	Drive	GR Cruise control	●	●	○	●	●	●	○
3 Series	E90/E91/E92/E93	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	AHM Trailer module	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	AMP Amplifier	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CA Comfort access system	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	CAN communication analysis	●	●	●	○	○	○	○
3 Series	E90/E91/E92/E93	Body	CCC-A Applications	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-B0 User interface	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CCC-GW Gateway	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CDC CD Changer	●	●	●	●	○	●	●
3 Series	E90/E91/E92/E93	Body	CIC Car Information Computer	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CIC-GW Gateway	●	●	●	●	○	●	●
3 Series	E90/E91/E92/E93	Body	CID Central information display	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CNAV Navigation system, China	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CON Controller	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	CTM Convertible-top module	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	DAB Digital tuner	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FLA High Beam Assist	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FRM footwell module	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FRM2 footwell module 2	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	FZD Function centre, roof	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IBOC Digital tuner US	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IHKR Heater and A/C control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	IHR Integrated heater control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JBE Junction-box electronics	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	JNAV Navigation system, Japan	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	KNAV Navigation system, Korea	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	M-ASK-B0 User interface	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E90/E91/E92/E93	Body	M-ASK-NAV Navigation system	●	●	●	●	●	●	○
3 Series	E90/E91/E92/E93	Body	MOST system analysis	●	●	●	●	○	○	○
3 Series	E90/E91/E92/E93	Body	PDC Park distance control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD Radio	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD2-BO User interface	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RAD2-GW Gateway	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
3 Series	E90/E91/E92/E93	Body	SDARS Satellite tuner	●	○	○	○	○	○	○
3 Series	E90/E91/E92/E93	Body	SHD Panorama glass sunroof							
3 Series	E90/E91/E92/E93	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
3 Series	E90/E91/E92/E93	Body	SMBF Seat module, passenger	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	TCU Telematic control unit	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Body	VM Video Module	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	ACC Active Cruise Control	●	●	●	●	○	○	●
3 Series	E90/E91/E92/E93	Chassis	AL active front steering(AFS70)	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	AL active steering	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	EDC Damper Control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Chassis	LDM Longitudinal Dynamics Management	●	●	●	●	●	○	●
3 Series	E90/E91/E92/E93	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	CAS Car Access System	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	DKG Twin-clutch gearbox	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
3 Series	E90/E91/E92/E93	Drive	VTG Transfer case	●	●	●	●	●	●	●
5 Series	E28	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
5 Series	E28	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
5 Series	E28	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
5 Series	E28	Body	KOM(Instrument cluster)	●	●	○	●			
5 Series	E28	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
5 Series	E28	Drive	GSR(Cruise control)	●	●	○	●	●	○	
5 Series	E28	Body	AB(airbag)	●	●	○	●	●	○	
5 Series	E28	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
5 Series	E28	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
5 Series	E28	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
5 Series	E28	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
5 Series	E28	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E28	Chassis	ABS/ASC tester	●	●	○	●	●	○	
5 Series	E34	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
5 Series	E34	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
5 Series	E34	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
5 Series	E34	Body	KOM(Instrument cluster)	●	●	○	●	●	○	
5 Series	E34	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
5 Series	E34	Drive	GSR(Cruise control)	●	●	○	●	●	○	
5 Series	E34	Body	AB(airbag)	●	●	○	●	●	○	
5 Series	E34	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
5 Series	E34	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
5 Series	E34	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
5 Series	E34	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
5 Series	E34	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
5 Series	E34	Chassis	ABS/ASC tester	●	●	○	●	●	○	
5 Series	E39	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
5 Series	E39	Body	AIC Automatic Interval control	●	●	○	●	●	○	○
5 Series	E39	Body	BIT Basis Interface Telephone	●	○	○	○	●	○	○
5 Series	E39	Body	BM On-board monitor	●	●	○	●	●	●	○
5 Series	E39	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
5 Series	E39	Body	GM base module	●	●	○	●	●	●	○
5 Series	E39	Body	GSR Cruise control	●	●	○	●	●	○	○
5 Series	E39	Body	HKM Boot-lid module	●	●	○	●	○	○	○
5 Series	E39	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
5 Series	E39	Body	IHKR Heater and A/C control	●	●	○	●	●	●	●
5 Series	E39	Body	IHR Integrated heater control	●	●	○	●	●	●	●
5 Series	E39	Body	IKE Instrument-cluster electronics	●	●	○	●	○	○	○
5 Series	E39	Body	IRIS Integrated Radio-Information System	●	○	○	○	○	○	○
5 Series	E39	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○
5 Series	E39	Body	KOM Instrument cluster	●	●	○	●	●	●	○
5 Series	E39	Body	LCM Light Check Module	●	●	○	●	●	●	○
5 Series	E39	Body	LCM Light Check Module IV	●	●	○	●	●	●	○
5 Series	E39	Body	LRA Automatic headlight vertical aim control	●	●	○	●	●	●	○
5 Series	E39	Body	MID Multi Information Display	●	●	○	●	○	○	○
5 Series	E39	Body	NAJ Navigation computer, Japan	●	●	○	●	●	●	○
5 Series	E39	Body	NAV Navigation computer	●	●	○	●	●	●	○
5 Series	E39	Body	PDC Park distance control	●	●	○	●	●	●	●
5 Series	E39	Body	RAD Radio	●	●	○	●	●	●	●
5 Series	E39	Body	RLS Rain/Light Sensor	●	●	○	●	●	○	●
5 Series	E39	Body	SES Language-input system	●	●	○	●	○	●	○
5 Series	E39	Body	SM/LSM Seat/steering-column memory	○	○	○	○	●	●	○
5 Series	E39	Body	STH park heating	●	●	○	●	●	●	○
5 Series	E39	Body	SZM Switching centre,centre console	●	●	○	●	●	●	●
5 Series	E39	Body	TCU Telematic control unit	●	●	○	●	●	●	●
5 Series	E39	Body	TEL Telephone interface	○	○	○	○	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E39	Body	ULF Universal charging and hands-free facility	●	●	○	●	●	●	●
5 Series	E39	Body	VID Video module	●	●	○	●	○	○	○
5 Series	E39	Body	ZKE Central body electronics	●	●	○	●	●	●	○
5 Series	E39	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
5 Series	E39	Chassis	DDS Deflation Detection System	●	●	○	●	●	○	○
5 Series	E39	Chassis	EDC Damper Control	●	●	○	●	●	●	●
5 Series	E39	Chassis	EHC Electronic Ride-Height Control	●	●	○	●	●	●	●
5 Series	E39	Chassis	LEW Steering-angle sensor	●	●	○	●	●	○	○
5 Series	E39	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
5 Series	E39	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
5 Series	E39	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
5 Series	E39	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
5 Series	E39	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
5 Series	E39	Drive	GR Cruise control	●	●	○	●	●	●	○
5 Series	E60/E61	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
5 Series	E60/E61	Body	AHL Adaptive directional headlights	●	●	●	●	●	●	●
5 Series	E60/E61	Body	AHM Trailer module	●	●	●	●	●	●	●
5 Series	E60/E61	Body	ALBBF active backrest width,front passenger	●	●	●	●	●	○	●
5 Series	E60/E61	Body	ALBFA active backrest width,driver	●	●	●	●	●	○	●
5 Series	E60/E61	Body	AMP Amplifier	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CA Comfort access system	●	●	●	●	●	○	●
5 Series	E60/E61	Body	CAN communication analysis	●	●	●	○	○	○	○
5 Series	E60/E61	Body	CCC-A Applications	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-BO User interface	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CCC-GW Gateway	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CDC CD Changer	●	●	●	●	○	●	●
5 Series	E60/E61	Body	CHAMP-BO User interface	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CHAMP-GW Gateway	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CIC Car Information Computer	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CIC-GW Gateway	●	●	●	●	○	●	●
5 Series	E60/E61	Body	CID Central information display	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CNAV Navigation system,China	●	●	●	●	●	●	●
5 Series	E60/E61	Body	CON Controller	●	●	●	●	●	●	●
5 Series	E60/E61	Body	DAB Digital tuner	●	●	●	●	●	●	●
5 Series	E60/E61	Body	DVDC DVD Changer	●	●	●	●	○	●	●
5 Series	E60/E61	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
5 Series	E60/E61	Body	FBI Flexible Bus Interface	●	●	●	●	●	○	●
5 Series	E60/E61	Body	FD Rear-compartment display	●	●	●	●	●	●	●
5 Series	E60/E61	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	●
5 Series	E60/E61	Body	FLA High Beam Assist	●	●	●	●	●	●	●
5 Series	E60/E61	Body	HKL Rear-lid lift	●	●	●	●	●	●	●
5 Series	E60/E61	Body	HUD Head-Up Display	●	●	●	●	●	●	●
5 Series	E60/E61	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
5 Series	E60/E61	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
5 Series	E60/E61	Body	JNAV Navigation system,Japan	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E60/E61	Body	KBM Body basic module	●	●	●	●	●	●	●
5 Series	E60/E61	Body	KGM Body Gateway Module	●	●	●	●	●	●	●
5 Series	E60/E61	Body	KHI Headset interface	●	●	●	●	●	●	●
5 Series	E60/E61	Body	KNAV Navigation system, Korea	●	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 Light module 2	●	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 Light module 2 with adaptive headlight	●	●	●	●	●	●	●
5 Series	E60/E61	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-BO User interface	●	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●
5 Series	E60/E61	Body	M-ASK-NAV Navigation system	●	●	●	●	●	●	○
5 Series	E60/E61	Body	MOST system analysis	●	●	●	●	○	○	○
5 Series	E60/E61	Body	MPM Micro-power module	●	●	●	●	●	●	●
5 Series	E60/E61	Body	NVE Night Vision Electronics	●	●	●	●	●	●	●
5 Series	E60/E61	Body	NVK Night Vision camera	●	●	●	●	●	●	●
5 Series	E60/E61	Body	PDC Park distance control	●	●	●	●	●	●	●
5 Series	E60/E61	Body	RLS Rain/Light Sensor	●	●	●	●	●	○	●
5 Series	E60/E61	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
5 Series	E60/E61	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SBSL Satellite, B-pillar, left	●	●	●	●	●	○	●
5 Series	E60/E61	Body	SBSR Satellite, B-pillar, right	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SFZ Satellite vehicle centre	●	●	●	●	●	○	●
5 Series	E60/E61	Body	SGM-SIM Safety and Gateway Module (SIM)	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SGM-ZGM Safety and Gateway Module (ZGM)	●	●	●	●	○	○	●
5 Series	E60/E61	Body	SHD Slide/tilt sunroof 2	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
5 Series	E60/E61	Body	SMBF Seat module, passenger	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SVS Language processing system	●	●	●	●	○	●	●
5 Series	E60/E61	Body	SZL Steering column switch centre 2	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SZL Switch centre, steering column	●	●	●	●	●	●	●
5 Series	E60/E61	Body	SZM Switching centre, centre console	●	●	●	●	●	●	●
5 Series	E60/E61	Body	TCU Telematic control unit	●	●	●	●	●	●	●
5 Series	E60/E61	Body	TLC Lane Departure Warning	●	●	●	●	●	●	○
5 Series	E60/E61	Body	TMBF Door module, front passenger	●	●	●	●	●	●	●
5 Series	E60/E61	Body	TMFA Door module, driver	●	●	●	●	●	○	●
5 Series	E60/E61	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●	●
5 Series	E60/E61	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
5 Series	E60/E61	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
5 Series	E60/E61	Body	VM Video Module	●	●	●	●	●	●	●
5 Series	E60/E61	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
5 Series	E60/E61	Chassis	ACC Active Cruise Control	●	●	●	●	○	○	●
5 Series	E60/E61	Chassis	ACC2 Active Cruise Control 2	●	●	●	●	○	○	●
5 Series	E60/E61	Chassis	AL active front steering (AFS70)	●	●	●	●	●	○	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E60/E61	Chassis	AL active steering	●	●	●	●	●	○	●
5 Series	E60/E61	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●	●
5 Series	E60/E61	Chassis	EDC Damper Control	●	●	●	●	●	●	●
5 Series	E60/E61	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	●
5 Series	E60/E61	Chassis	LDM Longitudinal Dynamics Management	●	●	●	●	●	○	●
5 Series	E60/E61	Chassis	LRR Long-range sensor	●	●	●	●	○	○	●
5 Series	E60/E61	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	CAS Car Access System	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	DME/DDE (Engine Electronics)	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	EGS/AGS (Transmission Control)	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
5 Series	E60/E61	Drive	VTC Valvetronic	●	○	○	○	○	○	●
5 Series	E60/E61	Drive	VTC2 Valvetronic 2	●	○	○	○	○	○	●
5 Series	E60/E61	Drive	VTG Transfer case	●	●	●	●	●	●	●
6 Series	E24	Drive	DME/DDE (Engine Electronics)	●	●	○	●	●	●	
6 Series	E24	Drive	EML (Engine-Power Control)	●	●	○	●	●	○	
6 Series	E24	Drive	EGS/AGS (Transmission Control)	●	●	○	●	●	●	
6 Series	E24	Body	KOM (Instrument cluster)	●	●	○	●			
6 Series	E24	Drive	EWS (Electronic car Immobilisation system)	●	●	○	●	●	○	
6 Series	E24	Drive	GSR (Cruise control)	●	●	○	●	●	○	
6 Series	E24	Body	AB (airbag)	●	●	○	●	●	○	
6 Series	E24	Body	SPM/SM (Seat/mirror memory)	●	●	○	●	●	○	
6 Series	E24	Body	IHK (Heater-A/C system)	●	●	○	●	●	○	
6 Series	E24	Chassis	ABS (Anti-lock braking system)\nASC (Automatic stability control)\nABD (Automatic brake differential (All-wheel drive))\nDSC (Dynamic stability control ('94-	●	●	○	●	●	●	
6 Series	E24	Chassis	DSC (Dynamic stability control)	●	●	○	●	●	○	
6 Series	E24	Body	ADS (Throttle-valve control)	●	●	○	●	●	○	
6 Series	E24	Chassis	ABS/ASC tester	●	●	○	●	●	○	
6 Series	E63/E64	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
6 Series	E63/E64	Body	AHL Adaptive directional headlights	●	●	●	●	●	●	●
6 Series	E63/E64	Body	AMP Amplifier	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CA Comfort access system	●	●	●	●	●	○	●
6 Series	E63/E64	Body	CAN communication analysis	●	●	●	○	○	○	○
6 Series	E63/E64	Body	CCC-A Applications	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-BO User interface	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CCC-GW Gateway	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CDC CD Changer	●	●	●	●	○	●	●
6 Series	E63/E64	Body	CHAMP-BO User interface	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CHAMP-GW Gateway	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CIC Car Information Computer	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CIC-GW Gateway	●	●	●	●	○	●	●
6 Series	E63/E64	Body	CID Central information display	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	E63/E64	Body	CNAV Navigation system, China	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CON Controller	●	●	●	●	●	●	●
6 Series	E63/E64	Body	CVM/CVM2 Convertible top module	●	●	●	●	●	●	●
6 Series	E63/E64	Body	DAB Digital tuner	●	●	●	●	●	●	●
6 Series	E63/E64	Body	DVDC DVD Changer	●	●	●	●	○	●	●
6 Series	E63/E64	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
6 Series	E63/E64	Body	FLA High Beam Assist	●	●	●	●	●	●	●
6 Series	E63/E64	Body	HUD Head-Up Display	●	●	●	●	●	●	●
6 Series	E63/E64	Body	IBOC Digital tuner US	●	●	●	●	●	○	●
6 Series	E63/E64	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
6 Series	E63/E64	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
6 Series	E63/E64	Body	JNAV Navigation system, Japan	●	●	●	●	●	●	●
6 Series	E63/E64	Body	KBM Body basic module	●	●	●	●	●	●	●
6 Series	E63/E64	Body	KGM Body Gateway Module	●	●	●	●	●	●	●
6 Series	E63/E64	Body	KNAV Navigation system, Korea	●	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 Light module 2	●	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 AHL light module 2 with adaptive headlight	●	●	●	●	●	●	●
6 Series	E63/E64	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●	●
6 Series	E63/E64	Body	M-ASK-B0 User interface	●	●	●	●	●	●	●
6 Series	E63/E64	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●
6 Series	E63/E64	Body	MOST system analysis	●	●	●	●	○	○	○
6 Series	E63/E64	Body	MPM Micro-power module	●	●	●	●	●	●	●
6 Series	E63/E64	Body	NVE Night Vision Electronics	●	●	●	●	●	●	●
6 Series	E63/E64	Body	NVK Night Vision camera	●	●	●	●	●	●	●
6 Series	E63/E64	Body	PDC Park distance control	●	●	●	●	●	●	●
6 Series	E63/E64	Body	RLS Rain/Light Sensor	●	●	●	●	●	○	●
6 Series	E63/E64	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
6 Series	E63/E64	Body	SBSL Satellite, B-pillar, left	●	●	●	●	●	○	●
6 Series	E63/E64	Body	SBSR Satellite, B-pillar, right	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SFZ Satellite vehicle centre	●	●	●	●	●	○	●
6 Series	E63/E64	Body	SGM-SIM Safety and Gateway Module (SIM)	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SGM-ZGM Safety and Gateway Module (ZGM)	●	●	●	●	○	○	●
6 Series	E63/E64	Body	SHD Slide/tilt sunroof 2							
6 Series	E63/E64	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SMBF Seat memory, front passenger							
6 Series	E63/E64	Body	SMF Seat memory, driver	●	●	●	●	●	●	○
6 Series	E63/E64	Body	SVS Language processing system	●	●	●	●	○	●	●
6 Series	E63/E64	Body	SZL Steering column switch centre 2	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SZL Switch centre, steering column	●	●	●	●	●	●	●
6 Series	E63/E64	Body	SZM Switching centre, centre console	●	●	●	●	●	●	●
6 Series	E63/E64	Body	TCU Telematic control unit	●	●	●	●	●	●	●
6 Series	E63/E64	Body	TLC Lane Departure Warning	●	●	●	●	●	●	○
6 Series	E63/E64	Body	TMBF Door module, front passenger	●	●	●	●	●	●	●
6 Series	E63/E64	Body	TMFA Door module, driver	●	●	●	●	●	○	●
6 Series	E63/E64	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	E63/E64	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
6 Series	E63/E64	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
6 Series	E63/E64	Body	VM Video Module	●	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ACC2 Active Cruise Control 2	●	●	●	●	○	○	●
6 Series	E63/E64	Chassis	AL active front steering(AFS70)	●	●	●	●	●	○	●
6 Series	E63/E64	Chassis	AL active steering	●	●	●	●	●	○	●
6 Series	E63/E64	Chassis	ARS Dynamic Drive	●	●	●	●	●	●	●
6 Series	E63/E64	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●	●
6 Series	E63/E64	Chassis	EDC Damper Control	●	●	●	●	●	●	●
6 Series	E63/E64	Chassis	LDM Longitudinal Dynamics Management	●	●	●	●	●	○	●
6 Series	E63/E64	Chassis	LRR Long-range sensor	●	●	●	●	○	○	●
6 Series	E63/E64	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	CAS Car Access System	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
6 Series	E63/E64	Drive	VTC Valvetronic	●	○	○	○	○	○	●
6 Series	E63/E64	Drive	VTC2 Valvetronic 2	●	○	○	○	○	○	●
7 Series	E23	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
7 Series	E23	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
7 Series	E23	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
7 Series	E23	Body	KOM(Instrument cluster)	●	●	○	●			
7 Series	E23	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
7 Series	E23	Drive	GSR(Cruise control)	●	●	○	●	●	○	
7 Series	E23	Body	AB(airbag)	●	●	○	●	●	○	
7 Series	E23	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
7 Series	E23	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
7 Series	E23	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
7 Series	E23	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
7 Series	E23	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
7 Series	E23	Chassis	ABS/ASC tester	●	●	○	●	●	○	
7 Series	E32	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
7 Series	E32	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
7 Series	E32	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
7 Series	E32	Body	KOM(Instrument cluster)	●	●	○	●			
7 Series	E32	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
7 Series	E32	Drive	GSR(Cruise control)	●	●	○	●	●	○	
7 Series	E32	Body	AB(airbag)	●	●	○	●	●	○	
7 Series	E32	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
7 Series	E32	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E32	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
7 Series	E32	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
7 Series	E32	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
7 Series	E32	Chassis	ABS/ASC tester	●	●	○	●	●	○	
7 Series	E38	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
7 Series	E38	Body	AIC Automatic Interval control	●	●	○	●	●	○	○
7 Series	E38	Body	BIT Basis Interface Telephone	●	●	○	●	●	○	○
7 Series	E38	Body	BM On-board monitor	●	●	○	●	●	●	○
7 Series	E38	Body	BMBT On-board monitor,control panel	●	●	○	●	●	○	○
7 Series	E38	Body	CCM Check Control Module	●	●	○	●	○	○	○
7 Series	E38	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
7 Series	E38	Body	FBZV Radio-control system	●	●	○	●	○	○	○
7 Series	E38	Body	FGB rear compartment blower	●	●	○	●	○	○	○
7 Series	E38	Body	FHK rear-compartment heating/air conditioning	●	●	○	●	○	○	○
7 Series	E38	Body	FID Rear-compartment information display	●	●	○	●	○	○	○
7 Series	E38	Body	FMBT Rear-compartment monitor,control panel			○				
7 Series	E38	Body	FMGT Rear-compartment monitor,graphics section			○				
7 Series	E38	Body	GR2 Cruise control	●	●	○	●	●	○	○
7 Series	E38	Body	HKM Boot-lid module	●	●	○	●	○	○	○
7 Series	E38	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
7 Series	E38	Body	IHKR Heater and A/C control	●	●	○	●	●	●	●
7 Series	E38	Body	IKE Instrument-cluster electronics	●	●	○	●	○	○	○
7 Series	E38	Body	IR Infrared compact locking system			○				
7 Series	E38	Body	IR Radio/infrared locking system			○				
7 Series	E38	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○
7 Series	E38	Body	LCM Light Check Module	●	●	○	●	●	●	○
7 Series	E38	Body	LM Lights Module	●	●	○	●	●	●	●
7 Series	E38	Body	LRA Automatic headlight vertical aim control	●	●	○	●	●	●	○
7 Series	E38	Body	MID Multi Information Display	●	●	○	●	○	○	○
7 Series	E38	Body	NAJ Navigation computer,Japan	●	●	○	●	●	●	○
7 Series	E38	Body	NAV Navigation computer	●	●	○	●	●	●	○
7 Series	E38	Body	NAV Navigation computer MKIII	●	●	○	●	●	○	○
7 Series	E38	Body	PDC Park distance control	●	●	○	●	●	●	●
7 Series	E38	Body	RAD Radio	●	●	○	●	●	●	●
7 Series	E38	Body	RCC Radio-clock module	●	○	○	○	●	○	○
7 Series	E38	Body	SES Language-input system	●	●	○	●	○	●	○
7 Series	E38	Body	SHD Sliding/tilting sunroof	●	●	○	●	●	●	●
7 Series	E38	Body	SM/LSM Seat/steering-column memory	○	○	○	○	●	●	○
7 Series	E38	Body	SMB passenger seat memory	●	●	○	●	●		○
7 Series	E38	Body	STH park heating	●	●	○	●	●	●	○
7 Series	E38	Body	SZM Switching centre,centre console	●	●	○	●	●	●	●
7 Series	E38	Body	TEL Telephone interface	○	○	○	○	●	●	○
7 Series	E38	Body	URS Rollover sensor	●	●	○	●	●	○	○
7 Series	E38	Body	VID Video module	●	●	○	●	○	○	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E38	Body	VID Video module III	●	●	○	●	○	○	○
7 Series	E38	Body	ZKE Central body electronics	●	●	○	●	●	●	○
7 Series	E38	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
7 Series	E38	Chassis	EDC Damper Control	●	●	○	●	●	●	●
7 Series	E38	Chassis	LEW Steering-angle sensor	●	●	○	●	●	○	○
7 Series	E38	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
7 Series	E38	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
7 Series	E38	Chassis	RDW tyre-blowout warning	●	●	○	●	●	○	○
7 Series	E38	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
7 Series	E38	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
7 Series	E38	Drive	EML Electronic engine-power control	●	●	○	●	○	○	○
7 Series	E38	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
7 Series	E38	Drive	TRS Electronic battery isolator switch	●	●	○	●	○	○	○
7 Series	E65	Body	AHL Adaptive directional headlights	●	●	●	●	●	●	●
7 Series	E65	Body	AHM Trailer module	●	●	●	●	●	●	●
7 Series	E65	Body	AMP Amplifier	●	●	●	●	●	●	●
7 Series	E65	Body	ANT Aerial/antenna tuner	●	●	●	●	●	●	●
7 Series	E65	Body	ASK Audio system controller	●	●	●	●	●	●	●
7 Series	E65	Body	BZM Control centre,centre console	●	●	●	●	●	●	●
7 Series	E65	Body	CA Comfort access system	●	●	●	●	●	○	●
7 Series	E65	Body	CAN communication analysis	●	●	●	○	○	○	○
7 Series	E65	Body	CD Control Display	●	●	●	●	○	●	●
7 Series	E65	Body	CDC CD Changer	●	●	●	●	○	●	●
7 Series	E65	Body	CD-GW Control Display(Gateway)	●	●	●	●	●	●	●
7 Series	E65	Body	CEM Clean Energy Module	●	●	●	●	●	○	○
7 Series	E65	Body	CNAV Navigation system,China	●	●	●	●	●	●	●
7 Series	E65	Body	CON Controller	●	●	●	●	●	●	●
7 Series	E65	Body	DAB Digital tuner	●	●	●	●	●	●	●
7 Series	E65	Body	DVDC DVD Changer	●	●	●	●	○	●	●
7 Series	E65	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
7 Series	E65	Body	FBI Flexible Bus Interface	●	●	●	●	●	○	●
7 Series	E65	Body	FBZM Rear compartment,control centre,centre console	●	●	●	●	●	●	●
7 Series	E65	Body	FCON Rear compartment controller	●	●	●	●	●	●	●
7 Series	E65	Body	FD Rear-compartment display	●	●	●	●	●	●	●
7 Series	E65	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	●
7 Series	E65	Body	FLA High Beam Assist	●	●	●	●	●	●	●
7 Series	E65	Body	HKL Rear-lid lift	●	●	●	●	●	●	●
7 Series	E65	Body	IBOC Digital tuner US	●	●	●	●	●	○	●
7 Series	E65	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
7 Series	E65	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
7 Series	E65	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○
7 Series	E65	Body	JNAV Navigation system,Japan	●	●	●	●	●	●	●
7 Series	E65	Body	KHI Headset interface	●	●	●	●	●	●	●
7 Series	E65	Body	KNAV Navigation system,Korea	●	●	●	●	●	●	●
7 Series	E65	Body	LM Lights Module	●	●	●	●	●	●	●
7 Series	E65	Body	LM2 Light module 2	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E65	Body	LM2 Light module 2 with adaptive headlight	●	●	●	●	●	●	●
7 Series	E65	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	●	●	●	●	●	●	●
7 Series	E65	Body	MOST system analysis	●	●	●	●	○	○	○
7 Series	E65	Body	NAJ Navigation computer, Japan	●	●	●	●	●	●	○
7 Series	E65	Body	NAV Navigation computer	●	●	●	●	●	●	○
7 Series	E65	Body	NVE Night Vision Electronics	●	●	●	●	●	●	●
7 Series	E65	Body	NVK Night Vision camera	●	●	●	●	●	●	●
7 Series	E65	Body	PDC Park distance control	●	●	●	●	●	●	●
7 Series	E65	Body	PM Power Module	●	●	●	●	●	●	●
7 Series	E65	Body	RLS Rain/Light Sensor	●	●	●	●	●	○	●
7 Series	E65	Body	SASL Satellite, A-pillar, left	●	●	●	●	●	○	●
7 Series	E65	Body	SASR Satellite, A-pillar, right	●	●	●	●	●	○	●
7 Series	E65	Body	SBSL Satellite, B-pillar, left	●	●	●	●	●	○	●
7 Series	E65	Body	SBSR Satellite, B-pillar, right	●	●	●	●	●	●	●
7 Series	E65	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
7 Series	E65	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	●
7 Series	E65	Body	SFZ Satellite vehicle centre	●	●	●	●	●	○	●
7 Series	E65	Body	SG-FD Control unit, rear-compartment display	●	●	●	●	○	●	●
7 Series	E65	Body	SG-FD-GW Control unit, rear-compartment display (gateway)	●	●	●	●	●	●	●
7 Series	E65	Body	SGM-SIM Safety and Gateway Module (SIM)	●	●	●	●	●	●	●
7 Series	E65	Body	SGM-ZGM Safety and Gateway Module (ZGM)	●	●	●	●	○	○	●
7 Series	E65	Body	SHD Slide/tilt sunroof 2							
7 Series	E65	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●	●
7 Series	E65	Body	SHZH Independent/auxiliary heater	●	●	●	●	●	●	●
7 Series	E65	Body	SIM Safety and Information Module	●	●	●	●	●	●	○
7 Series	E65	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
7 Series	E65	Body	SMBF Seat module, passenger	●	●	●	●	●	●	●
7 Series	E65	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	●
7 Series	E65	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
7 Series	E65	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	●
7 Series	E65	Body	SSBF Satellite, seat, passenger	●	●	●	●	●	○	●
7 Series	E65	Body	SSFA Satellite, seat, driver	●	●	●	●	●	○	●
7 Series	E65	Body	SSH Satellite, seat, rear	●	●	●	●	●	●	●
7 Series	E65	Body	STVL Satellite, door, front left	●	●	●	●	●	○	●
7 Series	E65	Body	STVR Satellite, door, front right	●	●	●	●	●	○	●
7 Series	E65	Body	SVS Language processing system	●	●	●	●	○	●	●
7 Series	E65	Body	SZL Switch centre, steering column	●	●	●	●	●	●	●
7 Series	E65	Body	TCU Telematic control unit	●	●	●	●	●	●	●
7 Series	E65	Body	TEL Telephone interface	○	○	○	○	●	●	○
7 Series	E65	Body	TEL Telephone (USA)	●	●	●	●	○	●	●
7 Series	E65	Body	TMBFH Door module, passenger's side, rear	●	●	●	●	●	○	●
7 Series	E65	Body	TMBFT Door module, passenger door	●	●	●	●	●	○	●
7 Series	E65	Body	TMFAH Door module, driver's side, rear	●	●	●	●	●	○	●
7 Series	E65	Body	TMFAT Door module, driver's door	●	●	●	●	●	○	●
7 Series	E65	Body	VM Video Module	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E65	Body	WIM Wiper module	●	●	●	●	●	●	●
7 Series	E65	Body	ZBM Two-battery management	●	●	●	●	●	●	●
7 Series	E65	Body	ZGM Central Gateway Module	●	●	●	●	○	○	●
7 Series	E65	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
7 Series	E65	Chassis	ACC Active Cruise Control	●	●	●	●	○	○	●
7 Series	E65	Chassis	ACC2 Active Cruise Control 2	●	●	●	●	○	○	●
7 Series	E65	Chassis	ARS Dynamic Drive	●	●	●	●	●	●	●
7 Series	E65	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●	●
7 Series	E65	Chassis	CIM Chassis Integration Module	●	●	●	●	●	●	●
7 Series	E65	Chassis	CIM2 Chassis Integration Module 2	●	●	●	●	●	●	●
7 Series	E65	Chassis	EDC Damper Control	●	●	●	●	●	●	●
7 Series	E65	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	●
7 Series	E65	Chassis	EMF Parking brake	●	●	●	●	●	●	●
7 Series	E65	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
7 Series	E65	Drive	CAS Car Access System	●	●	●	●	●	●	●
7 Series	E65	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
7 Series	E65	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
7 Series	E65	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
7 Series	E65	Drive	HPFI control unit	●	○	○	○	○	○	●
7 Series	E65	Drive	VTC Valvetronic	●	○	○	○	○	○	●
7 Series	E65	Drive	VTC2 Valvetronic 2	●	○	○	○	○	○	●
8 Series	E31	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
8 Series	E31	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
8 Series	E31	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
8 Series	E31	Body	KOM(Instrument cluster)	●	●	○	●	●	○	
8 Series	E31	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
8 Series	E31	Drive	GSR(Cruise control)	●	●	○	●	●	○	
8 Series	E31	Body	AB(airbag)	●	●	○	●	●	○	
8 Series	E31	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
8 Series	E31	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
8 Series	E31	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
8 Series	E31	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
8 Series	E31	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
8 Series	E31	Chassis	ABS/ASC tester	●	●	○	●	●	○	
X3 Series	E83	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
X3 Series	E83	Body	AHL Adaptive directional headlights	●	●	○	●	●	●	●
X3 Series	E83	Body	CDC CD Changer	●	●	○	●	○	●	●
X3 Series	E83	Body	CID Central information display	●	●	○	●	●	●	●
X3 Series	E83	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
X3 Series	E83	Body	GM base module	●	●	○	●	●	●	○
X3 Series	E83	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
X3 Series	E83	Body	IHKR Heater and A/C control	●	●	○	●	●	●	●
X3 Series	E83	Body	INSTR Instrument cluster	●	●	○	●	●	●	●
X3 Series	E83	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X3 Series	E83	Body	LM Lights Module	●	●	○	●	●	●	●
X3 Series	E83	Body	LSZ Light switch centre II	●	●	○	●	●	●	○
X3 Series	E83	Body	MIR Multi-Information Radio	●	●	○	●	●	○	○
X3 Series	E83	Body	NAJ Navigation computer, Japan	●	●	○	●	●	●	○
X3 Series	E83	Body	NAV Navigation computer	●	●	○	●	●	●	○
X3 Series	E83	Body	PDC Park distance control	●	●	○	●	●	●	●
X3 Series	E83	Body	RAD Radio	●	●	○	●	●	●	●
X3 Series	E83	Body	RLS Rain/Light Sensor	●	●	○	●	●	○	●
X3 Series	E83	Body	SBBF Seat occupancy, passenger	●	●	○	●		○	○
X3 Series	E83	Body	SES Language-input system	●	●	○	●	○	●	○
X3 Series	E83	Body	SHD Sliding/tilting sunroof	●	●	○	●	●	●	●
X3 Series	E83	Body	SMF Seat memory, driver	●	●	○	●	●	●	○
X3 Series	E83	Body	SZM Switching centre, centre console	●	●	○	●	●	●	●
X3 Series	E83	Body	TCU Telematic control unit	●	●	○	●	●	●	●
X3 Series	E83	Body	ULF Universal charging and hands-free facility	●	●	○	●	●	●	●
X3 Series	E83	Body	VID Video module	●	●	○	●	○	○	○
X3 Series	E83	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
X3 Series	E83	Chassis	LWS Steering angle sensor	●	●	○	●	●	○	○
X3 Series	E83	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
X3 Series	E83	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
X3 Series	E83	Chassis	SVT Servotronic	●	●	○	●	●	○	○
X3 Series	E83	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
X3 Series	E83	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
X3 Series	E83	Drive	EKPS fuel-pump control	●	●	○	●	●	●	●
X3 Series	E83	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
X3 Series	E83	Drive	VTG Transfer case	●	●	○	●	●	●	●
X5 Series	E53	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
X5 Series	E53	Body	AHL Adaptive directional headlights	●	●	○	●	●	●	●
X5 Series	E53	Body	AIC Automatic Interval control	●	●	○	●	●	○	○
X5 Series	E53	Body	BIT Basis Interface Telephone	●	●	○	●	●	○	○
X5 Series	E53	Body	BM On-board monitor	●	●	○	●	●	●	○
X5 Series	E53	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
X5 Series	E53	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
X5 Series	E53	Body	IHKR Heater and A/C control	●	●	○	●	●	●	●
X5 Series	E53	Body	IKE Instrument-cluster electronics	●	●	○	●	○	○	○
X5 Series	E53	Body	JBIT Japan Basis Interface Telephone	●	○	○	○	●	○	○
X5 Series	E53	Body	KOM Instrument cluster	●	●	○	●	●	●	○
X5 Series	E53	Body	LCM Light Check Module	●	●	○	●	●	●	○
X5 Series	E53	Body	LCM Light Check Module IV	●	●	○	●	●	●	○
X5 Series	E53	Body	LRA Automatic headlight vertical aim control	●	●	○	●	●	●	○
X5 Series	E53	Body	MID Multi Information Display	●	●	○	●	○	○	○
X5 Series	E53	Body	NAJ Navigation computer, Japan	●	●	○	●	●	●	○
X5 Series	E53	Body	NAV Navigation computer	●	●	○	●	●	●	○
X5 Series	E53	Body	NAV Navigation computer MKII	●	●	○	●	●	○	○
X5 Series	E53	Body	PDC Park distance control	●	●	○	●	●	●	●
X5 Series	E53	Body	PDC2 Park Distance Control 2	●	●	○	●	●	●	○
X5 Series	E53	Body	RAD Radio	●	●	○	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X5 Series	E53	Body	RLS Rain/Light Sensor	●	●	○	●	●	○	●
X5 Series	E53	Body	SBBF Seat occupancy,passenger	●	●	○	●		○	○
X5 Series	E53	Body	SES Language-input system	●	●	○	●	○	●	○
X5 Series	E53	Body	SHD Sliding/tilting sunroof	●	●	○	●	●	●	●
X5 Series	E53	Body	SM/SLM Seat/steering-column memory	●	●	○	●	●	●	○
X5 Series	E53	Body	STH park heating	●	●	○	●	●	●	○
X5 Series	E53	Body	SZM Switching centre,centre console	●	●	○	●	●	●	●
X5 Series	E53	Body	TCU Telematic control unit	●	●	○	●	●	●	●
X5 Series	E53	Body	TEL Telephone interface	○	○	○	○	●	●	○
X5 Series	E53	Body	ULF Universal charging and hands-free facility	●	●	○	●	●	●	●
X5 Series	E53	Body	VID Video module	●	●	○	●	○	○	○
X5 Series	E53	Body	ZKE Central body electronics	●	●	○	●	●	●	○
X5 Series	E53	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
X5 Series	E53	Chassis	EHC Electronic Ride-Height Control	●	●	○	●	●	●	●
X5 Series	E53	Chassis	EHC2 Electronic ride-level control							
X5 Series	E53	Chassis	LEW Steering-angle sensor	●	●	○	●	●	○	○
X5 Series	E53	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
X5 Series	E53	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
X5 Series	E53	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
X5 Series	E53	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
X5 Series	E53	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
X5 Series	E53	Drive	VTG Transfer case	●	●	○	●	●	●	●
X5 Series	E70	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
X5 Series	E70	Body	AHM Trailer module	●	●	●	●	●	●	●
X5 Series	E70	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	●
X5 Series	E70	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	●
X5 Series	E70	Body	CA Comfort access system	●	●	●	●	●	○	●
X5 Series	E70	Body	CAN communication analysis	●	●	●	○	○	○	○
X5 Series	E70	Body	CCC-A Applications	●	●	●	●	●	●	●
X5 Series	E70	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
X5 Series	E70	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
X5 Series	E70	Body	CCC-BO User interface	●	●	●	●	●	●	●
X5 Series	E70	Body	CCC-GW Gateway	●	●	●	●	●	●	●
X5 Series	E70	Body	CDC CD Changer	●	●	●	●	○	●	●
X5 Series	E70	Body	CHAMP-BO User interface	●	●	●	●	●	●	●
X5 Series	E70	Body	CHAMP-GW Gateway	●	●	●	●	●	●	●
X5 Series	E70	Body	CID Central information display	●	●	●	●	●	●	●
X5 Series	E70	Body	CNAV Navigation system,China	●	●	●	●	●	●	●
X5 Series	E70	Body	CON Controller	●	●	●	●	●	●	●
X5 Series	E70	Body	DAB Digital tuner	●	●	●	●	●	●	●
X5 Series	E70	Body	DVDC DVD Changer	●	●	●	●	○	●	●
X5 Series	E70	Body	FD Rear-compartment display	●	●	●	●	●	●	●
X5 Series	E70	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	●
X5 Series	E70	Body	FLA High Beam Assist	●	●	●	●	●	●	●
X5 Series	E70	Body	FRM2 footwell module 2	●	●	●	●	●	●	●
X5 Series	E70	Body	FZD Function centre,roof	●	●	●	●	●	●	●
X5 Series	E70	Body	HKL Rear-lid lift	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X5 Series	E70	Body	HUD Head-Up Display	●	●	●	●	●	●	●
X5 Series	E70	Body	IBOC Digital tuner US	●	●	●	●	●	○	●
X5 Series	E70	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
X5 Series	E70	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
X5 Series	E70	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	●
X5 Series	E70	Body	JNAV Navigation system, Japan	●	●	●	●	●	●	●
X5 Series	E70	Body	KHM Headphones module							
X5 Series	E70	Body	KNAV Navigation system, Korea	●	●	●	●	●	●	●
X5 Series	E70	Body	M-ASK-BO User interface	●	●	●	●	●	●	●
X5 Series	E70	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●
X5 Series	E70	Body	MOST system analysis	●	●	●	●	○	○	○
X5 Series	E70	Body	PDC Park distance control	●	●	●	●	●	●	●
X5 Series	E70	Body	RFK Reversing camera	●	●	●	●	●	●	●
X5 Series	E70	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
X5 Series	E70	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	●
X5 Series	E70	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
X5 Series	E70	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
X5 Series	E70	Body	SMBF Seat module, passenger	●	●	●	●	●	●	●
X5 Series	E70	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
X5 Series	E70	Body	TCU Telematic control unit	●	●	●	●	●	●	●
X5 Series	E70	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
X5 Series	E70	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
X5 Series	E70	Body	VM Video Module	●	●	●	●	●	●	●
X5 Series	E70	Body	VSW video switch	●	●	●	●	●	●	○
X5 Series	E70	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
X5 Series	E70	Chassis	AL active front steering(AFS70)	●	●	●	●	●	○	●
X5 Series	E70	Chassis	ARS Dynamic Drive	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	●
X5 Series	E70	Chassis	EMF Parking brake	●	●	●	●	●	●	●
X5 Series	E70	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
X5 Series	E70	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	●
X5 Series	E70	Drive	CAS Car Access System	●	●	●	●	●	●	●
X5 Series	E70	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
X5 Series	E70	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
X5 Series	E70	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
X5 Series	E70	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
X5 Series	E70	Drive	VTC Valvetronic	●	○	○	○	○	○	●
X5 Series	E70	Drive	VTC2 Valvetronic 2	●	○	○	○	○	○	●
X5 Series	E70	Drive	VTG Transfer case	●	●	●	●	●	●	●
X6 Series	E71	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
X6 Series	E71	Body	AHM Trailer module	●	●	●	●	●	●	●
X6 Series	E71	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	●
X6 Series	E71	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X6 Series	E71	Body	CA Comfort access system	●	●	●	●	●	○	●
X6 Series	E71	Body	CAN communication analysis	●	●	●	○	○	○	○
X6 Series	E71	Body	CCC-A Applications	●	●	●	●	●	●	●
X6 Series	E71	Body	CCC-ANT Aerial tuner	●	●	●	●	●	●	●
X6 Series	E71	Body	CCC-ASK Audio system controller	●	●	●	●	●	●	●
X6 Series	E71	Body	CCC-BO User interface	●	●	●	●	●	●	●
X6 Series	E71	Body	CCC-GW Gateway	●	●	●	●	●	●	●
X6 Series	E71	Body	CDC CD Changer	●	●	●	●	○	●	●
X6 Series	E71	Body	CHAMP-BO User interface	●	●	●	●	●	●	●
X6 Series	E71	Body	CHAMP-GW Gateway	●	●	●	●	●	●	●
X6 Series	E71	Body	CID Central information display	●	●	●	●	●	●	●
X6 Series	E71	Body	CNAV Navigation system, China	●	●	●	●	●	●	●
X6 Series	E71	Body	CON Controller	●	●	●	●	●	●	●
X6 Series	E71	Body	DAB Digital tuner	●	●	●	●	●	●	●
X6 Series	E71	Body	DVDC DVD Changer	●	●	●	●	○	●	●
X6 Series	E71	Body	FD Rear-compartment display	●	●	●	●	●	●	●
X6 Series	E71	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	●
X6 Series	E71	Body	FLA High Beam Assist	●	●	●	●	●	●	●
X6 Series	E71	Body	FRM2 footwell module 2	●	●	●	●	●	●	●
X6 Series	E71	Body	FZD Function centre, roof	●	●	●	●	●	●	●
X6 Series	E71	Body	HKL Rear-lid lift	●	●	●	●	●	●	●
X6 Series	E71	Body	HUD Head-Up Display	●	●	●	●	●	●	●
X6 Series	E71	Body	IBOC Digital tuner US	●	●	●	●	●	○	●
X6 Series	E71	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
X6 Series	E71	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
X6 Series	E71	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	●
X6 Series	E71	Body	JNAV Navigation system, Japan	●	●	●	●	●	●	●
X6 Series	E71	Body	KHM Headphones module							
X6 Series	E71	Body	KNAV Navigation system, Korea	●	●	●	●	●	●	●
X6 Series	E71	Body	M-ASK-BO User interface	●	●	●	●	●	●	●
X6 Series	E71	Body	M-ASK-GW Gateway	●	●	●	●	●	●	●
X6 Series	E71	Body	MOST system analysis	●	●	●	●	○	○	○
X6 Series	E71	Body	PDC Park distance control	●	●	●	●	●	●	●
X6 Series	E71	Body	RFK Reversing camera	●	●	●	●	●	●	●
X6 Series	E71	Body	RLSS Rain/Light Solar Sensor	●	●	●	●	●	○	○
X6 Series	E71	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	●
X6 Series	E71	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
X6 Series	E71	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
X6 Series	E71	Body	SMBF Seat module, passenger	●	●	●	●	●	●	●
X6 Series	E71	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
X6 Series	E71	Body	TCU Telematic control unit	●	●	●	●	●	●	●
X6 Series	E71	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
X6 Series	E71	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
X6 Series	E71	Body	VM Video Module	●	●	●	●	●	●	●
X6 Series	E71	Body	VSW video switch	●	●	●	●	●	●	○
X6 Series	E71	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
X6 Series	E71	Chassis	AL active steering	●	●	●	●	●	○	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X6 Series	E71	Chassis	ARS Dynamic Drive 2	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	●
X6 Series	E71	Chassis	EMF Parking brake	●	●	●	●	●	●	●
X6 Series	E71	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	○	○
X6 Series	E71	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
X6 Series	E71	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	●
X6 Series	E71	Drive	CAS Car Access System	●	●	●	●	●	●	●
X6 Series	E71	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
X6 Series	E71	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
X6 Series	E71	Drive	EKPS fuel-pump control	●	●	●	●	●	●	●
X6 Series	E71	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
X6 Series	E71	Drive	QMVH Lateral-moment distribution, rear axle	●	●	●	●	●	●	●
X6 Series	E71	Drive	VTG Transfer case	●	●	●	●	●	●	●
Z Series	E30	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	
Z Series	E30	Drive	EML(Engine-Power Control)	●	●	○	●	●	○	
Z Series	E30	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	
Z Series	E30	Body	KOM(Instrument cluster)	●	●	○	●			
Z Series	E30	Drive	EWS(Electronic car Immobilisation system)	●	●	○	●	●	○	
Z Series	E30	Drive	GSR(Cruise control)	●	●	○	●	●	○	
Z Series	E30	Body	AB(airbag)	●	●	○	●	●	○	
Z Series	E30	Body	SPM/SM(Seat/mirror memory)	●	●	○	●	●	○	
Z Series	E30	Body	IHK(Heater-A/C system)	●	●	○	●	●	○	
Z Series	E30	Chassis	ABS(Anti-lock braking system)\nASC(Automatic stability control)\nABD(Automatic brake differential(All-wheel drive))\nDSC(Dynamic stability control('94-	●	●	○	●	●	●	
Z Series	E30	Chassis	DSC(Dynamic stability control)	●	●	○	●	●	○	
Z Series	E30	Body	ADS(Throttle-valve control)	●	●	○	●	●	○	
Z Series	E30	Chassis	ABS/ASC tester	●	●	○	●	●	○	
Z3 Series	E36	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
Z3 Series	E36	Body	IR Radio/infrared locking system			○				
Z3 Series	E36	Body	KOM Instrument cluster	●	●	○	●	●	●	○
Z3 Series	E36	Body	ZKE Central body electronics	●	●	○	●	●	●	○
Z3 Series	E36	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
Z3 Series	E36	Chassis	LEW Steering-angle sensor	●	●	○	●	●	○	○
Z3 Series	E36	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
Z3 Series	E36	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
Z3 Series	E36	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
Z3 Series	E36	Drive	GR Cruise control	●	●	○	●	●	●	○
Z3 Series	E36	Drive	TOENS Thermal oil-level sensor	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
Z4 Series	E85/E86	Body	CDC CD Changer	●	●	○	●	○	●	●
Z4 Series	E85/E86	Body	CID Central information display	●	●	○	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Z4 Series	E85/E86	Body	CVM/CVM2 Convertible top module	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
Z4 Series	E85/E86	Body	GM5 General module 5	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	IHKA Heater/automatic A/C control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	IHKS Integrated heating/air-conditioning control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	INSTR Instrument cluster	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	LSZ Light switch centre II	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	MIR Multi-Information Radio	●	●	○	●	●	○	○
Z4 Series	E85/E86	Body	NAJ Navigation computer, Japan	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	NAV Navigation computer	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	PDC Park distance control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	RAD Radio	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	RLS Rain/Light Sensor	●	●	○	●	●	○	●
Z4 Series	E85/E86	Body	SBBF Seat occupancy, passenger	●	●	○	●	●	○	○
Z4 Series	E85/E86	Body	SBSL Satellite, B-pillar, left	●	●	○	●	●	○	●
Z4 Series	E85/E86	Body	SBSR Satellite, B-pillar, right	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	SES Language-input system	●	●	○	●	○	●	○
Z4 Series	E85/E86	Body	SIM Safety and Information Module	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	SMF Seat memory, driver	●	●	○	●	●	●	○
Z4 Series	E85/E86	Body	STVL Satellite, door, front left	●	●	○	●	●	○	●
Z4 Series	E85/E86	Body	STVR Satellite, door, front right	●	●	○	●	●	○	●
Z4 Series	E85/E86	Body	SZM Switching centre, centre console	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	TCU Telematic control unit	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	ULF Universal charging and hands-free facility	●	●	○	●	●	●	●
Z4 Series	E85/E86	Body	VID Video module	●	●	○	●	○	○	○
Z4 Series	E85/E86	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Chassis	EPS Electronic Power Steering	●	●	○	●	●	●	●
Z4 Series	E85/E86	Chassis	LWS Steering angle sensor	●	●	○	●	●	○	○
Z4 Series	E85/E86	Chassis	MFL Multi-function steering wheel	●	●	○	●	●	○	○
Z4 Series	E85/E86	Chassis	RDC Tyre pressure control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Drive	DME/DDE (Engine Electronics)	●	●	○	●	●	●	●
Z4 Series	E85/E86	Drive	EGS/AGS (Transmission Control)	●	●	○	●	●	●	●
Z4 Series	E85/E86	Drive	EKPS fuel-pump control	●	●	○	●	●	●	●
Z4 Series	E85/E86	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
Z8 Series	E52	Body	MRS/AB Airbag/ACSM	●	●	○	●	●	○	●
Z8 Series	E52	Body	BIT Basis Interface Telephone	●	●	○	●	●	○	○
Z8 Series	E52	Body	CVM/CVM2 Convertible top module	●	●	○	●	●	●	●
Z8 Series	E52	Body	DSP Digital Sound Processor	●	●	○	●	●	○	○
Z8 Series	E52	Body	GM base module	●	●	○	●	●	●	○
Z8 Series	E52	Body	IHKS Integrated heating/air-conditioning control	●	●	○	●	●	●	●
Z8 Series	E52	Body	KOM Instrument cluster	●	●	○	●	●	●	○
Z8 Series	E52	Body	LCM Light Check Module	●	●	○	●	●	●	○
Z8 Series	E52	Body	LCM Light Check Module IV	●	●	○	●	●	●	○
Z8 Series	E52	Body	LRA Automatic headlight vertical aim control	●	●	○	●	●	●	○
Z8 Series	E52	Body	MIR Multi-Information Radio	●	●	○	●	●	○	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Z8 Series	E52	Body	NAV Navigation computer MKII	●	●	○	●	●	○	○
Z8 Series	E52	Body	NAV Navigation computer MKIII	●	●	○	●	●	○	○
Z8 Series	E52	Body	RAD Radio	●	●	○	●	●	●	●
Z8 Series	E52	Body	TEL Telephone interface	○	○	○	○	●	●	○
Z8 Series	E52	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	○	●	●	●	●
Z8 Series	E52	Chassis	DDS Deflation Detection System	●	●	○	●	●	○	○
Z8 Series	E52	Chassis	ELV Electronic steering-column locking	●	●	○	●	●	○	○
Z8 Series	E52	Chassis	LEW Steering-angle sensor	●	●	○	●	●	○	○
Z8 Series	E52	Drive	DME/DDE(Engine Electronics)	●	●	○	●	●	●	●
Z8 Series	E52	Drive	EGS/AGS(Transmission Control)	●	●	○	●	●	●	●
Z8 Series	E52	Drive	EWS Vehicle immobilizer	●	●	○	●	●	●	○
Z Reihe	Z4 E89	Drive	CAS Car Access System	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Drive	DKG Twin-clutch gearbox	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Drive	DME/DDE(Engine Electronics)	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Drive	EGS/AGS(Transmission Control)	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Drive	GWS Gear selector switch	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Chassis	ABS/ASC/DSC Dynamic Stability Control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Chassis	EDC Damper Control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Chassis	EMF Parking brake	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	AMP Amplifier	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	CA Comfort access system	●	●	●	●	●	○	●
Z Reihe	Z4 E89	Body	CAN communication analysis	●	●	●	○	○	○	○
Z Reihe	Z4 E89	Body	CDC CD Changer	●	●	●	●	○	●	●
Z Reihe	Z4 E89	Body	CIC Car Information Computer	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	CIC-GW Gateway	●	●	●	●	○	●	●
Z Reihe	Z4 E89	Body	CID Central Information Display	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	CNAV Navigation system,China	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	CON Controller	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	CTM Convertible-top module	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	DAB Digital tuner	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	DVDC DVD Changer	●	●	●	●	○	●	●
Z Reihe	Z4 E89	Body	DWA anti-theft alarm system	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	FLA High Beam Assist	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	FRM2 Footwell module 2	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	FZD Function centre,roof	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	IHKA Heater/automatic A/C control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	IHKR Heater and A/C control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	IHR Integrated heater control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	INSTR Instrument cluster	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	JNAV Navigation system,Japan	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	KNAV Navigation system,Korea	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	M-ASK-BO User interface	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	M-ASK-BO User interface	●	●	●	●	●	●	●

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Z Reihe	Z4 E89	Body	MOST system analysis	●	●	●	●	○	○	○
Z Reihe	Z4 E89	Body	MRS/AB Airbag/ACSM	●	●	●	●	●	○	●
Z Reihe	Z4 E89	Body	PDC Park Distance Control	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	RAD Radio	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	RAD2-B0 User interface	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	RAD2-GW Gateway	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	RLSS Rain/light solar sensor	●	●	●	●	●	○	○
Z Reihe	Z4 E89	Body	SDARS Satellite tuner	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	SINE Siren and tilt sensor	●	●	●	●	●	○	○
Z Reihe	Z4 E89	Body	SMFA Seat module, driver	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	TCU Telematic Control Unit	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	ULF Universal charging and hands-free facility	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	ULF-SBX Interface box	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	●
Z Reihe	Z4 E89	Body	VM Video Module	●	●	●	●	●	●	●
1 Series	F20	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
1 Series	F20	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
1 Series	F20	Drive	EGS transmission management	●	●	●	●	●	●	○
1 Series	F20	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
1 Series	F20	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
1 Series	F20	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
1 Series	F20	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
1 Series	F20	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
1 Series	F20	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
1 Series	F20	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
1 Series	F20	Body	AHM Trailer module	●	●	●	●	●	●	○
1 Series	F20	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
1 Series	F20	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
1 Series	F20	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
1 Series	F20	Body	CIC Car Information Computer	●	●	●	●	●	●	○
1 Series	F20	Body	CID Central information display	●	●	●	●	●	●	○
1 Series	F20	Body	CON Controller	●	●	●	●	●	●	○
1 Series	F20	Body	DVDC DVD Changer	●	●	●	●	●	●	○
1 Series	F20	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
1 Series	F20	Body	FEM Front electronic module	●	●	●	●	●	●	○
1 Series	F20	Body	FLA High Beam Assist	●	●	●	●	●	●	○
1 Series	F20	Body	FZD Function centre, roof	●	●	●	●	●	●	○
1 Series	F20	Body	ICM Integrated Chassis Management	●	●	●	●	●	●	○
1 Series	F20	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
1 Series	F20	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
1 Series	F20	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
1 Series	F20	Body	PDC Park distance control	●	●	●	●	●	●	○
1 Series	F20	Body	PMA Parking assistant	●	●	●	●	●	●	○
1 Series	F20	Body	RAD Radio	●	●	●	●	●	●	○
1 Series	F20	Body	REM Rear electronic module	●	●	●	●	●	●	○
1 Series	F20	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	F20	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
1 Series	F20	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
1 Series	F20	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
1 Series	F20	Body	SWW Lane change warning	●	●	●	●	●	●	○
1 Series	F20	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
1 Series	F20	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
3 Series	F30	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
3 Series	F30	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
3 Series	F30	Drive	EGS transmission management	●	●	●	●	●	●	○
3 Series	F30	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
3 Series	F30	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
3 Series	F30	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
3 Series	F30	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
3 Series	F30	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
3 Series	F30	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
3 Series	F30	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
3 Series	F30	Body	AHM Trailer module	●	●	●	●	●	●	○
3 Series	F30	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
3 Series	F30	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
3 Series	F30	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
3 Series	F30	Body	CID Central information display	●	●	●	●	●	●	○
3 Series	F30	Body	CON Controller	●	●	●	●	●	●	○
3 Series	F30	Body	DVDC DVD Changer	●	●	●	●	●	●	○
3 Series	F30	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
3 Series	F30	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
3 Series	F30	Body	EME Electric machine electronics	●	●	●	●	●	●	○
3 Series	F30	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
3 Series	F30	Body	FEM Front electronic module	●	●	●	●	●	●	○
3 Series	F30	Body	FLA High Beam Assist	●	●	●	●	●	●	○
3 Series	F30	Body	FZD Function centre, roof	●	●	●	●	●	●	○
3 Series	F30	Body	ICM Integrated Chassis Management	●	●	●	●	●	●	○
3 Series	F30	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
3 Series	F30	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
3 Series	F30	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
3 Series	F30	Body	PDC Park distance control	●	●	●	●	●	●	○
3 Series	F30	Body	PMA Parking assistant	●	●	●	●	●	●	○
3 Series	F30	Body	RAD Radio	●	●	●	●	●	●	○
3 Series	F30	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
3 Series	F30	Body	REM Rear electronic module	●	●	●	●	●	●	○
3 Series	F30	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
3 Series	F30	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
3 Series	F30	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
3 Series	F30	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
3 Series	F30	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
3 Series	F30	Body	SWW Lane change warning	●	●	●	●	●	●	○
3 Series	F30	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F30	Body	TRSVc allround-view camera	●	●	●	●	●	●	○
3 Series	F30	Body	VM Video Module	●	●	●	●	●	●	○
3 Series	F30	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
5 Series	F07	Drive	CAS Car Access System	●	●	●	●	●	●	○
5 Series	F07	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
5 Series	F07	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
5 Series	F07	Drive	EGS transmission management	●	●	●	●	●	●	○
5 Series	F07	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
5 Series	F07	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
5 Series	F07	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
5 Series	F07	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
5 Series	F07	Chassis	EMF Parking brake	●	●	●	●	●	●	○
5 Series	F07	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
5 Series	F07	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○
5 Series	F07	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
5 Series	F07	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
5 Series	F07	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
5 Series	F07	Body	AHM Trailer module	●	●	●	●	●	●	○
5 Series	F07	Body	AL active steering	●	●	●	●	●	●	○
5 Series	F07	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
5 Series	F07	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
5 Series	F07	Body	CID Central information display	●	●	●	●	●	●	○
5 Series	F07	Body	CON Controller	●	●	●	●	●	●	○
5 Series	F07	Body	DVDC DVD Changer	●	●	●	●	●	●	○
5 Series	F07	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
5 Series	F07	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
5 Series	F07	Body	FD Rear-compartment display	●	●	●	●	●	●	○
5 Series	F07	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
5 Series	F07	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
5 Series	F07	Body	FLA High Beam Assist	●	●	●	●	●	●	○
5 Series	F07	Body	FRM Footwell module	●	●	●	●	●	●	○
5 Series	F07	Body	FZD Function centre, roof	●	●	●	●	●	●	○
5 Series	F07	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
5 Series	F07	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
5 Series	F07	Body	HUD Head-Up Display	●	●	●	●	●	●	○
5 Series	F07	Body	ICM Integrated Chassis Management	●	●	●	●	●	●	○
5 Series	F07	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
5 Series	F07	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
5 Series	F07	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
5 Series	F07	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
5 Series	F07	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
5 Series	F07	Body	PDC Park Distance Control	●	●	●	●	●	●	○
5 Series	F07	Body	RAD Radio	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F07	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
5 Series	F07	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
5 Series	F07	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
5 Series	F07	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
5 Series	F07	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
5 Series	F07	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
5 Series	F07	Body	SVT Servotronic	●	●	●	●	●	●	○
5 Series	F07	Body	SWW Lane change warning	●	●	●	●	●	●	○
5 Series	F07	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
5 Series	F07	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
5 Series	F07	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
5 Series	F07	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	○
5 Series	F07	Body	VM Video Module	●	●	●	●	●	●	○
5 Series	F07	Body	VSW video switch	●	●	●	●	●	●	○
5 Series	F07	Body	VTG Transfer case	●	●	●	●	●	●	○
5 Series	F07	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
5 Series	F07	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	CAS Car Access System	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	EGS transmission management	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
5 Series	F10/F11	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	AL active steering	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EMF Parking brake	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
5 Series	F10/F11	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
5 Series	F10/F11	Body	AHM Trailer module	●	●	●	●	●	●	○
5 Series	F10/F11	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ASD Active Sound Design	●	●	●	●	●	●	○
5 Series	F10/F11	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
5 Series	F10/F11	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
5 Series	F10/F11	Body	CIC Car Information Computer	●	●	●	●	●	●	○
5 Series	F10/F11	Body	CID Central Information Display	●	●	●	●	●	●	○
5 Series	F10/F11	Body	CON Controller	●	●	●	●	●	●	○
5 Series	F10/F11	Body	DVDC DVD Changer	●	●	●	●	●	●	○
5 Series	F10/F11	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F10/F11	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
5 Series	F10/F11	Body	EME Electric machine electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FD Rear-compartment display	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FLA High Beam Assist	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FRM Footwell module	●	●	●	●	●	●	○
5 Series	F10/F11	Body	FZD Function centre, roof	●	●	●	●	●	●	○
5 Series	F10/F11	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○
5 Series	F10/F11	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
5 Series	F10/F11	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
5 Series	F10/F11	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
5 Series	F10/F11	Body	HUD Head-Up Display	●	●	●	●	●	●	○
5 Series	F10/F11	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
5 Series	F10/F11	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
5 Series	F10/F11	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
5 Series	F10/F11	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Body	PDC Park Distance Control	●	●	●	●	●	●	○
5 Series	F10/F11	Body	PMA Parking assistant	●	●	●	●	●	●	○
5 Series	F10/F11	Body	RAD Radio	●	●	●	●	●	●	○
5 Series	F10/F11	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
5 Series	F10/F11	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SVT Servotronic	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SWW Lane change warning	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SCR Selective Catalytic Reduction	●	●	●	●	●	●	○
5 Series	F10/F11	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	○
5 Series	F10/F11	Body	VM Video Module	●	●	●	●	●	●	○
5 Series	F10/F11	Body	VSW video switch	●	●	●	●	●	●	○
5 Series	F10/F11	Body	VTG Transfer case	●	●	●	●	●	●	○
5 Series	F10/F11	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
5 Series	F10/F11	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
5 Series	F18	Drive	CAS Car Access System	●	●	●	●	●	●	○
5 Series	F18	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
5 Series	F18	Drive	EGS transmission management	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F18	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
5 Series	F18	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
5 Series	F18	Chassis	AL active steering	●	●	●	●	●	●	○
5 Series	F18	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○
5 Series	F18	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
5 Series	F18	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
5 Series	F18	Chassis	EMF Parking brake	●	●	●	●	●	●	○
5 Series	F18	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
5 Series	F18	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
5 Series	F18	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
5 Series	F18	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
5 Series	F18	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
5 Series	F18	Body	AHM Trailer module	●	●	●	●	●	●	○
5 Series	F18	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
5 Series	F18	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
5 Series	F18	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
5 Series	F18	Body	CID Central Information Display	●	●	●	●	●	●	○
5 Series	F18	Body	CON Controller	●	●	●	●	●	●	○
5 Series	F18	Body	DVDC DVD Changer	●	●	●	●	●	●	○
5 Series	F18	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
5 Series	F18	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
5 Series	F18	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
5 Series	F18	Body	FD Rear-compartment display	●	●	●	●	●	●	○
5 Series	F18	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
5 Series	F18	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
5 Series	F18	Body	FLA High Beam Assist	●	●	●	●	●	●	○
5 Series	F18	Body	FRM Footwell module	●	●	●	●	●	●	○
5 Series	F18	Body	FZD Function centre, roof	●	●	●	●	●	●	○
5 Series	F18	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
5 Series	F18	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
5 Series	F18	Body	HUD Head-Up Display	●	●	●	●	●	●	○
5 Series	F18	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
5 Series	F18	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
5 Series	F18	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
5 Series	F18	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
5 Series	F18	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
5 Series	F18	Body	PDC Park Distance Control	●	●	●	●	●	●	○
5 Series	F18	Body	PMA Parking assistant	●	●	●	●	●	●	○
5 Series	F18	Body	RAD Radio	●	●	●	●	●	●	○
5 Series	F18	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
5 Series	F18	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
5 Series	F18	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
5 Series	F18	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F18	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
5 Series	F18	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
5 Series	F18	Body	SWW Lane change warning	●	●	●	●	●	●	○
5 Series	F18	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
5 Series	F18	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
5 Series	F18	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
5 Series	F18	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	○
5 Series	F18	Body	VM Video Module	●	●	●	●	●	●	○
5 Series	F18	Body	VSW video switch	●	●	●	●	●	●	○
5 Series	F18	Body	VTG Transfer case	●	●	●	●	●	●	○
5 Series	F18	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
5 Series	F18	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	CAS Car Access System	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	EGS transmission management	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
6 Series	F12/F13	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	AL active steering	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EMF Parking brake	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
6 Series	F12/F13	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
6 Series	F12/F13	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
6 Series	F12/F13	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	AHM Trailer module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
6 Series	F12/F13	Body	ASD Active Sound Design	●	●	●	●	●	●	○
6 Series	F12/F13	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
6 Series	F12/F13	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
6 Series	F12/F13	Body	CID Central Information Display	●	●	●	●	●	●	○
6 Series	F12/F13	Body	CON Controller	●	●	●	●	●	●	○
6 Series	F12/F13	Body	CVM Convertible top module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	DVDC DVD Changer	●	●	●	●	●	●	○
6 Series	F12/F13	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
6 Series	F12/F13	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FD Rear-compartment display	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FLA High Beam Assist	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FRM Footwell module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	FZD Function centre, roof	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F12/F13	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
6 Series	F12/F13	Body	HUD Head-Up Display	●	●	●	●	●	●	○
6 Series	F12/F13	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
6 Series	F12/F13	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
6 Series	F12/F13	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
6 Series	F12/F13	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
6 Series	F12/F13	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
6 Series	F12/F13	Body	PDC Park Distance Control	●	●	●	●	●	●	○
6 Series	F12/F13	Body	PMA Parking assistant	●	●	●	●	●	●	○
6 Series	F12/F13	Body	RAD Radio	●	●	●	●	●	●	○
6 Series	F12/F13	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SVT Servotronic	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SWW Lane change warning	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
6 Series	F12/F13	Body	TRSVL allround-view camera	●	●	●	●	●	●	○
6 Series	F12/F13	Body	VM Video Module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	VSW video switch	●	●	●	●	●	●	○
6 Series	F12/F13	Body	VTG Transfer case	●	●	●	●	●	●	○
6 Series	F12/F13	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
6 Series	F12/F13	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	CAS Car Access System	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	EGS transmission management	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EMF Parking brake	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Chassis	AL active steering	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	F01/F02/F04	Body	CIC Car Information Computer	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FZD Function centre, roof	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	PDC Park Distance Control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FRM Footwell module	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ZGM Central Gateway Control Module	●	●	●	●	●	○	○
7 Series	F01/F02/F04	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CON Controller	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CID Central Information Display	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HUD Head-Up Display	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	●
7 Series	F01/F02/F04	Body	FLA High Beam Assist	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	DVDC DVD Changer	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VSW video switch	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FD Rear-compartment display	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	AHM Trailer module	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	EME Electric machine electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	GZAL Targeted illumination, left	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	GZAR Targeted illumination, right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	LHML LED main light module, left	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	LHMR LED main light module, right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RAD Radio	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SVT Servotronic	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	SWW Lane change warning	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	STML Headlight driver module, left	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	F01/F02/F04	Body	STMR Headlight driver module, right	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	TBX Touchbox	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VM Video Module	●	●	●	●	●	●	○
7 Series	F01/F02/F04	Body	VTG Transfer case	●	●	●	●	●	●	○
X3 Series	F25	Drive	CAS Car Access System	●	●	●	●	●	●	○
X3 Series	F25	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
X3 Series	F25	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
X3 Series	F25	Drive	EGS transmission management	●	●	●	●	●	●	○
X3 Series	F25	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
X3 Series	F25	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
X3 Series	F25	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
X3 Series	F25	Chassis	EMF Parking brake	●	●	●	●	●	●	○
X3 Series	F25	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
X3 Series	F25	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
X3 Series	F25	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
X3 Series	F25	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
X3 Series	F25	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
X3 Series	F25	Body	AHM Trailer module	●	●	●	●	●	●	○
X3 Series	F25	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
X3 Series	F25	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
X3 Series	F25	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
X3 Series	F25	Body	CID Central Information Display	●	●	●	●	●	●	○
X3 Series	F25	Body	CON Controller	●	●	●	●	●	●	○
X3 Series	F25	Body	DVDC DVD Changer	●	●	●	●	●	●	○
X3 Series	F25	Body	FLA High Beam Assist	●	●	●	●	●	●	○
X3 Series	F25	Body	FRM Footwell module	●	●	●	●	●	●	○
X3 Series	F25	Body	FZD Function centre, roof	●	●	●	●	●	●	○
X3 Series	F25	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○
X3 Series	F25	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
X3 Series	F25	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
X3 Series	F25	Body	HUD Head-Up Display	●	●	●	●	●	●	○
X3 Series	F25	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
X3 Series	F25	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
X3 Series	F25	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
X3 Series	F25	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
X3 Series	F25	Body	PDC Park Distance Control	●	●	●	●	●	●	○
X3 Series	F25	Body	RAD Radio	●	●	●	●	●	●	○
X3 Series	F25	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
X3 Series	F25	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
X3 Series	F25	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
X3 Series	F25	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
X3 Series	F25	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
X3 Series	F25	Body	SWW Lane change warning	●	●	●	●	●	●	○
X3 Series	F25	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X3 Series	F25	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
X3 Series	F25	Body	VM Video Module	●	●	●	●	●	●	○
X3 Series	F25	Body	VTG Transfer case	●	●	●	●	●	●	○
X3 Series	F25	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
X6 Series	E72	Drive	CAS Car Access System	●	●	●	●	●	●	○
X6 Series	E72	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
X6 Series	E72	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
X6 Series	E72	Drive	EMPI Hybrid oil-pump activation	●	●	●	●	●	●	○
X6 Series	E72	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
X6 Series	E72	Drive	TCM Hybrid-transmission control	●	●	●	●	●	●	○
X6 Series	E72	Drive	VTG Transfer case	●	●	●	●	●	●	○
X6 Series	E72	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
X6 Series	E72	Chassis	DSM Hybrid parking lock	●	●	●	●	●	●	○
X6 Series	E72	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
X6 Series	E72	Chassis	EMF Parking brake	●	●	●	●	●	●	○
X6 Series	E72	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
X6 Series	E72	Chassis	RDC Tyre pressure control	●	●	●	●	●	●	○
X6 Series	E72	Chassis	SBA Hybrid brake-actuation changeover	●	●	●	●	●	●	○
X6 Series	E72	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
X6 Series	E72	Body	AHM Trailer module	●	●	●	●	●	●	○
X6 Series	E72	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
X6 Series	E72	Body	APM Hybrid DC/DC converter	●	●	●	●	●	●	○
X6 Series	E72	Body	BCM Battery check module	●	●	●	●	●	●	○
X6 Series	E72	Body	CA Comfort access system	●	●	●	●	●	●	○
X6 Series	E72	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
X6 Series	E72	Body	CDC CD Changer	●	●	●	●	●	●	○
X6 Series	E72	Body	CCC-GW Gateway	●	●	●	●	●	●	○
X6 Series	E72	Body	CID Central Information Display	●	●	●	●	●	●	○
X6 Series	E72	Body	CON Controller	●	●	●	●	●	●	○
X6 Series	E72	Body	DVDC DVD Changer	●	●	●	●	●	●	○
X6 Series	E72	Body	EKK Electric A/C compressor	●	●	●	●	●	●	○
X6 Series	E72	Body	FD Rear-compartment display	●	●	●	●	●	●	○
X6 Series	E72	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
X6 Series	E72	Body	FLA High Beam Assist	●	●	●	●	●	●	○
X6 Series	E72	Body	FRM2 Footwell module 2	●	●	●	●	●	●	○
X6 Series	E72	Body	FZD Function centre, roof	●	●	●	●	●	●	○
X6 Series	E72	Body	HCP Hybrid master control unit	●	●	●	●	●	●	○
X6 Series	E72	Body	HIM Hybrid Interface Module	●	●	●	●	●	●	○
X6 Series	E72	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
X6 Series	E72	Body	HUD Head-Up Display	●	●	●	●	●	●	○
X6 Series	E72	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
X6 Series	E72	Body	JBE2 Junction Box electronics	●	●	●	●	●	●	○
X6 Series	E72	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
X6 Series	E72	Body	M-ASK-BO User interface	●	●	●	●	●	●	○
X6 Series	E72	Body	MCPA Hybrid electric-motor control 1	●	●	●	●	●	●	○
X6 Series	E72	Body	MCPB Hybrid electric-motor control 2	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X6 Series	E72	Body	PDC Park Distance Control	●	●	●	●	●	●	○
X6 Series	E72	Body	RLSS Rain/light solar sensor	●	●	●	●	●	●	○
X6 Series	E72	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
X6 Series	E72	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
X6 Series	E72	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
X6 Series	E72	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
X6 Series	E72	Body	TFE Hybrid pressure-tank electronics	●	●	●	●	●	●	○
X6 Series	E72	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
X6 Series	E72	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
X6 Series	E72	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	○
X6 Series	E72	Body	VM Video Module	●	●	●	●	●	●	○
X1 Series	E84	Drive	CAS Car Access System	●	●	●	●	●	●	○
X1 Series	E84	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
X1 Series	E84	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
X1 Series	E84	Drive	EGS transmission management	●	●	●	●	●	●	○
X1 Series	E84	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
X1 Series	E84	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
X1 Series	E84	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
X1 Series	E84	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
X1 Series	E84	Body	AHM Trailer module	●	●	●	●	●	●	○
X1 Series	E84	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
X1 Series	E84	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
X1 Series	E84	Body	CID Central Information Display	●	●	●	●	●	●	○
X1 Series	E84	Body	CON Controller	●	●	●	●	●	●	○
X1 Series	E84	Body	FLA High Beam Assist	●	●	●	●	●	●	○
X1 Series	E84	Body	FRM Footwell module	●	●	●	●	●	●	○
X1 Series	E84	Body	FZD Function centre, roof	●	●	●	●	●	●	○
X1 Series	E84	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
X1 Series	E84	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
X1 Series	E84	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
X1 Series	E84	Body	PDC Park Distance Control	●	●	●	●	●	●	○
X1 Series	E84	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
X1 Series	E84	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
X1 Series	E84	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
X1 Series	E84	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
X1 Series	E84	Body	VM Video Module	●	●	●	●	●	●	○
X1 Series	E84	Body	VTG Transfer case	●	●	●	●	●	●	○
X1 Series	E84	Body	CA Comfort access system	●	●	●	●	●	●	○
X1 Series	E84	Body	CDC CD Changer	●	●	●	●	●	●	○
X1 Series	E84	Body	CHAMP-BO User interface	●	●	●	●	●	●	○
X1 Series	E84	Body	CCC-GW Gateway	●	●	●	●	●	●	○
X1 Series	E84	Body	DAB Digital tuner	●	●	●	●	●	●	○
X1 Series	E84	Body	DWA anti-theft alarm system	●	●	●	●	●	●	○
X1 Series	E84	Body	RLSS Rain/light solar sensor	●	●	●	●	●	●	○
X1 Series	E84	Body	SHD Sliding/tilting sunroof	●	●	●	●	●	●	○
X1 Series	E84	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X1 Series	E84	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
X1 Series	E84	Body	ULF-SBX-H Interface box High	●	●	●	●	●	●	○
2 Series	F22	Drive	CAS Car Access System	●	●	●	●	●	●	○
2 Series	F22	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
2 Series	F22	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
2 Series	F22	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
2 Series	F22	Drive	EGS transmission management	●	●	●	●	●	●	○
2 Series	F22	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
2 Series	F22	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
2 Series	F22	Chassis	AL active steering	●	●	●	●	●	●	○
2 Series	F22	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
2 Series	F22	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
2 Series	F22	Chassis	EMF Parking brake	●	●	●	●	●	●	○
2 Series	F22	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
2 Series	F22	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
2 Series	F22	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
2 Series	F22	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	●	○
2 Series	F22	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
2 Series	F22	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
2 Series	F22	Body	AHM Trailer module	●	●	●	●	●	●	○
2 Series	F22	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
2 Series	F22	Body	ASD Active Sound Design	●	●	●	●	●	●	○
2 Series	F22	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
2 Series	F22	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
2 Series	F22	Body	CIC Car Information Computer	●	●	●	●	●	●	○
2 Series	F22	Body	CON Controller	●	●	●	●	●	●	○
2 Series	F22	Body	CVM Convertible top module	●	●	●	●	●	●	○
2 Series	F22	Body	DVDC DVD Changer	●	●	●	●	●	●	○
2 Series	F22	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
2 Series	F22	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
2 Series	F22	Body	EME Electric machine electronics	●	●	●	●	●	●	○
2 Series	F22	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
2 Series	F22	Body	FLA High Beam Assist	●	●	●	●	●	●	○
2 Series	F22	Body	FRM Footwell module	●	●	●	●	●	●	○
2 Series	F22	Body	FZD Function centre, roof	●	●	●	●	●	●	○
2 Series	F22	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○
2 Series	F22	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
2 Series	F22	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
2 Series	F22	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
2 Series	F22	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
2 Series	F22	Body	PDC Park distance control	●	●	●	●	●	●	○
2 Series	F22	Body	PMA Parking assistant	●	●	●	●	●	●	○
2 Series	F22	Body	RAD Radio	●	●	●	●	●	●	○
2 Series	F22	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
2 Series	F22	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
2 Series	F22	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F22	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
2 Series	F22	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
2 Series	F22	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
2 Series	F22	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
2 Series	F22	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
2 Series	F22	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
2 Series	F22	Body	SVT Servotronic	●	●	●	●	●	●	○
2 Series	F22	Body	SWW Lane change warning	●	●	●	●	●	●	○
2 Series	F22	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
2 Series	F22	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
2 Series	F22	Body	VM Video Module	●	●	●	●	●	●	○
2 Series	F22	Body	VTG Transfer case	●	●	●	●	●	●	○
2 Series	F22	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
3 Series	F34	Drive	CAS Car Access System	●	●	●	●	●	●	○
3 Series	F34	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
3 Series	F34	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
3 Series	F34	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
3 Series	F34	Drive	EGS transmission management	●	●	●	●	●	●	○
3 Series	F34	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
3 Series	F34	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
3 Series	F34	Chassis	AL active steering	●	●	●	●	●	●	○
3 Series	F34	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
3 Series	F34	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
3 Series	F34	Chassis	EMF Parking brake	●	●	●	●	●	●	○
3 Series	F34	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
3 Series	F34	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
3 Series	F34	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
3 Series	F34	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	●	○
3 Series	F34	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
3 Series	F34	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
3 Series	F34	Body	AHM Trailer module	●	●	●	●	●	●	○
3 Series	F34	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
3 Series	F34	Body	ASD Active Sound Design	●	●	●	●	●	●	○
3 Series	F34	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
3 Series	F34	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
3 Series	F34	Body	CIC Car Information Computer	●	●	●	●	●	●	○
3 Series	F34	Body	CON Controller	●	●	●	●	●	●	○
3 Series	F34	Body	CVM Convertible top module	●	●	●	●	●	●	○
3 Series	F34	Body	DVDC DVD Changer	●	●	●	●	●	●	○
3 Series	F34	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
3 Series	F34	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
3 Series	F34	Body	EME Electric machine electronics	●	●	●	●	●	●	○
3 Series	F34	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
3 Series	F34	Body	FLA High Beam Assist	●	●	●	●	●	●	○
3 Series	F34	Body	FRM Footwell module	●	●	●	●	●	●	○
3 Series	F34	Body	FZD Function centre, roof	●	●	●	●	●	●	○
3 Series	F34	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F34	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
3 Series	F34	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
3 Series	F34	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
3 Series	F34	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
3 Series	F34	Body	PDC Park distance control	●	●	●	●	●	●	○
3 Series	F34	Body	PMA Parking assistant	●	●	●	●	●	●	○
3 Series	F34	Body	RAD Radio	●	●	●	●	●	●	○
3 Series	F34	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
3 Series	F34	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
3 Series	F34	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○
3 Series	F34	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
3 Series	F34	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
3 Series	F34	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
3 Series	F34	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
3 Series	F34	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
3 Series	F34	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
3 Series	F34	Body	SVT Servotronic	●	●	●	●	●	●	○
3 Series	F34	Body	SWW Lane change warning	●	●	●	●	●	●	○
3 Series	F34	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
3 Series	F34	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
3 Series	F34	Body	VM Video Module	●	●	●	●	●	●	○
3 Series	F34	Body	VTG Transfer case	●	●	●	●	●	●	○
3 Series	F34	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	CAS Car Access System	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	EGS transmission management	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
4 Series	F32/F33	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	AL active steering	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EMF Parking brake	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
4 Series	F32/F33	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	●	○
4 Series	F32/F33	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
4 Series	F32/F33	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
4 Series	F32/F33	Body	AHM Trailer module	●	●	●	●	●	●	○
4 Series	F32/F33	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
4 Series	F32/F33	Body	ASD Active Sound Design	●	●	●	●	●	●	○
4 Series	F32/F33	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
4 Series	F32/F33	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
4 Series	F32/F33	Body	CIC Car Information Computer	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
4 Series	F32/F33	Body	CON Controller	●	●	●	●	●	●	○
4 Series	F32/F33	Body	CVM Convertible top module	●	●	●	●	●	●	○
4 Series	F32/F33	Body	DVDC DVD Changer	●	●	●	●	●	●	○
4 Series	F32/F33	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
4 Series	F32/F33	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
4 Series	F32/F33	Body	EME Electric machine electronics	●	●	●	●	●	●	○
4 Series	F32/F33	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
4 Series	F32/F33	Body	FLA High Beam Assist	●	●	●	●	●	●	○
4 Series	F32/F33	Body	FRM Footwell module	●	●	●	●	●	●	○
4 Series	F32/F33	Body	FZD Function centre,roof	●	●	●	●	●	●	○
4 Series	F32/F33	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○
4 Series	F32/F33	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
4 Series	F32/F33	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
4 Series	F32/F33	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
4 Series	F32/F33	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
4 Series	F32/F33	Body	PDC Park distance control	●	●	●	●	●	●	○
4 Series	F32/F33	Body	PMA Parking assistant	●	●	●	●	●	●	○
4 Series	F32/F33	Body	RAD Radio	●	●	●	●	●	●	○
4 Series	F32/F33	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SVT Servotronic	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SWW Lane change warning	●	●	●	●	●	●	○
4 Series	F32/F33	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
4 Series	F32/F33	Body	TR SVC allround-view camera	●	●	●	●	●	●	○
4 Series	F32/F33	Body	VM Video Module	●	●	●	●	●	●	○
4 Series	F32/F33	Body	VTG Transfer case	●	●	●	●	●	●	○
4 Series	F32/F33	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
6 Series	F06	Drive	CAS Car Access System	●	●	●	●	●	●	○
6 Series	F06	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
6 Series	F06	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
6 Series	F06	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
6 Series	F06	Drive	EGS transmission management	●	●	●	●	●	●	○
6 Series	F06	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
6 Series	F06	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
6 Series	F06	Chassis	AL active steering	●	●	●	●	●	●	○
6 Series	F06	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSHL Damper satellite, rear left	●	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSHR Damper satellite, rear right	●	●	●	●	●	●	○
6 Series	F06	Chassis	EDCSVL Damper satellite, front left	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F06	Chassis	EDCSVR Damper satellite, front right	●	●	●	●	●	●	○
6 Series	F06	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
6 Series	F06	Chassis	EMF Parking brake	●	●	●	●	●	●	○
6 Series	F06	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
6 Series	F06	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
6 Series	F06	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
6 Series	F06	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	●	○
6 Series	F06	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
6 Series	F06	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
6 Series	F06	Body	AHM Trailer module	●	●	●	●	●	●	○
6 Series	F06	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
6 Series	F06	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
6 Series	F06	Body	ASD Active Sound Design	●	●	●	●	●	●	○
6 Series	F06	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
6 Series	F06	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
6 Series	F06	Body	CIC Car Information Computer	●	●	●	●	●	●	○
6 Series	F06	Body	CID Central information display	●	●	●	●	●	●	○
6 Series	F06	Body	CON Controller	●	●	●	●	●	●	○
6 Series	F06	Body	CVM Convertible top module	●	●	●	●	●	●	○
6 Series	F06	Body	DVDC DVD Changer	●	●	●	●	●	●	○
6 Series	F06	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
6 Series	F06	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
6 Series	F06	Body	EME Electric machine electronics	●	●	●	●	●	●	○
6 Series	F06	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
6 Series	F06	Body	FCON Rear compartment controller	●	●	●	●	●	●	○
6 Series	F06	Body	FD Rear-compartment display	●	●	●	●	●	●	○
6 Series	F06	Body	FD2 Rear-compartment display 2	●	●	●	●	●	●	○
6 Series	F06	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
6 Series	F06	Body	FLA High Beam Assist	●	●	●	●	●	●	○
6 Series	F06	Body	FRM Footwell module	●	●	●	●	●	●	○
6 Series	F06	Body	FZD Function centre, roof	●	●	●	●	●	●	○
6 Series	F06	Body	GHAS Regulated differential lock	●	●	●	●	●	●	○
6 Series	F06	Body	HKA Rear-cabin automatic A/C	●	●	●	●	●	●	○
6 Series	F06	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
6 Series	F06	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
6 Series	F06	Body	HSR Rear-axle slip-angle control	●	●	●	●	●	●	○
6 Series	F06	Body	HUD Head-Up Display	●	●	●	●	●	●	○
6 Series	F06	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
6 Series	F06	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
6 Series	F06	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
6 Series	F06	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○
6 Series	F06	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
6 Series	F06	Body	PDC Park distance control	●	●	●	●	●	●	○
6 Series	F06	Body	PMA Parking assistant	●	●	●	●	●	●	○
6 Series	F06	Body	RAD Radio	●	●	●	●	●	●	○
6 Series	F06	Body	RDC Tyre pressure control	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F06	Body	REM Rear electronic module	●	●	●	●	●	●	○
6 Series	F06	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
6 Series	F06	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
6 Series	F06	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
6 Series	F06	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○
6 Series	F06	Body	SINE Siren and tilt sensor	●	●	●	●	●	●	○
6 Series	F06	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
6 Series	F06	Body	SMBFH Seat module, passenger's side, rear	●	●	●	●	●	●	○
6 Series	F06	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
6 Series	F06	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
6 Series	F06	Body	SMFAH Seat module, driver's side, rear	●	●	●	●	●	●	○
6 Series	F06	Body	SVT Servotronic	●	●	●	●	●	●	○
6 Series	F06	Body	SWW Lane change warning	●	●	●	●	●	●	○
6 Series	F06	Body	SZL Switch centre, steering column	●	●	●	●	●	●	○
6 Series	F06	Body	SDARS Satellite tuner	●	●	●	●	●	●	○
6 Series	F06	Body	TRSVC allround-view camera	●	●	●	●	●	●	○
6 Series	F06	Body	TCU Telematic Control Unit	●	●	●	●	●	●	○
6 Series	F06	Body	ULF-SBX Interface box	●	●	●	●	●	●	○
6 Series	F06	Body	ULF-SBX-H Interface box high	●	●	●	●	●	●	○
6 Series	F06	Body	VM Video Module	●	●	●	●	●	●	○
6 Series	F06	Body	VSW video switch	●	●	●	●	●	●	○
6 Series	F06	Body	VTG Transfer case	●	●	●	●	●	●	○
6 Series	F06	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
I Series	I00/I12	Drive	CAS Car Access System	●	●	●	●	●	●	○
I Series	I00/I12	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
I Series	I00/I12	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
I Series	I00/I12	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
I Series	I00/I12	Drive	EGS transmission management	●	●	●	●	●	●	○
I Series	I00/I12	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
I Series	I00/I12	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
I Series	I00/I12	Chassis	EMF Parking brake	●	●	●	●	●	●	○
I Series	I00/I12	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
I Series	I00/I12	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
I Series	I00/I12	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
I Series	I00/I12	Body	AMPT Top Hi-Fi amplifier	●	●	●	●	●	●	○
I Series	I00/I12	Body	ASD Active Sound Design	●	●	●	●	●	●	○
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
I Series	I00/I12	Body	CIC Car Information Computer	●	●	●	●	●	●	○
I Series	I00/I12	Body	CON Controller	●	●	●	●	●	●	○
I Series	I00/I12	Body	EME Electric machine electronics	●	●	●	●	●	●	○
I Series	I00/I12	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
I Series	I00/I12	Body	FZD Function centre, roof	●	●	●	●	●	●	○
I Series	I00/I12	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
I Series	I00/I12	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
I Series	I00/I12	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
I Series	I00/I12	Body	PMA Parking assistant	●	●	●	●	●	●	○
I Series	I00/I12	Body	RAD Radio	●	●	●	●	●	●	○
I Series	I00/I12	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
I Series	I00/I12	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○
X Series	X5 F15	Drive	CAS Car Access System	●	●	●	●	●	●	○
X Series	X5 F15	Drive	DDE Diesel Electronics	●	●	●	●	●	●	○
X Series	X5 F15	Drive	DME Digital Motor Electronics	●	●	●	●	●	●	○
X Series	X5 F15	Drive	DME Digital Motor Electronics 2	●	●	●	●	●	●	○
X Series	X5 F15	Drive	EGS transmission management	●	●	●	●	●	●	○
X Series	X5 F15	Drive	EKPS Fuel-pump control	●	●	●	●	●	●	○
X Series	X5 F15	Drive	GWS Gear selector switch	●	●	●	●	●	●	○
X Series	X5 F15	Drive	QMVH Lateral-moment distribution, rear axle	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	AL active steering	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	DSC Dynamic Stability Control	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	EHC Electronic Ride-Height Control	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	EMF Parking brake	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	EPS Electronic Power Steering	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	ICM Integrated Chassis Management	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	VDM Vertical Dynamics Management	●	●	●	●	●	●	○
X Series	X5 F15	Chassis	VDM2 Vertical dynamics management	●	●	●	●	●	●	○
X Series	X5 F15	Body	ACC Active Cruise Control	●	●	●	●	●	●	○
X Series	X5 F15	Body	ACSM Crash Safety Module	●	●	●	●	●	●	○
X Series	X5 F15	Body	AHM Trailer module	●	●	●	●	●	●	○
X Series	X5 F15	Body	AMPH Hi-Fi amplifier	●	●	●	●	●	●	○
X Series	X5 F15	Body	ASD Active Sound Design	●	●	●	●	●	●	○
X Series	X5 F15	Body	CBX-ECALL Combox emergency call	●	●	●	●	●	●	○
X Series	X5 F15	Body	CBX-MEDIA Combox Multimedia	●	●	●	●	●	●	○
X Series	X5 F15	Body	CIC Car Information Computer	●	●	●	●	●	●	○
X Series	X5 F15	Body	CID Central information display	●	●	●	●	●	●	○
X Series	X5 F15	Body	CON Controller	●	●	●	●	●	●	○
X Series	X5 F15	Body	DVDC DVD Changer	●	●	●	●	●	●	○
X Series	X5 F15	Body	EMALI Electric-motor reel, left	●	●	●	●	●	●	○
X Series	X5 F15	Body	EMARE Electric-motor reel, right	●	●	●	●	●	●	○
X Series	X5 F15	Body	EME Electric machine electronics	●	●	●	●	●	●	○
X Series	X5 F15	Body	EME2 Electrical machine electronics	●	●	●	●	●	●	○
X Series	X5 F15	Body	FKA Rear heater/air conditioning	●	●	●	●	●	●	○
X Series	X5 F15	Body	FLA High Beam Assist	●	●	●	●	●	●	○
X Series	X5 F15	Body	FRM Footwell module	●	●	●	●	●	●	○
X Series	X5 F15	Body	FZD Function centre, roof	●	●	●	●	●	●	○
X Series	X5 F15	Body	HKL Automatic luggage compartment lid	●	●	●	●	●	●	○
X Series	X5 F15	Body	HKL Rear-lid lift	●	●	●	●	●	●	○
X Series	X5 F15	Body	HUD Head-Up Display	●	●	●	●	●	●	○
X Series	X5_F15	Body	IHKA Integrated automatic heating/air conditioning	●	●	●	●	●	●	○
X Series	X5 F15	Body	INSTR Instrument cluster	●	●	●	●	●	●	○
X Series	X5 F15	Body	JBE Junction-box electronics	●	●	●	●	●	●	○
X Series	X5 F15	Body	KAFAS Camera-based driver-assistance systems	●	●	●	●	●	●	○

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X5 F15	Body	NVE Night Vision Electronics	●	●	●	●	●	●	○
X Series	X5 F15	Body	PDC Park distance control	●	●	●	●	●	●	○
X Series	X5 F15	Body	PMA Parking assistant	●	●	●	●	●	●	○
X Series	X5 F15	Body	PCU Power Control Unit	●	●	●	●	●	●	○
X Series	X5 F15	Body	RDC Tyre pressure control	●	●	●	●	●	●	○
X Series	X5 F15	Body	RSE Rear Seat Entertainment	●	●	●	●	●	●	○
X Series	X5 F15	Body	SEC Supplementary control unit	●	●	●	●	●	●	○
X Series	X5 F15	Body	SEC2 Supplementary control unit 2	●	●	●	●	●	●	○
X Series	X5 F15	Body	SMBF Seat module, passenger	●	●	●	●	●	●	○
X Series	X5 F15	Body	SME Accumulator-management electronics	●	●	●	●	●	●	○
X Series	X5 F15	Body	SMFA Seat module, driver	●	●	●	●	●	●	○
X Series	X5 F15	Body	SVT Servotronic	●	●	●	●	●	●	○
X Series	X5 F15	Body	SWW Lane change warning	●	●	●	●	●	●	○
X Series	X5 F15	Body	STML Headlight driver module, left	●	●	●	●	●	●	○
X Series	X5 F15	Body	STMR Headlight driver module, right	●	●	●	●	●	●	○
X Series	X5 F15	Body	TRSVc allround-view camera	●	●	●	●	●	●	○
X Series	X5 F15	Body	TBX Touchbox	●	●	●	●	●	●	○
X Series	X5 F15	Body	VM Video Module	●	●	●	●	●	●	○
X Series	X5 F15	Body	VTG Transfer case	●	●	●	●	●	●	○
X Series	X5 F15	Body	ZGM Central Gateway Control Module	●	●	●	●	●	●	○

Service Function List

备注:

- This function is supported. ▲ This function is the new feature in this version.
- This function is not supported.

All functions are available to E/F/I Chassis. In the actual test procedure, different menus will be displayed depending on the model configuration.

Part	Components	Status
Maintenance	CBS functionality, engine oil impaired	▲
Maintenance	CBS reset	●
Maintenance	CBS Reset UDS	▲
Maintenance	CBS vehicle data correction	●
Maintenance	CESG maintenance: FUP check	▲
Maintenance	Charging the battery via diagnostic socket	▲
Maintenance	Deactivation, engine oil	▲
Maintenance	Delete transport mode	▲
Maintenance	Reset engine oil	▲
Maintenance	Reset pre-delivery check	▲
Maintenance	Set rollover protection system in transport mode	▲
Maintenance	Setting the transport mode	▲
Vehicle information	Check Control messages	▲
Vehicle information	correction power supply network identification	▲
Vehicle information	DWA: Alarm activation	▲
Vehicle information	Integration level	▲
Vehicle information	Read Check Control history memory	▲
Vehicle information	Read out check Control message from central fault memory	▲
Vehicle information	Remote door lock activations	▲
Vehicle information	Total counter, convertible top opening time	▲
Body	A/C compressor running-in protection	▲
Body	Activate Bluetooth and emergency call	▲
Body	Activate deactivate test card	▲
Body	Activate radio module	▲
Body	Activate SDARS	▲
Body	Activation of rollover protection	▲
Body	Active backrest width, driver: Initialisation	▲
Body	Active backrest width, front passenger: Initialisation	▲
Body	Add tuner section	▲
Body	All-round vision camera teach-in	●
Body	Analysis for wake-up control units	▲
Body	Assign RHD ID for switch block seat memory	▲
Body	Auxiliary battery and cut-out relay	▲
Body	Register battery replacement	▲
Body	Auxiliary fault lockout	▲
Body	Auxiliary heater: Initialisation of the Telestart transmitter	▲
Body	Auxiliary heater: Resetting fault lockout	▲
Body	Auxiliary heater: System test	▲
Body	Bleed headlight cleaning system	●
Body	Boil-off test	●
Body	Calibrating and 'teaching' system for all-round vision camera	▲
Body	Calibrating the expansion valves of the heat pump circuit	▲
Body	Calibration of body general module	●
Body	Calibration run for flap motors	▲
Body	CESG access to the fuel tank and/or extraction line	▲
Body	CESG delete persistent data	▲
Body	CESG fill level sensors, general	▲
Body	CESG filling/draining pressure accumulator	▲
Body	CESG read/compare mileages	▲
Body	CESG service function, calibration of filling volume detection	▲
Body	CESG service function, slacken feed line	▲
Body	Change personalisation data of remote key	▲
Body	Charge high-voltage battery	▲
Body	CIC: Activate and deactivate test card	▲
Body	Compressor / first start-up	●

Part	Components	Status
Body	Coolant compressor infeed protection	●
Body	Correct M-ASK tuner	●
Body	Correction of undervoltage limits of the auxiliary heater	▲
Body	Country-wide activation of the internal telephone module	▲
Body	Create boot file again	▲
Body	CTM loading aid: Joint switching after repair	▲
Body	CTM: Rear module emergency access	●
Body	Delete the personal profile	▲
Body	Drain or fill the refrigerant circuit of the heat pump	▲
Body	Driver's seat standardisation	●
Body	EMALI: Electric motor initialisation	▲
Body	Enable airbag activation after programming operation	▲
Body	Evaluate closed-circuit current monitoring	▲
Body	Evaluate state of battery charge	▲
Body	Flexible diagnosis module	▲
Body	Floating headlining installation position	▲
Body	Front passenger seat occupancy detection	▲
Body	Front passenger seat, seat standardisation	●
Body	Heating and air conditioning functions: - Newly address the air distribution flap motors	▲
Body	Heating and air conditioning functions: Calibrate selector wheels	▲
Body	Heating and air conditioning functions: Unlocking auxiliary heating	●
Body	Heating and air conditioning system: Potentiometer	●
Body	Heating/air conditioning function: Heater test run	●
Body	High-voltage battery unit: Drain coolant expansion tank	▲
Body	High-voltage battery: Evaluating the battery state of charge	▲
Body	High-voltage electrical system: Locate insulation fault	▲
Body	High-voltage safety: Check	▲
Body	High-voltage safety: Status	▲
Body	HIP module reset	▲
Body	Ignition key: Personalisation number	●
Body	Individual test for aerials in vehicle	▲
Body	Inflation pressure indicator	▲
Body	Initialisation of rain-light-solar-condensation sensor	●
Body	Initialise audio operation at rear	▲
Body	initialise CID cover	▲
Body	Initialise emergency exit	▲
Body	Initialise fire extinguishing system	▲
Body	Initialise new headlight driver module and teach-in turn indicator	●
Body	Initialise power window regulators	●
Body	initialise radiator emblem	▲
Body	Initialise rain sensor	●
Body	Initialise slide/tilt sunroof	●
Body	Initialise trailer tow hitch	▲
Body	Initialising boot lid lift	●
Body	Initialize curtains	▲
Body	Lane change assistant calibration	▲
Body	Leakage test of the valves	▲
Body	Light adjustment for antiglare high-beam headlight and GZA	▲
Body	Load auxiliary battery (12 V)	▲
Body	Lock and enable master key	●
Body	Log off handset (SBDH)	▲
Body	Log on handset (SBDH)	▲
Body	Log on mobile phone	▲
Body	Log on snap-in adapter	▲
Body	Logging the handset on and off	▲
Body	MOST ring: Store configuration	●
Body	Navigation system: Deblock fault memory	▲

Part	Components	Status
Body	Navigation system: DVD lock	▲
Body	Newly address the air distribution flap motors	●
Body	Open tailgate	●
Body	Operational parameter of evaporator temperature	▲
Body	Power Down command	●
Body	Power management: Evaluating the battery state of charge	▲
Body	Power tailgate initialisation	●
Body	Presentation mode	▲
Body	Program seat occupancy detection	▲
Body	Read MRS coding data	▲
Body	Rear driver's side seat standardisation	●
Body	Rear passenger's side seat standardisation	●
Body	Rear-window roller blind	▲
Body	Recode seat-occupancy mat	▲
Body	Register battery replacement	●
Body	Release electric auxiliary heater	▲
Body	Remote key: Change personalisation data	●
Body	Remote key: Personalisation number	●
Body	Reset the internal ELV fault counter	▲
Body	Reset ZBM / SEC workshop mode	▲
Body	Resistance measurement, glow element, auxiliary heater	▲
Body	Roll-over protection system	▲
Body	RSE: Radio remote control	●
Body	Run-in protection for A/C compressor	●
Body	S6411_PL2SHZHTJ -Auxiliary additional heating: Self-test (JBBF70)	▲
Body	Safety system (airbag): Coding data	▲
Body	SBE front passenger	●
Body	Set Night Vision camera alignment	▲
Body	Soft top initialisation	▲
Body	Standby current check, CD batteries	▲
Body	Start safety system (airbag):system time	▲
Body	TCU subsequent evaluation	▲
Body	TCU: Correct volume	▲
Body	Teach in front wiper	●
Body	Teaching in the new headlight driver module	●
Body	Telestart initialisation	▲
Body	Transportability of high-voltage battery unit: Electrical assessment	▲
Body	Trigger roll bar.	▲
Body	Tuner, Japan	▲
Body	Tuner, New Zealand	▲
Body	ULF-SBX and ULF-SBX-H: - Log on mobile phone	▲
Body	Vertically adjust Night Vision camera	▲
Body	Wiper: Installation position	●
Body	ZGM: FlexRay initialisation	●
Chassis and suspension	ACC: Adjust short-range sensors	▲
Chassis and suspension	ACC: Long-range sensor setting	▲
Chassis and suspension	Adjust ACC sensor	▲
Chassis and suspension	Adjustment of steering angle sensor in the SZL	●
Chassis and suspension	Adjustment of the driving dynamics sensors	●
Chassis and suspension	ARS: Initial operation	●
Chassis and suspension	ARS: Lateral acceleration sensor	▲
Chassis and suspension	ARS: Pressure sensor, front axle	▲
Chassis and suspension	ARS: Pressure sensor, rear axle	▲
Chassis and suspension	ARS: Sensor system	▲

Part	Components	Status
Chassis and suspension	ARS: Start-up	▲
Chassis and suspension	Bedding-in workshop	▲
Chassis and suspension	Bleeding DSC hydraulics	●
Chassis and suspension	Brake line mix-up test	●
Chassis and suspension	Brake pedal travel sensor start-up	●
Chassis and suspension	Braking brake bleeding procedure	▲
Chassis and suspension	Check, air supply system	▲
Chassis and suspension	CIM: Steering column calibration	●
Chassis and suspension	DSC control unit adjustment	●
Chassis and suspension	DSC sensor adjustment	●
Chassis and suspension	DSC: Brake bleeding procedure for special cases	●
Chassis and suspension	DSC: Brake line mix-up test	●
Chassis and suspension	DSC: Start-up for brake pedal travel sensor	●
Chassis and suspension	Dynamic Drive, start-up fault	▲
Chassis and suspension	Dynamic Drive, start-up warning	▲
Chassis and suspension	EDC: Function check, vertical acceleration sensors, damper satellites	▲
Chassis and suspension	EDC: Initial operation	▲
Chassis and suspension	EHC: - Lifting and lowering function check	▲
Chassis and suspension	EHC: - Ride height sensor check	▲
Chassis and suspension	EHC: Compressor cycle	●
Chassis and suspension	EHC: Compressor relay check	▲
Chassis and suspension	EHC: Delete energy saving mode	▲
Chassis and suspension	EHC: Preparation for wheel alignment	▲
Chassis and suspension	EHC: Pressure sensor	▲
Chassis and suspension	EHC: Ride height sensors	▲
Chassis and suspension	Electric steering lock: Normalisation	●
Chassis and suspension	Electric steering lock: Partial normalisation	▲
Chassis and suspension	Electrical steering column adjustment normalisation	▲
Chassis and suspension	Electronic ride height control (EHC): - Ride height sensor check	▲
Chassis and suspension	Electronic ride height control (EHC): Air spring	▲
Chassis and suspension	Electronic ride height control (EHC): Air supply system	▲
Chassis and suspension	Electronic ride height control (EHC): Air supply system check	▲
Chassis and suspension	Electronic ride height control (EHC): Bellows valve check	▲
Chassis and suspension	Electronic ride height control (EHC): Check pressure accumulator sensor	▲
Chassis and suspension	Electronic ride height control (EHC): Check, compressor relay	▲
Chassis and suspension	Electronic ride height control (EHC): Compressor	▲
Chassis and suspension	Electronic ride height control (EHC): Draining the air-spring bellows	▲
Chassis and suspension	Electronic ride height control (EHC): Filling and draining	▲
Chassis and suspension	Electronic ride height control (EHC): Filling the air-spring bellows	▲
Chassis and suspension	Electronic ride height control (EHC): Pressure accumulator	▲
Chassis and suspension	Electronic ride height control (EHC): Ride height adjustment	●
Chassis and suspension	Electronic ride height control (EHC): Ride-height sensors	▲
Chassis and suspension	Electronic ride height control (EHC): Valve, pressure accumulator	▲
Chassis and suspension	Electronic ride height control (EHC): Vehicle level	▲
Chassis and suspension	Electronic ride height control (EHC): Vent pressure accumulator	▲
Chassis and suspension	EMF start-up	●
Chassis and suspension	EMF: Bedding-in procedure	●

Part	Components	Status
Chassis and suspension	EMF: Workshop mode	●
Chassis and suspension	EPS: Active steering teach-in procedure	●
Chassis and suspension	EPS: Initial steering startup	●
Chassis and suspension	EPS: Teach-in end stop	●
Chassis and suspension	HSR functional check	●
Chassis and suspension	HSR start-up	●
Chassis and suspension	HSR wheel alignment	●
Chassis and suspension	ICM sensor system: Initial operation	●
Chassis and suspension	Installation mode	▲
Chassis and suspension	Lower front axle by 35 mm for camber adjustment	▲
Chassis and suspension	Normalisation, steering column adjustment	●
Chassis and suspension	Parking brake: Initial operation	●
Chassis and suspension	Positioning-travel check	●
Chassis and suspension	Pre-adjustment of EDC-K switched-on state	●
Chassis and suspension	PSC: Initial steering startup	●
Chassis and suspension	Register change of the capacitor box	▲
Chassis and suspension	SBA: Initial operation	▲
Chassis and suspension	Service function, pressure encoding	▲
Chassis and suspension	Setting, LRR sensor for ACC	▲
Chassis and suspension	Shock absorber adjustment	▲
Chassis and suspension	Start-up Active Steering	●
Chassis and suspension	Start-up for brake pedal travel sensor	●
Chassis and suspension	Steering angle sensor, energy saving mode	▲
Chassis and suspension	Switch off DSC via diagnosis	▲
Chassis and suspension	SWW sensor system: Start-up	▲
Chassis and suspension	SZL/DSC: Steering angle sensor adjustment	●
Chassis and suspension	Tyre defect indicator	▲
Chassis and suspension	VDM: Self-diagnosis, troubleshooting	▲
Chassis and suspension	VDM: Start self-diagnosis	▲
Chassis and suspension	VDM: Start start-up	▲
Chassis and suspension	VDM: Start-up, troubleshooting	▲
Chassis and suspension	VDM: Study the adjustment value	▲
Chassis and suspension	VDM: Vertical acceleration sensor adjustment	▲
Driver assistance	ACC sensor: Start-up	▲
Driver assistance	Adaptation of screen dimensions of the reversing camera on the MASK	▲
Driver assistance	All-round vision camera: Check of the programming	▲
Driver assistance	HUD: - Setting picture geometry	▲
Driver assistance	HUD: Correct picture geometry	▲
Driver assistance	HUD: Correct picture position	▲
Driver assistance	KAFAS: Calibration	▲
Driver assistance	KAFAS: TLC adjustment	▲
Driver assistance	NVE: Calibration	▲
Driver assistance	PMA, updating software of ultrasonic sensors	▲
Driver assistance	Pressure coding service function, RDC integrated	▲
Driver assistance	Replace combiner	▲
Driver assistance	RFK: Calibration	▲
Driver assistance	TLC: Calibrate vibration motor	▲
Engine	Activate recirculating pump unit	●
Engine	Activate refuel detection	▲
Engine	Activation fuel pump control module	●
Engine	Activation/deactivation, terminal 15	●
Engine	Adaptation of exhaust back pressure sensor before exhaust turbocharger	●
Engine	Adaptation value for resetting the fuel pump	●
Engine	Adaptations, low-pressure exhaust-gas recirculation	●

Part	Components	Status
Engine	Adjusting the starting torque	●
Engine	Adjustment of exhaust-gas recirculation	●
Engine	Adjustment, consumption calculation	●
Engine	Automatic air flap control	●
Engine	Basic injection rate at start	●
Engine	Bleeding, fuel system	●
Engine	CAS: Reset	●
Engine	Charging the high-voltage battery: Read out history of last charging procedures	▲
Engine	Checking oxygen sensors for switched plug connections	▲
Engine	Clear adaptations	●
Engine	CO adjustment	●
Engine	Composition of the high-voltage battery unit: Read out serial numbers	●
Engine	Compression pressure	●
Engine	Compression test	●
Engine	Consumption calculation	●
Engine	Cooling system ventilation	●
Engine	cooling system: Ventilation	●
Engine	DDE - CAS adjustment	●
Engine	Delete engine adaptation value	●
Engine	Delete installation mode	●
Engine	Diesel particulate filter: Filter Replacement	●
Engine	Diesel particulate filter: Regeneration	●
Engine	Diesel particulate filter: Request regeneration	●
Engine	DKG: flushing function	●
Engine	DKG: Oil adjustment	●
Engine	DKG: Teach-in clutch slipping point	●
Engine	DME: Reset adaptation values and versions	●
Engine	DMTL pump activation	●
Engine	DSM: Teach-in routine after parts replacement	●
Engine	EGR adaptation	●
Engine	EGS: Mechatronic calibration	●
Engine	EGS: Reset adaptation values	●
Engine	EGS: Teach in neutral position	●
Engine	EGS: transmission fluid adjustment	●
Engine	Electronic immobiliser (EWS): Reset starter lock	▲
Engine	EME: DC/DC converter adjustment	▲
Engine	EME: Delete install mode	▲
Engine	EME: Instruct rotor position sensor	▲
Engine	EME: Read out the adjustment value of the rotor position sensor	▲
Engine	EME: Reset vacuum pump operating time	▲
Engine	EME: Rotor position sensor adjustment	▲
Engine	EME: Teach in parking lock module	▲
Engine	Engine control: Injection rate adjustment	●
Engine	Engine control: Limit quantity adjustment	▲
Engine	Engine control: Mean quantity adaptation	▲
Engine	Engine control: Start amount adjustment	▲
Engine	Engine oil quantity	▲
Engine	Engine operating values record	▲
Engine	E-OBd readiness code	▲
Engine	EWS interface	▲
Engine	Exhaust-gas recirculation cooler adaptation	▲
Engine	Fuel consumption display	▲
Engine	Fuel consumption display adjustment	▲
Engine	Fuel grade output	▲

Part	Components	Status
Engine	Fuel quality identification	●
Engine	Fuel tank pressure sensor adjustment	●
Engine	Gear sensor	●
Engine	Gearbox adaptation	●
Engine	Glow element adjustment	●
Engine	HCP: Start-up after airbag deployment	▲
Engine	HCP: Teach in tilt sensor	▲
Engine	High-voltage battery cooling system: Fill cooling circuit	▲
Engine	High-voltage battery unit: Drain coolant expansion tank	▲
Engine	High-voltage battery: Evaluating the battery state of charge	▲
Engine	Idle speed: Target value and actual value comparison	▲
Engine	Idling quality	▲
Engine	Individual data rescue	▲
Engine	Initialisation of SCR tank system	▲
Engine	Injection deactivation	●
Engine	Injection quantity compensation	●
Engine	Injection quantity compensation, 4-cylinder engine	●
Engine	Injection rate	▲
Engine	Injector equalisation	▲
Engine	Internal engine pressure	▲
Engine	Leakage test, H2 injection valve	▲
Engine	Leakage test, H2 pressure control valve	▲
Engine	Learn Valvetronic limit positions	●
Engine	Limit quantity	▲
Engine	Low/high pressure exhaust-gas recirculation cooler adjustment and adaptation	▲
Engine	Mass meter	▲
Engine	Mean quantity adaptation	●
Engine	Mechatronic calibration	▲
Engine	Minimum stroke adjustment	▲
Engine	MSA: Read history memory	▲
Engine	MSA: zero-gear sensor	▲
Engine	Nitrogen oxide catalytic converter: regeneration	▲
Engine	Nitrogen oxide catalytic converter: Replacement	▲
Engine	OBD Readiness Codes	●
Engine	Oil change	●
Engine	Oil-level adjustment	▲
Engine	Operational smoothness measurement	▲
Engine	Preheating control adjustment	▲
Engine	QMVH: Initial operation	●
Engine	QMVH: Oil change	▲
Engine	Rail pressure regulating valve adaptation	▲
Engine	RDME: Delete install mode	▲
Engine	Read and delete swirl flap adaptation	▲
Engine	Read DDE measured values	▲
Engine	Read/delete engine adaptation value	▲
Engine	Reading out the readiness codes	▲
Engine	Recalibration of SMG	▲
Engine	Regulated differential lock repair function	▲
Engine	Regulation of switching speed	▲
Engine	REME: Delete install mode	▲
Engine	Remove Valvetronic servomotor	▲
Engine	Replacement and repair	▲
Engine	Reset adaptation values	▲
Engine	Reset EWS	●

Part	Components	Status
Engine	Reset learning functions	▲
Engine	Reset production mode	▲
Engine	Reset production mode, preheating control unit	▲
Engine	Reset SCR control unit installation mode	▲
Engine	Reset service function of learning functions	▲
Engine	Reset speedmarks	▲
Engine	Reset starter lock	▲
Engine	Reset the adaptation of the electric fuel pump	▲
Engine	Reset the internal ELV fault counter	▲
Engine	Reset the production mode for the fuel pump control module	▲
Engine	Reset: SCR switch-off scenario	▲
Engine	Resetting the oil service interval	●
Engine	SCR adjustments and adaptations	▲
Engine	SCR reset	●
Engine	SCR system: Adjustment	●
Engine	SCR: Display of fuel tank level	▲
Engine	Service function, display and reset adaptation values	▲
Engine	Service function, engine exchange	▲
Engine	Service start range extender	▲
Engine	SMG hydraulic system	▲
Engine	SMG test functions	▲
Engine	Smooth running control	▲
Engine	Start amount	▲
Engine	Start moment adjustment	▲
Engine	Starter exchange	▲
Engine	Starting up the high-voltage battery unit	▲
Engine	Start-up Valvetronic	●
Engine	Start-up, fuel pump control	●
Engine	System check	▲
Engine	Teach in clutch slipping point	▲
Engine	Teach in drive position actuator	▲
Engine	Teach in SMG transmission	▲
Engine	Teach in zero-gear sensor	▲
Engine	Tolerance test, intermediate lever	▲
Engine	Transmission control unit: , parking lock hook test	▲
Engine	Transmission control unit: Data adjustment, mechatronics	▲
Engine	Transmission control unit: Format fault memory	▲
Engine	Transmission control unit: Oil balancing	▲
Engine	Transmission control unit: Oil change	▲
Engine	Transmission control unit: Replacement	▲
Engine	Transmission control unit: Reset learning function	▲
Engine	Transmission control unit: Reset torque characteristic curve	▲
Engine	Transmission control unit: Resetting adaption functions	▲
Engine	Transmission control unit: Teach in valve characteristic curves PV1, PV2	▲
Engine	Transmission control unit: Teach-in routine, EWS adjustment (immobiliser)	▲
Engine	Transmission control unit: Testing the integrated electrical pump	▲
Engine	Transmission oil pump activation	▲
Engine	Transportability of high-voltage battery unit: Electrical assessment	▲
Engine	Twin-clutch gearbox: , parking lock hook test	▲
Engine	Twin-clutch gearbox: Functional check, parking lock	▲
Engine	Twin-clutch gearbox: Gearbox adaptation	▲
Engine	Valvetronic adaptation limit positions	●
Engine	Valvetronic mechanism/function	●
Engine	Valvetronic: start-up	●

Part	Components	Status
Engine	VANOS ventilation	●
Maintenance	Manual enabling of navigation function	○
Maintenance	Enabling, navigation, automatic	○
Body	Initialise telematics services (Canada)	○
Body	Re-enabling BMW Assist TCU 1.5 Most	○
Body	Re-enabling, BMW Assist TCU MOST	○
Body	Updating online services	○
Engine	Engine self-learning cycle	○
Engine	Compression test	○

Coding List

Series	Model Series	Systems	Coding
3 Series	E36	ABS/ASC/DSC Dynamic Stability Control	●
1 Series	E81/E82/E87/E88	AL active steering	●
3 Series	E36	EWS Electronic immobilizer	●
3 Series	E36	GR Cruise control	●
3 Series	E36	IHKA Heater/automatic A/C control	●
3 Series	E36	KOM Instrument cluster	●
3 Series	E36	SPMFT Mirror memory, driver	●
3 Series	E36	TOENS Thermal oil-level sensor	●
3 Series	E36	ZKE Central body electronics	●
7 Series	E38	AB Airbag	●
7 Series	E38	ABS/ASC/DSC Dynamic Stability Control	●
7 Series	E38	CCM Check Control Module	●
7 Series	E38	DSP Digital Sound Processor	●
7 Series	E38	EDC Damper Control	●
7 Series	E38	EML Electronic engine-power control	●
7 Series	E38	EWS Electronic immobilizer	●
7 Series	E38	GR Cruise control	●
7 Series	E38	HKM Boot-lid module	●
7 Series	E38	IHKA Heater/automatic A/C control	●
7 Series	E38	IKE Instrument-cluster electronics	●
7 Series	E38	LCM Light Check Module	●
7 Series	E38	LEW Steering-angle sensor	●
7 Series	E38	MRS Multiple restraint system	●
7 Series	E38	PDC Park Distance Control	●
7 Series	E38	RDC Tyre pressure control	●
7 Series	E38	SHD Sliding/tilting sunroof	●
7 Series	E38	STH park heating	●
7 Series	E38	TEL Telephone interface	●
7 Series	E38	VID Video module	●
7 Series	E38	ZKE Central body electronics	●
5 Series	E39	AB Airbag	●
5 Series	E39	ABS/ASC/DSC Dynamic Stability Control	●
5 Series	E39	AIC Automatic Interval Control	●
5 Series	E39	DSP Digital Sound Processor	●
5 Series	E39	EDC Damper Control	●
5 Series	E39	EHC Electronic Ride-Height Control	●
5 Series	E39	EWS Electronic immobilizer	●
5 Series	E39	GR Cruise control	●
5 Series	E39	HKM Boot-lid module	●
5 Series	E39	IHKA Heater/automatic A/C control	●
5 Series	E39	IKE Instrument-cluster electronics	●
5 Series	E39	LCM Light Check Module	●
5 Series	E39	LEW Steering-angle sensor	●
5 Series	E39	PDC Park Distance Control	●
5 Series	E39	RAD Radio	●
5 Series	E39	RDC Tyre pressure control	●
5 Series	E39	STH park heating	●
5 Series	E39	TEL Telephone interface	●
5 Series	E39	VID Video module	●
5 Series	E39	ZKE Central body electronics	●
3 Series	E46	AB Airbag	●

Series	Model Series	Systems	Coding
3 Series	E46	ABS/ASC/DSC Dynamic Stability Control	●
3 Series	E46	AHL Adaptive directional headlights	●
3 Series	E46	AIC Automatic Interval Control	●
3 Series	E46	CVM Convertible top module	●
3 Series	E46	DME Motor Electronics	●
3 Series	E46	EKP Fuel pump	●
3 Series	E46	EWS Electronic immobilizer	●
3 Series	E46	GR Cruise control	●
3 Series	E46	IHKA Heater/automatic A/C control	●
3 Series	E46	IKE Instrument-cluster electronics	●
3 Series	E46	LCM Light Check Module	●
3 Series	E46	LEW Steering-angle sensor	●
3 Series	E46	PDC Park Distance Control	●
3 Series	E46	RAD Radio	●
3 Series	E46	RDC Tyre pressure control	●
3 Series	E46	SHD Sliding/tilting sunroof	●
3 Series	E46	SMF Seat memory, driver	●
3 Series	E46	SPMBT Mirror memory, passenger	●
3 Series	E46	SPMFT Mirror memory, driver	●
3 Series	E46	TEL Telephone interface	●
3 Series	E46	VID Video module	●
3 Series	E46	ZKE Central body electronics	●
Z Series	E52	AB Airbag	●
Z Series	E52	ABS/ASC/DSC Dynamic Stability Control	●
Z Series	E52	ELV Electronic steering-column locking	●
Z Series	E52	EWS Electronic immobilizer	●
Z Series	E52	GM base module	●
Z Series	E52	IHKA Heater/automatic A/C control	●
Z Series	E52	IKE Instrument-cluster electronics	●
Z Series	E52	LCM Light Check Module	●
Z Series	E52	LEW Steering-angle sensor	●
Z Series	E52	RAD Radio	●
X Series	E53	AB Airbag	●
X Series	E53	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E53	AHL Adaptive directional headlights	●
X Series	E53	AIC Automatic Interval Control	●
X Series	E53	DME Motor Electronics	●
X Series	E53	DSP Digital Sound Processor	●
X Series	E53	EHC Electronic Ride-Height Control	●
X Series	E53	EWS Electronic immobilizer	●
X Series	E53	IHKA Heater/automatic A/C control	●
X Series	E53	IKE Instrument-cluster electronics	●
X Series	E53	LCM Light Check Module	●
X Series	E53	LEW Steering-angle sensor	●
X Series	E53	PDC Park Distance Control	●
X Series	E53	RAD Radio	●
X Series	E53	RDC Tyre pressure control	●
X Series	E53	SHD Sliding/tilting sunroof	●
X Series	E53	SMF Seat memory, driver	●
X Series	E53	STH park heating	●
X Series	E53	TEL Telephone interface	●
X Series	E53	VID Video module	●
X Series	E53	ZKE Central body electronics	●
5 Series	E60	ABS/ASC/DSC Dynamic Stability Control	●

Series	Model Series	Systems	Coding
5 Series	E60	ACC2 Active cruise control 2	●
5 Series	E60	AHL Adaptive directional headlights	●
5 Series	E60	AHM Trailer module	●
5 Series	E60	AL active steering	●
5 Series	E60	ALBBF active backrest width, front passenger	●
5 Series	E60	ALBFA active backrest width, driver	●
5 Series	E60	AMP Amplifier	●
5 Series	E60	ARS Dynamic Drive 2	●
5 Series	E60	CA Comfort access system	●
5 Series	E60	CAS Car Access System	●
5 Series	E60	CCC-A Applications	●
5 Series	E60	CCC-ANT Aerial tuner	●
5 Series	E60	CCC-ASK Audio system controller	●
5 Series	E60	CCC-B0 User interface	●
5 Series	E60	CCC-GW Gateway	●
5 Series	E60	CID Central Information Display	●
5 Series	E60	CON Controller	●
5 Series	E60	DME Motor Electronics	●
5 Series	E60	DVDC DVD Changer	●
5 Series	E60	DWA anti-theft alarm system	●
5 Series	E60	EDC Damper Control	●
5 Series	E60	EGS transmission management	●
5 Series	E60	EHC Electronic Ride-Height Control	●
5 Series	E60	EKPS Fuel-pump control	●
5 Series	E60	FLA High Beam Assist	●
5 Series	E60	GWS Gear selector switch	●
5 Series	E60	HKL Rear-lid lift	●
5 Series	E60	HUD Head-Up Display	●
5 Series	E60	IHKA Integrated automatic heating/air conditioning	●
5 Series	E60	INSTR Instrument cluster	●
5 Series	E60	KBM Body basic module	●
5 Series	E60	KGM Body Gateway Module	●
5 Series	E60	LDM Longitudinal Dynamics Management	●
5 Series	E60	LM2 Light module 2	●
5 Series	E60	MPM Micro-power module	●
5 Series	E60	NVE Night Vision Electronics	●
5 Series	E60	PDC Park Distance Control	●
5 Series	E60	RLS Rain/Light Sensor	●
5 Series	E60	RSE Rear Seat Entertainment	●
5 Series	E60	SBSL Satellite, B-pillar, left	●
5 Series	E60	SBSR Satellite, B-pillar, right	●
5 Series	E60	SFZ Satellite vehicle centre	●
5 Series	E60	SGM-SIM Safety and Gateway Module (SIM)	●
5 Series	E60	SHD Sliding/tilting sunroof	●
5 Series	E60	SHZH Independent/auxiliary heater	●
5 Series	E60	SINE Siren and tilt sensor	●
5 Series	E60	SMBF Seat module, passenger	●
5 Series	E60	SMFA Seat module, driver	●
5 Series	E60	SZL Switch centre, steering column	●
5 Series	E60	SZM Switching centre, centre console	●
5 Series	E60	TLC Lane Departure Warning	●
5 Series	E60	TMBF Door module, front passenger	●
5 Series	E60	TMFA Door module, driver	●
5 Series	E60	ULF Universal charging and hands-free facility	●

Series	Model Series	Systems	Coding
5 Series	E60	ULF-SBX-H Interface box High	●
5 Series	E60	VTG Transfer case	●
5 Series	E61	ABS/ASC/DSC Dynamic Stability Control	●
5 Series	E61	ACC2 Active cruise control 2	●
5 Series	E61	AHL Adaptive directional headlights	●
5 Series	E61	AHM Trailer module	●
5 Series	E61	AL active steering	●
5 Series	E61	ALBBF active backrest width, front passenger	●
5 Series	E61	ALBFA active backrest width, driver	●
5 Series	E61	AMP Amplifier	●
5 Series	E61	ARS Dynamic Drive 2	●
5 Series	E61	CA Comfort access system	●
5 Series	E61	CAS Car Access System	●
5 Series	E61	CCC-A Applications	●
5 Series	E61	CCC-ANT Aerial tuner	●
5 Series	E61	CCC-ASK Audio system controller	●
5 Series	E61	CCC-B0 User interface	●
5 Series	E61	CCC-GW Gateway	●
5 Series	E61	CID Central Information Display	●
5 Series	E61	CON Controller	●
5 Series	E61	DME Motor Electronics	●
5 Series	E61	DVDC DVD Changer	●
5 Series	E61	DWA anti-theft alarm system	●
5 Series	E61	EDC Damper Control	●
5 Series	E61	EGS transmission management	●
5 Series	E61	EHC Electronic Ride-Height Control	●
5 Series	E61	EKPS Fuel-pump control	●
5 Series	E61	FLA High Beam Assist	●
5 Series	E61	GWS Gear selector switch	●
5 Series	E61	HKL Rear-lid lift	●
5 Series	E61	HUD Head-Up Display	●
5 Series	E61	IHKA Integrated automatic heating/air conditioning	●
5 Series	E61	INSTR Instrument cluster	●
5 Series	E61	KBM Body basic module	●
5 Series	E61	KGM Body Gateway Module	●
5 Series	E61	LDM Longitudinal Dynamics Management	●
5 Series	E61	LM2 Light module 2	●
5 Series	E61	MPM Micro-power module	●
5 Series	E61	NVE Night Vision Electronics	●
5 Series	E61	PDC Park Distance Control	●
5 Series	E61	RLS Rain/Light Sensor	●
5 Series	E61	RSE Rear Seat Entertainment	●
5 Series	E61	SBSL Satellite, B-pillar, left	●
5 Series	E61	SBSR Satellite, B-pillar, right	●
5 Series	E61	SFZ Satellite vehicle centre	●
5 Series	E61	SGM-SIM Safety and Gateway Module (SIM)	●
5 Series	E61	SHD Sliding/tilting sunroof	●
5 Series	E61	SHZH Independent/auxiliary heater	●
5 Series	E61	SINE Siren and tilt sensor	●
5 Series	E61	SMBF Seat module, passenger	●
5 Series	E61	SMFA Seat module, driver	●
5 Series	E61	SZL Switch centre, steering column	●
5 Series	E61	SZM Switching centre, centre console	●
5 Series	E61	TLC Lane Departure Warning	●

Series	Model Series	Systems	Coding
5 Series	E61	TMBF Door module, front passenger	●
5 Series	E61	TMFA Door module, driver	●
5 Series	E61	ULF Universal charging and hands-free facility	●
5 Series	E61	ULF-SBX-H Interface box High	●
5 Series	E61	VTG Transfer case	●
6 Series	E63	ABS/ASC/DSC Dynamic Stability Control	●
6 Series	E63	ACC2 Active cruise control 2	●
6 Series	E63	AHL Adaptive directional headlights	●
6 Series	E63	AHM Trailer module	●
6 Series	E63	AL active steering	●
6 Series	E63	ALBBF active backrest width, front passenger	●
6 Series	E63	ALBFA active backrest width, driver	●
6 Series	E63	AMP Amplifier	●
6 Series	E63	ARS Dynamic Drive 2	●
6 Series	E63	CA Comfort access system	●
6 Series	E63	CAS Car Access System	●
6 Series	E63	CCC-A Applications	●
6 Series	E63	CCC-ANT Aerial tuner	●
6 Series	E63	CCC-ASK Audio system controller	●
6 Series	E63	CCC-B0 User interface	●
6 Series	E63	CCC-GW Gateway	●
6 Series	E63	CID Central Information Display	●
6 Series	E63	CON Controller	●
6 Series	E63	DME Motor Electronics	●
6 Series	E63	DVDC DVD Changer	●
6 Series	E63	DWA anti-theft alarm system	●
6 Series	E63	EDC Damper Control	●
6 Series	E63	EGS transmission management	●
6 Series	E63	EHC Electronic Ride-Height Control	●
6 Series	E63	EKPS Fuel-pump control	●
6 Series	E63	FLA High Beam Assist	●
6 Series	E63	GWS Gear selector switch	●
6 Series	E63	HKL Rear-lid lift	●
6 Series	E63	HUD Head-Up Display	●
6 Series	E63	IHKA Integrated automatic heating/air conditioning	●
6 Series	E63	INSTR Instrument cluster	●
6 Series	E63	KBM Body basic module	●
6 Series	E63	KGM Body Gateway Module	●
6 Series	E63	LDM Longitudinal Dynamics Management	●
6 Series	E63	LM2 Light module 2	●
6 Series	E63	MPM Micro-power module	●
6 Series	E63	NVE Night Vision Electronics	●
6 Series	E63	PDC Park Distance Control	●
6 Series	E63	RLS Rain/Light Sensor	●
6 Series	E63	RSE Rear Seat Entertainment	●
6 Series	E63	SBSL Satellite, B-pillar, left	●
6 Series	E63	SBSR Satellite, B-pillar, right	●
6 Series	E63	SFZ Satellite vehicle centre	●
6 Series	E63	SGM-SIM Safety and Gateway Module (SIM)	●
6 Series	E63	SHD Sliding/tilting sunroof	●
6 Series	E63	SHZH Independent/auxiliary heater	●
6 Series	E63	SINE Siren and tilt sensor	●
6 Series	E63	SMBF Seat module, passenger	●
6 Series	E63	SMFA Seat module, driver	●

Series	Model Series	Systems	Coding
6 Series	E63	SZL Switch centre, steering column	●
6 Series	E63	SZM Switching centre, centre console	●
6 Series	E63	TLC Lane Departure Warning	●
6 Series	E63	TMBF Door module, front passenger	●
6 Series	E63	TMFA Door module, driver	●
6 Series	E63	ULF Universal charging and hands-free facility	●
6 Series	E63	ULF-SBX-H Interface box High	●
6 Series	E63	VTG Transfer case	●
6 Series	E64	ABS/ASC/DSC Dynamic Stability Control	●
6 Series	E64	ACC2 Active cruise control 2	●
6 Series	E64	AHL Adaptive directional headlights	●
6 Series	E64	AHM Trailer module	●
6 Series	E64	AL active steering	●
6 Series	E64	ALBBF active backrest width, front passenger	●
6 Series	E64	ALBFA active backrest width, driver	●
6 Series	E64	AMP Amplifier	●
6 Series	E64	ARS Dynamic Drive 2	●
6 Series	E64	CA Comfort access system	●
6 Series	E64	CAS Car Access System	●
6 Series	E64	CCC-A Applications	●
6 Series	E64	CCC-ANT Aerial tuner	●
6 Series	E64	CCC-ASK Audio system controller	●
6 Series	E64	CCC-B0 User interface	●
6 Series	E64	CCC-GW Gateway	●
6 Series	E64	CID Central Information Display	●
6 Series	E64	CON Controller	●
6 Series	E64	DME Motor Electronics	●
6 Series	E64	DVDC DVD Changer	●
6 Series	E64	DWA anti-theft alarm system	●
6 Series	E64	EDC Damper Control	●
6 Series	E64	EGS transmission management	●
6 Series	E64	EHC Electronic Ride-Height Control	●
6 Series	E64	EKPS Fuel-pump control	●
6 Series	E64	FLA High Beam Assist	●
6 Series	E64	GWS Gear selector switch	●
6 Series	E64	HKL Rear-lid lift	●
6 Series	E64	HUD Head-Up Display	●
6 Series	E64	IHKA Integrated automatic heating/air conditioning	●
6 Series	E64	INSTR Instrument cluster	●
6 Series	E64	KBM Body basic module	●
6 Series	E64	KGM Body Gateway Module	●
6 Series	E64	LDM Longitudinal Dynamics Management	●
6 Series	E64	LM2 Light module 2	●
6 Series	E64	MPM Micro-power module	●
6 Series	E64	NVE Night Vision Electronics	●
6 Series	E64	PDC Park Distance Control	●
6 Series	E64	RLS Rain/Light Sensor	●
6 Series	E64	RSE Rear Seat Entertainment	●
6 Series	E64	SBSL Satellite, B-pillar, left	●
6 Series	E64	SBSR Satellite, B-pillar, right	●
6 Series	E64	SFZ Satellite vehicle centre	●
6 Series	E64	SGM-SIM Safety and Gateway Module (SIM)	●
6 Series	E64	SHD Sliding/tilting sunroof	●
6 Series	E64	SHZH Independent/auxiliary heater	●

Series	Model Series	Systems	Coding
6 Series	E64	SINE Siren and tilt sensor	●
6 Series	E64	SMBF Seat module, passenger	●
6 Series	E64	SMFA Seat module, driver	●
6 Series	E64	SZL Switch centre, steering column	●
6 Series	E64	SZM Switching centre, centre console	●
6 Series	E64	TLC Lane Departure Warning	●
6 Series	E64	TMBF Door module, front passenger	●
6 Series	E64	TMFA Door module, driver	●
6 Series	E64	ULF Universal charging and hands-free facility	●
6 Series	E64	ULF-SBX-H Interface box High	●
6 Series	E64	VTG Transfer case	●
7 Series	E65	ACC Active Cruise Control	●
7 Series	E65	AHL Adaptive directional headlights	●
7 Series	E65	AHM Trailer module	●
7 Series	E65	ANT Aerial/antenna tuner	●
7 Series	E65	ARS Dynamic Drive	●
7 Series	E65	ASK Audio system controller	●
7 Series	E65	CA Comfort access system	●
7 Series	E65	CAS Car Access System	●
7 Series	E65	CD Control Display	●
7 Series	E65	CIM Chassis Integration Module	●
7 Series	E65	DME Motor Electronics	●
7 Series	E65	DME Motor Electronics2	●
7 Series	E65	DVDC DVD Changer	●
7 Series	E65	DWA anti-theft alarm system	●
7 Series	E65	EDC Damper Control	●
7 Series	E65	EGS transmission management	●
7 Series	E65	EHC Electronic Ride-Height Control	●
7 Series	E65	EMF Parking brake	●
7 Series	E65	FBI Flexible Bus Interface	●
7 Series	E65	FKA Rear heater/air conditioning	●
7 Series	E65	FLA High Beam Assist	●
7 Series	E65	HKL Rear-lid lift	●
7 Series	E65	IHKA Integrated automatic heating/air conditioning	●
7 Series	E65	INSTR Instrument cluster	●
7 Series	E65	LM Lights Module	●
7 Series	E65	NAV Navigation computer	●
7 Series	E65	NVE Night Vision Electronics	●
7 Series	E65	PDC Park Distance Control	●
7 Series	E65	PM Power Module	●
7 Series	E65	RDC Tyre pressure control	●
7 Series	E65	RLS Rain/Light Sensor	●
7 Series	E65	SASL Satellite, A-pillar, left	●
7 Series	E65	SASR Satellite, A-pillar, right	●
7 Series	E65	SBSL Satellite, B-pillar, left	●
7 Series	E65	SBSR Satellite, B-pillar, right	●
7 Series	E65	SEC2 Supplementary control unit 2	●
7 Series	E65	SFZ Satellite vehicle centre	●
7 Series	E65	SG-FD Control unit, rear-compartment display	●
7 Series	E65	SGM-SIM Safety and Gateway Module (SIM)	●
7 Series	E65	SHD Sliding/tilting sunroof	●
7 Series	E65	SHZH Independent/auxiliary heater	●
7 Series	E65	SINE Siren and tilt sensor	●
7 Series	E65	SMBF Seat module, passenger	●

Series	Model Series	Systems	Coding
7 Series	E65	SMBFH Seat module, passenger's side, rear	●
7 Series	E65	SMFA Seat module, driver	●
7 Series	E65	SMFAH Seat module, driver's side, rear	●
7 Series	E65	SSBF Satellite, seat, passenger	●
7 Series	E65	SSFA Satellite, seat, driver	●
7 Series	E65	SSH Satellite, seat, rear	●
7 Series	E65	STVL Satellite, door, front left	●
7 Series	E65	STVR Satellite, door, front right	●
7 Series	E65	SZL Switch centre, steering column	●
7 Series	E65	TEL Telephone interface	●
7 Series	E65	TMBFH Door module, passenger's side, rear	●
7 Series	E65	TMBFT Door module, passenger door	●
7 Series	E65	TMFAH Door module, driver's side, rear	●
7 Series	E65	TMFAT Door module, driver's door	●
7 Series	E65	WIM Wiper module	●
7 Series	E65	ZBM Two-battery management	●
7 Series	E66	ACC Active Cruise Control	●
7 Series	E66	AHL Adaptive directional headlights	●
7 Series	E66	AHM Trailer module	●
7 Series	E66	ANT Aerial/antenna tuner	●
7 Series	E66	ARS Dynamic Drive	●
7 Series	E66	ASK Audio system controller	●
7 Series	E66	CA Comfort access system	●
7 Series	E66	CAS Car Access System	●
7 Series	E66	CD Control Display	●
7 Series	E66	CIM Chassis Integration Module	●
7 Series	E66	DME Motor Electronics	●
7 Series	E66	DME Motor Electronics2	●
7 Series	E66	DVDC DVD Changer	●
7 Series	E66	DWA anti-theft alarm system	●
7 Series	E66	EDC Damper Control	●
7 Series	E66	EGS transmission management	●
7 Series	E66	EHC Electronic Ride-Height Control	●
7 Series	E66	EMF Parking brake	●
7 Series	E66	FBI Flexible Bus Interface	●
7 Series	E66	FKA Rear heater/air conditioning	●
7 Series	E66	FLA High Beam Assist	●
7 Series	E66	HKL Rear-lid lift	●
7 Series	E66	IHKA Integrated automatic heating/air conditioning	●
7 Series	E66	INSTR Instrument cluster	●
7 Series	E66	LM Lights Module	●
7 Series	E66	NAV Navigation computer	●
7 Series	E66	NVE Night Vision Electronics	●
7 Series	E66	PDC Park Distance Control	●
7 Series	E66	PM Power Module	●
7 Series	E66	RDC Tyre pressure control	●
7 Series	E66	RLS Rain/Light Sensor	●
7 Series	E66	SASL Satellite, A-pillar, left	●
7 Series	E66	SASR Satellite, A-pillar, right	●
7 Series	E66	SBSL Satellite, B-pillar, left	●
7 Series	E66	SBSR Satellite, B-pillar, right	●
7 Series	E66	SEC2 Supplementary control unit 2	●
7 Series	E66	SFZ Satellite vehicle centre	●
7 Series	E66	SG-FD Control unit, rear-compartment display	●

Series	Model Series	Systems	Coding
7 Series	E66	SGM-SIM Safety and Gateway Module(SIM)	●
7 Series	E66	SHD Sliding/tilting sunroof	●
7 Series	E66	SHZH Independent/auxiliary heater	●
7 Series	E66	SINE Siren and tilt sensor	●
7 Series	E66	SMBF Seat module, passenger	●
7 Series	E66	SMBFH Seat module, passenger's side, rear	●
7 Series	E66	SMFA Seat module, driver	●
7 Series	E66	SMFAH Seat module, driver's side, rear	●
7 Series	E66	SSBF Satellite, seat, passenger	●
7 Series	E66	SSFA Satellite, seat, driver	●
7 Series	E66	SSH Satellite, seat, rear	●
7 Series	E66	STVL Satellite, door, front left	●
7 Series	E66	STVR Satellite, door, front right	●
7 Series	E66	SZL Switch centre, steering column	●
7 Series	E66	TEL Telephone interface	●
7 Series	E66	TMBFH Door module, passenger's side, rear	●
7 Series	E66	TMBFT Door module, passenger door	●
7 Series	E66	TMFAH Door module, driver's side, rear	●
7 Series	E66	TMFAT Door module, driver's door	●
7 Series	E66	WIM Wiper module	●
7 Series	E66	ZBM Two-battery management	●
7 Series	E67	ACC Active Cruise Control	●
7 Series	E67	AHL Adaptive directional headlights	●
7 Series	E67	AHM Trailer module	●
7 Series	E67	ANT Aerial/antenna tuner	●
7 Series	E67	ARS Dynamic Drive	●
7 Series	E67	ASK Audio system controller	●
7 Series	E67	CA Comfort access system	●
7 Series	E67	CAS Car Access System	●
7 Series	E67	CD Control Display	●
7 Series	E67	CIM Chassis Integration Module	●
7 Series	E67	DME Motor Electronics	●
7 Series	E67	DME Motor Electronics2	●
7 Series	E67	DVDC DVD Changer	●
7 Series	E67	DWA anti-theft alarm system	●
7 Series	E67	EDC Damper Control	●
7 Series	E67	EGS transmission management	●
7 Series	E67	EHC Electronic Ride-Height Control	●
7 Series	E67	EMF Parking brake	●
7 Series	E67	FBI Flexible Bus Interface	●
7 Series	E67	FKA Rear heater/air conditioning	●
7 Series	E67	FLA High Beam Assist	●
7 Series	E67	HKL Rear-lid lift	●
7 Series	E67	IHKA Integrated automatic heating/air conditioning	●
7 Series	E67	INSTR Instrument cluster	●
7 Series	E67	LM Lights Module	●
7 Series	E67	NAV Navigation computer	●
7 Series	E67	NVE Night Vision Electronics	●
7 Series	E67	PDC Park Distance Control	●
7 Series	E67	PM Power Module	●
7 Series	E67	RDC Tyre pressure control	●
7 Series	E67	RLS Rain/Light Sensor	●
7 Series	E67	SASL Satellite, A-pillar, left	●
7 Series	E67	SASR Satellite, A-pillar, right	●

Series	Model Series	Systems	Coding
7 Series	E67	SBSL Satellite, B-pillar, left	●
7 Series	E67	SBSR Satellite, B-pillar, right	●
7 Series	E67	SEC2 Supplementary control unit 2	●
7 Series	E67	SFZ Satellite vehicle centre	●
7 Series	E67	SG-FD Control unit, rear-compartment display	●
7 Series	E67	SGM-SIM Safety and Gateway Module (SIM)	●
7 Series	E67	SHD Sliding/tilting sunroof	●
7 Series	E67	SHZH Independent/auxiliary heater	●
7 Series	E67	SINE Siren and tilt sensor	●
7 Series	E67	SMBF Seat module, passenger	●
7 Series	E67	SMBFH Seat module, passenger's side, rear	●
7 Series	E67	SMFA Seat module, driver	●
7 Series	E67	SMFAH Seat module, driver's side, rear	●
7 Series	E67	SSBF Satellite, seat, passenger	●
7 Series	E67	SSFA Satellite, seat, driver	●
7 Series	E67	SSH Satellite, seat, rear	●
7 Series	E67	STVL Satellite, door, front left	●
7 Series	E67	STVR Satellite, door, front right	●
7 Series	E67	SZL Switch centre, steering column	●
7 Series	E67	TEL Telephone interface	●
7 Series	E67	TMBFH Door module, passenger's side, rear	●
7 Series	E67	TMBFT Door module, passenger door	●
7 Series	E67	TMFAH Door module, driver's side, rear	●
7 Series	E67	TMFAT Door module, driver's door	●
7 Series	E67	WIM Wiper module	●
7 Series	E67	ZBM Two-battery management	●
7 Series	E68	ACC Active Cruise Control	●
7 Series	E68	AHL Adaptive directional headlights	●
7 Series	E68	AHM Trailer module	●
7 Series	E68	ANT Aerial/antenna tuner	●
7 Series	E68	ARS Dynamic Drive	●
7 Series	E68	ASK Audio system controller	●
7 Series	E68	CA Comfort access system	●
7 Series	E68	CAS Car Access System	●
7 Series	E68	CD Control Display	●
7 Series	E68	CIM Chassis Integration Module	●
7 Series	E68	DME Motor Electronics	●
7 Series	E68	DME Motor Electronics2	●
7 Series	E68	DVDC DVD Changer	●
7 Series	E68	DWA anti-theft alarm system	●
7 Series	E68	EDC Damper Control	●
7 Series	E68	EGS transmission management	●
7 Series	E68	EHC Electronic Ride-Height Control	●
7 Series	E68	EMF Parking brake	●
7 Series	E68	FBI Flexible Bus Interface	●
7 Series	E68	FKA Rear heater/air conditioning	●
7 Series	E68	FLA High Beam Assist	●
7 Series	E68	HKL Rear-lid lift	●
7 Series	E68	IHKA Integrated automatic heating/air conditioning	●
7 Series	E68	INSTR Instrument cluster	●
7 Series	E68	LM Lights Module	●
7 Series	E68	NAV Navigation computer	●
7 Series	E68	NVE Night Vision Electronics	●
7 Series	E68	PDC Park Distance Control	●

Series	Model Series	Systems	Coding
7 Series	E68	PM Power Module	●
7 Series	E68	RDC Tyre pressure control	●
7 Series	E68	RLS Rain/Light Sensor	●
7 Series	E68	SASL Satellite, A-pillar, left	●
7 Series	E68	SASR Satellite, A-pillar, right	●
7 Series	E68	SBSL Satellite, B-pillar, left	●
7 Series	E68	SBSR Satellite, B-pillar, right	●
7 Series	E68	SEC2 Supplementary control unit 2	●
7 Series	E68	SFZ Satellite vehicle centre	●
7 Series	E68	SG-FD Control unit, rear-compartment display	●
7 Series	E68	SGM-SIM Safety and Gateway Module (SIM)	●
7 Series	E68	SHD Sliding/tilting sunroof	●
7 Series	E68	SHZH Independent/auxiliary heater	●
7 Series	E68	SINE Siren and tilt sensor	●
7 Series	E68	SMBF Seat module, passenger	●
7 Series	E68	SMBFH Seat module, passenger's side, rear	●
7 Series	E68	SMFA Seat module, driver	●
7 Series	E68	SMFAH Seat module, driver's side, rear	●
7 Series	E68	SSBF Satellite, seat, passenger	●
7 Series	E68	SSFA Satellite, seat, driver	●
7 Series	E68	SSH Satellite, seat, rear	●
7 Series	E68	STVL Satellite, door, front left	●
7 Series	E68	STVR Satellite, door, front right	●
7 Series	E68	SZL Switch centre, steering column	●
7 Series	E68	TEL Telephone interface	●
7 Series	E68	TMBFH Door module, passenger's side, rear	●
7 Series	E68	TMBFT Door module, passenger door	●
7 Series	E68	TMFAH Door module, driver's side, rear	●
7 Series	E68	TMFAT Door module, driver's door	●
7 Series	E68	WIM Wiper module	●
7 Series	E68	ZBM Two-battery management	●
X Series	E70	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E70	ACSM Crash Safety Module	●
X Series	E70	AHM Trailer module	●
X Series	E70	AL active front steering (AFS70)	●
X Series	E70	AMPH Hi-Fi amplifier	●
X Series	E70	ARS Dynamic Drive	●
X Series	E70	CA Comfort access system	●
X Series	E70	CAS Car Access System	●
X Series	E70	CCC-A Applications	●
X Series	E70	CCC-ANT Aerial tuner	●
X Series	E70	CCC-ASK Audio system controller	●
X Series	E70	CCC-GW Gateway	●
X Series	E70	CHAMP-BO User interface	●
X Series	E70	CON Controller	●
X Series	E70	DME Motor Electronics	●
X Series	E70	DVDC DVD Changer	●
X Series	E70	EDCSHL Damper satellite, rear left	●
X Series	E70	EDCSHR Damper satellite, rear right	●
X Series	E70	EDCSVL Damper satellite, front left	●
X Series	E70	EDCSVR Damper satellite, front right	●
X Series	E70	EGS 6HPTU transmission control	●
X Series	E70	EHC Electronic Ride-Height Control	●
X Series	E70	EKPS Fuel-pump control	●

Series	Model Series	Systems	Coding
X Series	E70	EMF Parking brake	●
X Series	E70	FKA Rear heater/air conditioning	●
X Series	E70	FLA High Beam Assist	●
X Series	E70	FRM2 Footwell module 2	●
X Series	E70	FZD Function centre, roof	●
X Series	E70	GWS Gear selector switch	●
X Series	E70	HKL Rear-lid lift	●
X Series	E70	HUD Head-Up Display	●
X Series	E70	IHKA Integrated automatic heating/air conditioning	●
X Series	E70	INSTR Instrument cluster	●
X Series	E70	JBE2 Junction Box electronics	●
X Series	E70	PDC Park Distance Control	●
X Series	E70	RFK Reversing camera	●
X Series	E70	RLS Rain/light solar sensor	●
X Series	E70	RSE Rear Seat Entertainment	●
X Series	E70	SINE Siren and tilt sensor	●
X Series	E70	SMBF Seat module, passenger	●
X Series	E70	SMFA Seat module, driver	●
X Series	E70	SVT Servotronic	●
X Series	E70	TR SVC allround-view camera	●
X Series	E70	ULF-SBX Interface box	●
X Series	E70	ULF-SBX-H Interface box High	●
X Series	E70	VDM Vertical Dynamics Management	●
X Series	E70	VM Video Module	●
X Series	E70	VSW video switch	●
X Series	E70	VTG Transfer case	●
X Series	E71	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E71	ACSM Crash Safety Module	●
X Series	E71	AHM Trailer module	●
X Series	E71	AL active front steering(AFS70)	●
X Series	E71	AMPH Hi-Fi amplifier	●
X Series	E71	ARS Dynamic Drive	●
X Series	E71	CA Comfort access system	●
X Series	E71	CAS Car Access System	●
X Series	E71	CCC-A Applications	●
X Series	E71	CCC-ANT Aerial tuner	●
X Series	E71	CCC-ASK Audio system controller	●
X Series	E71	CCC-GW Gateway	●
X Series	E71	CHAMP-BO User interface	●
X Series	E71	CON Controller	●
X Series	E71	DME Motor Electronics	●
X Series	E71	DVDC DVD Changer	●
X Series	E71	EDCSHL Damper satellite, rear left	●
X Series	E71	EDCSHR Damper satellite, rear right	●
X Series	E71	EDCSVL Damper satellite, front left	●
X Series	E71	EDCSVR Damper satellite, front right	●
X Series	E71	EGS 6HPTU transmission control	●
X Series	E71	EHC Electronic Ride-Height Control	●
X Series	E71	EKPS Fuel-pump control	●
X Series	E71	EMF Parking brake	●
X Series	E71	FKA Rear heater/air conditioning	●
X Series	E71	FLA High Beam Assist	●
X Series	E71	FRM2 Footwell module 2	●
X Series	E71	FZD Function centre, roof	●

Series	Model Series	Systems	Coding
X Series	E71	GWS Gear selector switch	●
X Series	E71	HKL Rear-lid lift	●
X Series	E71	HUD Head-Up Display	●
X Series	E71	IHKA Integrated automatic heating/air conditioning	●
X Series	E71	INSTR Instrument cluster	●
X Series	E71	JBE2 Junction Box electronics	●
X Series	E71	PDC Park Distance Control	●
X Series	E71	RFK Reversing camera	●
X Series	E71	RLS Rain/light solar sensor	●
X Series	E71	RSE Rear Seat Entertainment	●
X Series	E71	SINE Siren and tilt sensor	●
X Series	E71	SMBF Seat module, passenger	●
X Series	E71	SMFA Seat module, driver	●
X Series	E71	SVT Servotronic	●
X Series	E71	TR SVC allround-view camera	●
X Series	E71	ULF-SBX Interface box	●
X Series	E71	ULF-SBX-H Interface box High	●
X Series	E71	VDM Vertical Dynamics Management	●
X Series	E71	VM Video Module	●
X Series	E71	VSW video switch	●
X Series	E71	VTG Transfer case	●
X Series	E72	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E72	ACSM Crash Safety Module	●
X Series	E72	AHM Trailer module	●
X Series	E72	AL active front steering(AFS70)	●
X Series	E72	AMPH Hi-Fi amplifier	●
X Series	E72	ARS Dynamic Drive	●
X Series	E72	CA Comfort access system	●
X Series	E72	CAS Car Access System	●
X Series	E72	CCC-A Applications	●
X Series	E72	CCC-ANT Aerial tuner	●
X Series	E72	CCC-ASK Audio system controller	●
X Series	E72	CCC-GW Gateway	●
X Series	E72	CHAMP-BO User interface	●
X Series	E72	CON Controller	●
X Series	E72	DME Motor Electronics	●
X Series	E72	DVDC DVD Changer	●
X Series	E72	EDCSHL Damper satellite, rear left	●
X Series	E72	EDCSHR Damper satellite, rear right	●
X Series	E72	EDCSVL Damper satellite, front left	●
X Series	E72	EDCSVR Damper satellite, front right	●
X Series	E72	EGS 6HPTU transmission control	●
X Series	E72	EHC Electronic Ride-Height Control	●
X Series	E72	EKPS Fuel-pump control	●
X Series	E72	EMF Parking brake	●
X Series	E72	FKA Rear heater/air conditioning	●
X Series	E72	FLA High Beam Assist	●
X Series	E72	FRM2 Footwell module 2	●
X Series	E72	FZD Function centre, roof	●
X Series	E72	GWS Gear selector switch	●
X Series	E72	HKL Rear-lid lift	●
X Series	E72	HUD Head-Up Display	●
X Series	E72	IHKA Integrated automatic heating/air conditioning	●
X Series	E72	INSTR Instrument cluster	●

Series	Model Series	Systems	Coding
X Series	E72	JBE2 Junction Box electronics	●
X Series	E72	PDC Park Distance Control	●
X Series	E72	RFK Reversing camera	●
X Series	E72	RLS Rain/light solar sensor	●
X Series	E72	RSE Rear Seat Entertainment	●
X Series	E72	SINE Siren and tilt sensor	●
X Series	E72	SMBF Seat module, passenger	●
X Series	E72	SMFA Seat module, driver	●
X Series	E72	SVT Servotronic	●
X Series	E72	TR SVC allround-view camera	●
X Series	E72	ULF-SBX Interface box	●
X Series	E72	ULF-SBX-H Interface box High	●
X Series	E72	VDM Vertical Dynamics Management	●
X Series	E72	VM Video Module	●
X Series	E72	VSW video switch	●
X Series	E72	VTG Transfer case	●
X Series	E83	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E83	AHL Adaptive directional headlights	●
X Series	E83	DME Motor Electronics	●
X Series	E83	DSP Digital Sound Processor	●
X Series	E83	EWS Vehicle immobilizer	●
X Series	E83	GM base module	●
X Series	E83	IHKR Integrated heating/air-conditioning regulation	●
X Series	E83	INSTR Instrument cluster	●
X Series	E83	LM Lights Module	●
X Series	E83	LWS Steering angle sensor	●
X Series	E83	MRS Multiple Restraint System V	●
X Series	E83	PDC Park Distance Control	●
X Series	E83	RAD Radio	●
X Series	E83	RDC Tyre pressure control	●
X Series	E83	RLS Rain/Light Sensor	●
X Series	E83	SHD Sliding/tilting sunroof	●
X Series	E83	SMF Seat memory, driver	●
X Series	E83	SMF Seat memory, driver	●
X Series	E83	SVT Servotronic	●
X Series	E83	TCU Telematic Control Unit	●
X Series	E83	VID Video module	●
X Series	E83	VTG Transfer case	●
Z Series	E85	ABS/ASC/DSC Dynamic Stability Control	●
Z Series	E85	CVM Convertible top module	●
Z Series	E85	DME Motor Electronics	●
Z Series	E85	DSP Digital Sound Processor	●
Z Series	E85	EPS Electronic Power Steering	●
Z Series	E85	EWS Vehicle immobilizer	●
Z Series	E85	GM5 General module 5	●
Z Series	E85	IHKS Integrated heating/air-conditioning control	●
Z Series	E85	INSTR Instrument cluster	●
Z Series	E85	LSZ Light switch centre II	●
Z Series	E85	LWS Steering angle sensor	●
Z Series	E85	PDC Park Distance Control	●
Z Series	E85	RAD Radio	●
Z Series	E85	RLS Rain/Light Sensor	●
Z Series	E85	SBSL Satellite, B-pillar, left	●
Z Series	E85	SBSR Satellite, B-pillar, right	●

Series	Model Series	Systems	Coding
Z Series	E85	SIM Safety and Information Module	●
Z Series	E85	SMF Seat memory, driver	●
Z Series	E85	SMF Seat memory, driver	●
Z Series	E85	STVL Satellite, door, front left	●
Z Series	E85	STVR Satellite, door, front right	●
Z Series	E85	TCU Telematic Control Unit	●
Z Series	E85	VID Video module	●
Z Series	E86	ABS/ASC/DSC Dynamic Stability Control	●
Z Series	E86	CVM Convertible top module	●
Z Series	E86	DME Motor Electronics	●
Z Series	E86	DSP Digital Sound Processor	●
Z Series	E86	EPS Electronic Power Steering	●
Z Series	E86	EWS Vehicle immobilizer	●
Z Series	E86	GM5 General module 5	●
Z Series	E86	IHKS Integrated heating/air-conditioning control	●
Z Series	E86	INSTR Instrument cluster	●
Z Series	E86	LSZ Light switch centre II	●
Z Series	E86	LWS Steering angle sensor	●
Z Series	E86	PDC Park Distance Control	●
Z Series	E86	RAD Radio	●
Z Series	E86	RLS Rain/Light Sensor	●
Z Series	E86	SBSL Satellite, B-pillar, left	●
Z Series	E86	SBSR Satellite, B-pillar, right	●
Z Series	E86	SIM Safety and Information Module	●
Z Series	E86	SMF Seat memory, driver	●
Z Series	E86	SMF Seat memory, driver	●
Z Series	E86	STVL Satellite, door, front left	●
Z Series	E86	STVR Satellite, door, front right	●
Z Series	E86	TCU Telematic Control Unit	●
Z Series	E86	VID Video module	●
Z Series	E89	ABS/ASC/DSC Dynamic Stability Control	●
Z Series	E89	CA Comfort access system	●
Z Series	E89	CIC Car Information Computer	●
Z Series	E89	CID Central Information Display	●
Z Series	E89	CON Controller	●
Z Series	E89	CTM Convertible-top module	●
Z Series	E89	DME Motor Electronics	●
Z Series	E89	DVDC DVD Changer	●
Z Series	E89	DWA anti-theft alarm system	●
Z Series	E89	EDC Damper Control	●
Z Series	E89	EGS 6HPTU transmission control	●
Z Series	E89	EKPS Fuel-pump control	●
Z Series	E89	EMF Parking brake	●
Z Series	E89	EPS Electronic Power Steering	●
Z Series	E89	EPS Electronic Power Steering	●
Z Series	E89	FLA High Beam Assist	●
Z Series	E89	FRM2 Footwell module 2	●
Z Series	E89	FZD Function centre, roof	●
Z Series	E89	GWS Gear selector switch	●
Z Series	E89	IHKR Integrated heating/air-conditioning regulation	●
Z Series	E89	INSTR Instrument cluster	●
Z Series	E89	JBE2 Junction Box electronics	●
Z Series	E89	MOST system analysis	●
Z Series	E89	MRS Multiple Restraint System	●

Series	Model Series	Systems	Coding
Z Series	E89	PDC Park Distance Control	●
Z Series	E89	RAD Radio	●
Z Series	E89	RAD2-GW Gateway	●
Z Series	E89	SINE Siren and tilt sensor	●
Z Series	E89	SMFA Seat module, driver	●
Z Series	E89	TCU Telematic Control Unit	●
Z Series	E89	ULF-SBX-H Interface box High	●
Z Series	E89	VM Video Module	●
l Series	E81	ABS/ASC/DSC Dynamic Stability Control	●
l Series	E81	CA Comfort access system	●
l Series	E81	CIC Car Information Computer	●
l Series	E81	CID Central Information Display	●
l Series	E81	CON Controller	●
l Series	E81	CTM Convertible-top module	●
l Series	E81	DME Motor Electronics	●
l Series	E81	DVDC DVD Changer	●
l Series	E81	DWA anti-theft alarm system	●
l Series	E81	EDC Damper Control	●
l Series	E81	EGS 6HPTU transmission control	●
l Series	E81	EKPS Fuel-pump control	●
l Series	E81	EMF Parking brake	●
l Series	E81	EPS Electronic Power Steering	●
l Series	E81	EPS Electronic Power Steering	●
l Series	E81	FLA High Beam Assist	●
l Series	E81	FRM2 Footwell module 2	●
l Series	E81	FZD Function centre, roof	●
l Series	E81	GWS Gear selector switch	●
l Series	E81	IHKR Integrated heating/air-conditioning regulation	●
l Series	E81	INSTR Instrument cluster	●
l Series	E81	JBE2 Junction Box electronics	●
l Series	E81	MOST system analysis	●
l Series	E81	MRS Multiple Restraint System	●
l Series	E81	PDC Park Distance Control	●
l Series	E81	RAD Radio	●
l Series	E81	RAD2-GW Gateway	●
l Series	E81	SINE Siren and tilt sensor	●
l Series	E81	SMFA Seat module, driver	●
l Series	E81	TCU Telematic Control Unit	●
l Series	E81	ULF-SBX-H Interface box High	●
l Series	E81	VM Video Module	●
l Series	E82	ABS/ASC/DSC Dynamic Stability Control	●
l Series	E82	CA Comfort access system	●
l Series	E82	CIC Car Information Computer	●
l Series	E82	CID Central Information Display	●
l Series	E82	CON Controller	●
l Series	E82	CTM Convertible-top module	●
l Series	E82	DME Motor Electronics	●
l Series	E82	DVDC DVD Changer	●
l Series	E82	DWA anti-theft alarm system	●
l Series	E82	EDC Damper Control	●
l Series	E82	EGS 6HPTU transmission control	●
l Series	E82	EKPS Fuel-pump control	●
l Series	E82	EMF Parking brake	●
l Series	E82	EPS Electronic Power Steering	●

Series	Model Series	Systems	Coding
l Series	E82	EPS Electronic Power Steering	●
l Series	E82	FLA High Beam Assist	●
l Series	E82	FRM2 Footwell module 2	●
l Series	E82	FZD Function centre, roof	●
l Series	E82	GWS Gear selector switch	●
l Series	E82	IHKR Integrated heating/air-conditioning regulation	●
l Series	E82	INSTR Instrument cluster	●
l Series	E82	JBE2 Junction Box electronics	●
l Series	E82	MOST system analysis	●
l Series	E82	MRS Multiple Restraint System	●
l Series	E82	PDC Park Distance Control	●
l Series	E82	RAD Radio	●
l Series	E82	RAD2-GW Gateway	●
l Series	E82	SINE Siren and tilt sensor	●
l Series	E82	SMFA Seat module, driver	●
l Series	E82	TCU Telematic Control Unit	●
l Series	E82	ULF-SBX-H Interface box High	●
l Series	E82	VM Video Module	●
X Series	E84	ABS/ASC/DSC Dynamic Stability Control	●
X Series	E84	CA Comfort access system	●
X Series	E84	CIC Car Information Computer	●
X Series	E84	CID Central Information Display	●
X Series	E84	CON Controller	●
X Series	E84	CTM Convertible-top module	●
X Series	E84	DME Motor Electronics	●
X Series	E84	DVDC DVD Changer	●
X Series	E84	DWA anti-theft alarm system	●
X Series	E84	EDC Damper Control	●
X Series	E84	EGS 6HPTU transmission control	●
X Series	E84	EKPS Fuel-pump control	●
X Series	E84	EMF Parking brake	●
X Series	E84	EPS Electronic Power Steering	●
X Series	E84	EPS Electronic Power Steering	●
X Series	E84	FLA High Beam Assist	●
X Series	E84	FRM2 Footwell module 2	●
X Series	E84	FZD Function centre, roof	●
X Series	E84	GWS Gear selector switch	●
X Series	E84	IHKR Integrated heating/air-conditioning regulation	●
X Series	E84	INSTR Instrument cluster	●
X Series	E84	JBE2 Junction Box electronics	●
X Series	E84	MOST system analysis	●
X Series	E84	MRS Multiple Restraint System	●
X Series	E84	PDC Park Distance Control	●
X Series	E84	RAD Radio	●
X Series	E84	RAD2-GW Gateway	●
X Series	E84	SINE Siren and tilt sensor	●
X Series	E84	SMFA Seat module, driver	●
X Series	E84	TCU Telematic Control Unit	●
X Series	E84	ULF-SBX-H Interface box High	●
X Series	E84	VM Video Module	●
l Series	E87	ABS/ASC/DSC Dynamic Stability Control	●
l Series	E87	CA Comfort access system	●
l Series	E87	CIC Car Information Computer	●
l Series	E87	CID Central Information Display	●

Series	Model Series	Systems	Coding
1 Series	E87	CON Controller	●
1 Series	E87	CTM Convertible-top module	●
1 Series	E87	DME Motor Electronics	●
1 Series	E87	DVDC DVD Changer	●
1 Series	E87	DWA anti-theft alarm system	●
1 Series	E87	EDC Damper Control	●
1 Series	E87	EGS 6HPTU transmission control	●
1 Series	E87	EKPS Fuel-pump control	●
1 Series	E87	EMF Parking brake	●
1 Series	E87	EPS Electronic Power Steering	●
1 Series	E87	EPS Electronic Power Steering	●
1 Series	E87	FLA High Beam Assist	●
1 Series	E87	FRM2 Footwell module 2	●
1 Series	E87	FZD Function centre,roof	●
1 Series	E87	GWS Gear selector switch	●
1 Series	E87	IHKR Integrated heating/air-conditioning regulation	●
1 Series	E87	INSTR Instrument cluster	●
1 Series	E87	JBE2 Junction Box electronics	●
1 Series	E87	MOST system analysis	●
1 Series	E87	MRS Multiple Restraint System	●
1 Series	E87	PDC Park Distance Control	●
1 Series	E87	RAD Radio	●
1 Series	E87	RAD2-GW Gateway	●
1 Series	E87	SINE Siren and tilt sensor	●
1 Series	E87	SMFA Seat module,driver	●
1 Series	E87	TCU Telematic Control Unit	●
1 Series	E87	ULF-SBX-H Interface box High	●
1 Series	E87	VM Video Module	●
1 Series	E88	ABS/ASC/DSC Dynamic Stability Control	●
1 Series	E88	CA Comfort access system	●
1 Series	E88	CIC Car Information Computer	●
1 Series	E88	CID Central Information Display	●
1 Series	E88	CON Controller	●
1 Series	E88	CTM Convertible-top module	●
1 Series	E88	DME Motor Electronics	●
1 Series	E88	DVDC DVD Changer	●
1 Series	E88	DWA anti-theft alarm system	●
1 Series	E88	EDC Damper Control	●
1 Series	E88	EGS 6HPTU transmission control	●
1 Series	E88	EKPS Fuel-pump control	●
1 Series	E88	EMF Parking brake	●
1 Series	E88	EPS Electronic Power Steering	●
1 Series	E88	EPS Electronic Power Steering	●
1 Series	E88	FLA High Beam Assist	●
1 Series	E88	FRM2 Footwell module 2	●
1 Series	E88	FZD Function centre,roof	●
1 Series	E88	GWS Gear selector switch	●
1 Series	E88	IHKR Integrated heating/air-conditioning regulation	●
1 Series	E88	INSTR Instrument cluster	●
1 Series	E88	JBE2 Junction Box electronics	●
1 Series	E88	MOST system analysis	●
1 Series	E88	MRS Multiple Restraint System	●
1 Series	E88	PDC Park Distance Control	●
1 Series	E88	RAD Radio	●

Series	Model Series	Systems	Coding
1 Series	E88	RAD2-GW Gateway	●
1 Series	E88	SINE Siren and tilt sensor	●
1 Series	E88	SMFA Seat module, driver	●
1 Series	E88	TCU Telematic Control Unit	●
1 Series	E88	ULF-SBX-H Interface box High	●
1 Series	E88	VM Video Module	●
3 Series	E90	ABS/ASC/DSC Dynamic Stability Control	●
3 Series	E90	CA Comfort access system	●
3 Series	E90	CIC Car Information Computer	●
3 Series	E90	CID Central Information Display	●
3 Series	E90	CON Controller	●
3 Series	E90	CTM Convertible-top module	●
3 Series	E90	DME Motor Electronics	●
3 Series	E90	DVDC DVD Changer	●
3 Series	E90	DWA anti-theft alarm system	●
3 Series	E90	EDC Damper Control	●
3 Series	E90	EGS 6HPTU transmission control	●
3 Series	E90	EKPS Fuel-pump control	●
3 Series	E90	EMF Parking brake	●
3 Series	E90	EPS Electronic Power Steering	●
3 Series	E90	EPS Electronic Power Steering	●
3 Series	E90	FLA High Beam Assist	●
3 Series	E90	FRM2 Footwell module 2	●
3 Series	E90	FZD Function centre, roof	●
3 Series	E90	GWS Gear selector switch	●
3 Series	E90	IHKR Integrated heating/air-conditioning regulation	●
3 Series	E90	INSTR Instrument cluster	●
3 Series	E90	JBE2 Junction Box electronics	●
3 Series	E90	MOST system analysis	●
3 Series	E90	MRS Multiple Restraint System	●
3 Series	E90	PDC Park Distance Control	●
3 Series	E90	RAD Radio	●
3 Series	E90	RAD2-GW Gateway	●
3 Series	E90	SINE Siren and tilt sensor	●
3 Series	E90	SMFA Seat module, driver	●
3 Series	E90	TCU Telematic Control Unit	●
3 Series	E90	ULF-SBX-H Interface box High	●
3 Series	E90	VM Video Module	●
3 Series	E91	ABS/ASC/DSC Dynamic Stability Control	●
3 Series	E91	CA Comfort access system	●
3 Series	E91	CIC Car Information Computer	●
3 Series	E91	CID Central Information Display	●
3 Series	E91	CON Controller	●
3 Series	E91	CTM Convertible-top module	●
3 Series	E91	DME Motor Electronics	●
3 Series	E91	DVDC DVD Changer	●
3 Series	E91	DWA anti-theft alarm system	●
3 Series	E91	EDC Damper Control	●
3 Series	E91	EGS 6HPTU transmission control	●
3 Series	E91	EKPS Fuel-pump control	●
3 Series	E91	EMF Parking brake	●
3 Series	E91	EPS Electronic Power Steering	●
3 Series	E91	EPS Electronic Power Steering	●
3 Series	E91	FLA High Beam Assist	●

Series	Model Series	Systems	Coding
3 Series	E91	FRM2 Footwell module 2	●
3 Series	E91	FZD Function centre, roof	●
3 Series	E91	GWS Gear selector switch	●
3 Series	E91	IHKR Integrated heating/air-conditioning regulation	●
3 Series	E91	INSTR Instrument cluster	●
3 Series	E91	JBE2 Junction Box electronics	●
3 Series	E91	MOST system analysis	●
3 Series	E91	MRS Multiple Restraint System	●
3 Series	E91	PDC Park Distance Control	●
3 Series	E91	RAD Radio	●
3 Series	E91	RAD2-GW Gateway	●
3 Series	E91	SINE Siren and tilt sensor	●
3 Series	E91	SMFA Seat module, driver	●
3 Series	E91	TCU Telematic Control Unit	●
3 Series	E91	ULF-SBX-H Interface box High	●
3 Series	E91	VM Video Module	●
3 Series	E92	ABS/ASC/DSC Dynamic Stability Control	●
3 Series	E92	CA Comfort access system	●
3 Series	E92	CIC Car Information Computer	●
3 Series	E92	CID Central Information Display	●
3 Series	E92	CON Controller	●
3 Series	E92	CTM Convertible-top module	●
3 Series	E92	DME Motor Electronics	●
3 Series	E92	DVDC DVD Changer	●
3 Series	E92	DWA anti-theft alarm system	●
3 Series	E92	EDC Damper Control	●
3 Series	E92	EGS 6HPTU transmission control	●
3 Series	E92	EKPS Fuel-pump control	●
3 Series	E92	EMF Parking brake	●
3 Series	E92	EPS Electronic Power Steering	●
3 Series	E92	EPS Electronic Power Steering	●
3 Series	E92	FLA High Beam Assist	●
3 Series	E92	FRM2 Footwell module 2	●
3 Series	E92	FZD Function centre, roof	●
3 Series	E92	GWS Gear selector switch	●
3 Series	E92	IHKR Integrated heating/air-conditioning regulation	●
3 Series	E92	INSTR Instrument cluster	●
3 Series	E92	JBE2 Junction Box electronics	●
3 Series	E92	MOST system analysis	●
3 Series	E92	MRS Multiple Restraint System	●
3 Series	E92	PDC Park Distance Control	●
3 Series	E92	RAD Radio	●
3 Series	E92	RAD2-GW Gateway	●
3 Series	E92	SINE Siren and tilt sensor	●
3 Series	E92	SMFA Seat module, driver	●
3 Series	E92	TCU Telematic Control Unit	●
3 Series	E92	ULF-SBX-H Interface box High	●
3 Series	E92	VM Video Module	●
3 Series	E93	ABS/ASC/DSC Dynamic Stability Control	●
3 Series	E93	CA Comfort access system	●
3 Series	E93	CIC Car Information Computer	●
3 Series	E93	CID Central Information Display	●
3 Series	E93	CON Controller	●
3 Series	E93	CTM Convertible-top module	●

Series	Model Series	Systems	Coding
3 Series	E93	DME Motor Electronics	●
3 Series	E93	DVDC DVD Changer	●
3 Series	E93	DWA anti-theft alarm system	●
3 Series	E93	EDC Damper Control	●
3 Series	E93	EGS 6HPTU transmission control	●
3 Series	E93	EKPS Fuel-pump control	●
3 Series	E93	EMF Parking brake	●
3 Series	E93	EPS Electronic Power Steering	●
3 Series	E93	EPS Electronic Power Steering	●
3 Series	E93	FLA High Beam Assist	●
3 Series	E93	FRM2 Footwell module 2	●
3 Series	E93	FZD Function centre, roof	●
3 Series	E93	GWS Gear selector switch	●
3 Series	E93	IHKR Integrated heating/air-conditioning regulation	●
3 Series	E93	INSTR Instrument cluster	●
3 Series	E93	JBE2 Junction Box electronics	●
3 Series	E93	MOST system analysis	●
3 Series	E93	MRS Multiple Restraint System	●
3 Series	E93	PDC Park Distance Control	●
3 Series	E93	RAD Radio	●
3 Series	E93	RAD2-GW Gateway	●
3 Series	E93	SINE Siren and tilt sensor	●
3 Series	E93	SMFA Seat module, driver	●
3 Series	E93	TCU Telematic Control Unit	●
3 Series	E93	ULF-SBX-H Interface box High	●
3 Series	E93	VM Video Module	●
7 Series	F001/F002/F004	JBE Junction-box electronics	●
7 Series	F001/F002/F004	ACSM Crash Safety Module	●
7 Series	F001/F002/F004	SZL Switch centre, steering column	●
7 Series	F001/F002/F004	TR SVC allround-view camera	●
7 Series	F001/F002/F004	SME Accumulator-management electronics	●
7 Series	F001/F002/F004	SWW Lane change warning	●
7 Series	F001/F002/F004	SVT Servotronic	●
7 Series	F001/F002/F004	DME Digital Motor Electronics	●
7 Series	F001/F002/F004	DME Digital Motor Electronics 2	●
7 Series	F001/F002/F004	AL active steering	●
7 Series	F001/F002/F004	EKPS Fuel-pump control	●
7 Series	F001/F002/F004	EGS transmission management	●
7 Series	F001/F002/F004	VTG Transfer case	●
7 Series	F001/F002/F004	ICM Integrated Chassis Management	●
7 Series	F001/F002/F004	RDC Tyre pressure control	●
7 Series	F001/F002/F004	ACC Active Cruise Control	●
7 Series	F001/F002/F004	RSE Rear Seat Entertainment	●
7 Series	F001/F002/F004	DSC Dynamic Stability Control	●
7 Series	F001/F002/F004	HSR Rear-axle slip-angle control	●
7 Series	F001/F002/F004	EPS Electronic Power Steering	●
7 Series	F001/F002/F004	DVDC DVD Changer	●
7 Series	F001/F002/F004	TBX Touchbox	●
7 Series	F001/F002/F004	CBX-MEDIA Combox Multimedia	●
7 Series	F001/F002/F004	AMPT Top Hi-Fi amplifier	●
7 Series	F001/F002/F004	EHC Electronic Ride-Height Control	●
7 Series	F001/F002/F004	VDM Vertical Dynamics Management	●
7 Series	F001/F002/F004	HUD Head-Up Display	●
7 Series	F001/F002/F004	CAS Car Access System	●

Series	Model Series	Systems	Coding
7 Series	F001/F002/F004	STML Headlight driver module, left	●
7 Series	F001/F002/F004	STMR Headlight driver module, right	●
7 Series	F001/F002/F004	LHML LED main light module, left	●
7 Series	F001/F002/F004	LHMR LED main light module, right	●
7 Series	F001/F002/F004	GZAL Targeted illumination, left	●
7 Series	F001/F002/F004	GZAR Targeted illumination, right	●
7 Series	F001/F002/F004	VM Video Module	●
7 Series	F001/F002/F004	EMALI Electric-motor reel, left	●
7 Series	F001/F002/F004	EMARE Electric-motor reel, right	●
7 Series	F001/F002/F004	ULF-SBX-H Interface box high	●
7 Series	F001/F002/F004	FZD Function centre, roof	●
7 Series	F001/F002/F004	NVE Night Vision Electronics	●
7 Series	F001/F002/F004	KAFAS Camera-based driver-assistance systems	●
7 Series	F001/F002/F004	GWS Gear selector switch	●
7 Series	F001/F002/F004	FLA High Beam Assist	●
7 Series	F001/F002/F004	INSTR Instrument cluster	●
7 Series	F001/F002/F004	CBX-ECALL Combox emergency call	●
7 Series	F001/F002/F004	CIC Car Information Computer	●
7 Series	F001/F002/F004	PDC Park Distance Control	●
7 Series	F001/F002/F004	CON Controller	●
7 Series	F001/F002/F004	FCON Rear compartment controller	●
7 Series	F001/F002/F004	SMFAH Seat module, driver's side, rear	●
7 Series	F001/F002/F004	SMBFH Seat module, passenger's side, rear	●
7 Series	F001/F002/F004	HKL Rear-lid lift	●
7 Series	F001/F002/F004	SMFA Seat module, driver	●
7 Series	F001/F002/F004	SMBF Seat module, passenger	●
7 Series	F001/F002/F004	AHM Trailer module	●
7 Series	F001/F002/F004	FRM Footwell module	●
7 Series	F001/F002/F004	CID Central Information Display	●
7 Series	F001/F002/F004	FD Rear-compartment display	●
7 Series	F001/F002/F004	FD2 Rear-compartment display 2	●
7 Series	F001/F002/F004	IHKA Integrated automatic heating/air conditioning	●
7 Series	F001/F002/F004	FKA Rear heater/air conditioning	●
7 Series	F001/F002/F004	EDCSVL Damper satellite, front left	●
7 Series	F001/F002/F004	EDCSVR Damper satellite, front right	●
7 Series	F001/F002/F004	EDCSHL Damper satellite, rear left	●
7 Series	F001/F002/F004	EDCSHR Damper satellite, rear right	●
5 Series	F010/F011/F018	JBE Junction-box electronics	●
5 Series	F010/F011/F018	ACSM Crash Safety Module	●
5 Series	F010/F011/F018	SZL Switch centre, steering column	●
5 Series	F010/F011/F018	TRSVC allround-view camera	●
5 Series	F010/F011/F018	SME Accumulator-management electronics	●
5 Series	F010/F011/F018	SWW Lane change warning	●
5 Series	F010/F011/F018	HKL Automatic luggage compartment lid actuation	●
5 Series	F010/F011/F018	SVT Servotronic	●
5 Series	F010/F011/F018	GHAS Regulated differential lock	●
5 Series	F010/F011/F018	DME Digital Motor Electronics	●
5 Series	F010/F011/F018	DME Digital Motor Electronics 2	●
5 Series	F010/F011/F018	AL active steering	●
5 Series	F010/F011/F018	EKPS Fuel-pump control	●
5 Series	F010/F011/F018	EGS transmission management	●
5 Series	F010/F011/F018	VTG Transfer case	●
5 Series	F010/F011/F018	ICM Integrated Chassis Management	●
5 Series	F010/F011/F018	RDC Tyre pressure control	●

Series	Model Series	Systems	Coding
5 Series	F010/F011/F018	ACC Active Cruise Control	●
5 Series	F010/F011/F018	CTM Convertible-top module	●
5 Series	F010/F011/F018	RSE Rear Seat Entertainment	●
5 Series	F010/F011/F018	DSC Dynamic Stability Control	●
5 Series	F010/F011/F018	EMF Parking brake	●
5 Series	F010/F011/F018	HSR Rear-axle slip-angle control	●
5 Series	F010/F011/F018	PMA Parking assistant	●
5 Series	F010/F011/F018	EPS Electronic Power Steering	●
5 Series	F010/F011/F018	DVDC DVD Changer	●
5 Series	F010/F011/F018	CBX-MEDIA Combox Multimedia	●
5 Series	F010/F011/F018	AMPT Top Hi-Fi amplifier	●
5 Series	F010/F011/F018	EHC Electronic Ride-Height Control	●
5 Series	F010/F011/F018	VDM Vertical Dynamics Management	●
5 Series	F010/F011/F018	HUD Head-Up Display	●
5 Series	F010/F011/F018	ASD Active Sound Design	●
5 Series	F010/F011/F018	CAS Car Access System	●
5 Series	F010/F011/F018	VM Video Module	●
5 Series	F010/F011/F018	EMALI Electric-motor reel, left	●
5 Series	F010/F011/F018	EMARE Electric-motor reel, right	●
5 Series	F010/F011/F018	SINE Siren and tilt sensor	●
5 Series	F010/F011/F018	ULF-SBX-H Interface box high	●
5 Series	F010/F011/F018	FZD Function centre, roof	●
5 Series	F010/F011/F018	NVE Night Vision Electronics	●
5 Series	F010/F011/F018	KAFAS Camera-based driver-assistance systems	●
5 Series	F010/F011/F018	GWS Gear selector switch	●
5 Series	F010/F011/F018	FLA High Beam Assist	●
5 Series	F010/F011/F018	INSTR Instrument cluster	●
5 Series	F010/F011/F018	CBX-ECALL Combox emergency call	●
5 Series	F010/F011/F018	CIC Car Information Computer	●
5 Series	F010/F011/F018	PDC Park Distance Control	●
5 Series	F010/F011/F018	CON Controller	●
5 Series	F010/F011/F018	HKL Rear-lid lift	●
5 Series	F010/F011/F018	SMFA Seat module, driver	●
5 Series	F010/F011/F018	SMBF Seat module, passenger	●
5 Series	F010/F011/F018	AHM Trailer module	●
5 Series	F010/F011/F018	FRM Footwell module	●
5 Series	F010/F011/F018	CID Central Information Display	●
5 Series	F010/F011/F018	FD Rear-compartment display	●
5 Series	F010/F011/F018	FD2 Rear-compartment display 2	●
5 Series	F010/F011/F018	VDM2 Vertical dynamics management	●
5 Series	F010/F011/F018	IHKA Integrated automatic heating/air conditioning	●
5 Series	F010/F011/F018	FKA Rear heater/air conditioning	●
5 Series	F010/F011/F018	EDCSVL Damper satellite, front left	●
5 Series	F010/F011/F018	EDCSVR Damper satellite, front right	●
5 Series	F010/F011/F018	EDCSHL Damper satellite, rear left	●
5 Series	F010/F011/F018	EDCSHR Damper satellite, rear right	●
1 Series	F020/F021	ACSM Crash Safety Module	●
1 Series	F020/F021	TRSVCA allround-view camera	●
1 Series	F020/F021	SME Accumulator-management electronics	●
1 Series	F020/F021	SWW Lane change warning	●
1 Series	F020/F021	HKL Automatic luggage compartment lid actuation	●
1 Series	F020/F021	GHAS Regulated differential lock	●
1 Series	F020/F021	DME Digital Motor Electronics	●
1 Series	F020/F021	EKPS Fuel-pump control	●

Series	Model Series	Systems	Coding
1 Series	F020/F021	EGS transmission management	●
1 Series	F020/F021	VTG Transfer case	●
1 Series	F020/F021	ICM Integrated Chassis Management	●
1 Series	F020/F021	ACC Active Cruise Control	●
1 Series	F020/F021	CTM Convertible-top module	●
1 Series	F020/F021	DSC Dynamic Stability Control	●
1 Series	F020/F021	PMA Parking assistant	●
1 Series	F020/F021	EPS Electronic Power Steering	●
1 Series	F020/F021	DVDC DVD Changer	●
1 Series	F020/F021	CBX-MEDIA Combox Multimedia	●
1 Series	F020/F021	AMPT Top Hi-Fi amplifier	●
1 Series	F020/F021	ASD Active Sound Design	●
1 Series	F020/F021	CAS Car Access System	●
1 Series	F020/F021	VM Video Module	●
1 Series	F020/F021	EMALI Electric-motor reel, left	●
1 Series	F020/F021	EMARE Electric-motor reel, right	●
1 Series	F020/F021	SINE Siren and tilt sensor	●
1 Series	F020/F021	FZD Function centre, roof	●
1 Series	F020/F021	KAFAS Camera-based driver-assistance systems	●
1 Series	F020/F021	FLA High Beam Assist	●
1 Series	F020/F021	INSTR Instrument cluster	●
1 Series	F020/F021	CBX-ECALL Combox emergency call	●
1 Series	F020/F021	CIC Car Information Computer	●
1 Series	F020/F021	CON Controller	●
1 Series	F020/F021	SMFA Seat module, driver	●
1 Series	F020/F021	SMBF Seat module, passenger	●
1 Series	F020/F021	AHM Trailer module	●
1 Series	F020/F021	FRM Footwell module	●
1 Series	F020/F021	VDM2 Vertical dynamics management	●
1 Series	F020/F021	IHKA Integrated automatic heating/air conditioning	●
5 Series	F007	JBE Junction-box electronics	●
5 Series	F007	ACSM Crash Safety Module	●
5 Series	F007	SZL Switch centre, steering column	●
5 Series	F007	TR SVC allround-view camera	●
5 Series	F007	SME Accumulator-management electronics	●
5 Series	F007	SWW Lane change warning	●
5 Series	F007	SVT Servotronic	●
5 Series	F007	DME Digital Motor Electronics	●
5 Series	F007	DME Digital Motor Electronics 2	●
5 Series	F007	AL active steering	●
5 Series	F007	EKPS Fuel-pump control	●
5 Series	F007	EGS transmission management	●
5 Series	F007	VTG Transfer case	●
5 Series	F007	ICM Integrated Chassis Management	●
5 Series	F007	RDC Tyre pressure control	●
5 Series	F007	ACC Active Cruise Control	●
5 Series	F007	RSE Rear Seat Entertainment	●
5 Series	F007	DSC Dynamic Stability Control	●
5 Series	F007	HSR Rear-axle slip-angle control	●
5 Series	F007	EPS Electronic Power Steering	●
5 Series	F007	DVDC DVD Changer	●
5 Series	F007	TBX Touchbox	●
5 Series	F007	CBX-MEDIA Combox Multimedia	●
5 Series	F007	AMPT Top Hi-Fi amplifier	●

Series	Model Series	Systems	Coding
5 Series	F007	EHC Electronic Ride-Height Control	●
5 Series	F007	VDM Vertical Dynamics Management	●
5 Series	F007	HUD Head-Up Display	●
5 Series	F007	CAS Car Access System	●
5 Series	F007	STML Headlight driver module, left	●
5 Series	F007	STMR Headlight driver module, right	●
5 Series	F007	LHML LED main light module, left	●
5 Series	F007	LHMR LED main light module, right	●
5 Series	F007	GZAL Targeted illumination, left	●
5 Series	F007	GZAR Targeted illumination, right	●
5 Series	F007	VM Video Module	●
5 Series	F007	EMALI Electric-motor reel, left	●
5 Series	F007	EMARE Electric-motor reel, right	●
5 Series	F007	ULF-SBX-H Interface box high	●
5 Series	F007	FZD Function centre, roof	●
5 Series	F007	NVE Night Vision Electronics	●
5 Series	F007	KAFAS Camera-based driver-assistance systems	●
5 Series	F007	GWS Gear selector switch	●
5 Series	F007	FLA High Beam Assist	●
5 Series	F007	INSTR Instrument cluster	●
5 Series	F007	CBX-ECALL Combox emergency call	●
5 Series	F007	CIC Car Information Computer	●
5 Series	F007	PDC Park Distance Control	●
5 Series	F007	CON Controller	●
5 Series	F007	FCON Rear compartment controller	●
5 Series	F007	SMFAH Seat module, driver's side, rear	●
5 Series	F007	SMBFH Seat module, passenger's side, rear	●
5 Series	F007	HKL Rear-lid lift	●
5 Series	F007	SMFA Seat module, driver	●
5 Series	F007	SMBF Seat module, passenger	●
5 Series	F007	AHM Trailer module	●
5 Series	F007	FRM Footwell module	●
5 Series	F007	CID Central Information Display	●
5 Series	F007	FD Rear-compartment display	●
5 Series	F007	FD2 Rear-compartment display 2	●
5 Series	F007	IHKA Integrated automatic heating/air conditioning	●
5 Series	F007	FKA Rear heater/air conditioning	●
5 Series	F007	EDCSVL Damper satellite, front left	●
5 Series	F007	EDCSVR Damper satellite, front right	●
5 Series	F007	EDCSHL Damper satellite, rear left	●
5 Series	F007	EDCSHR Damper satellite, rear right	●
6 Series	F006/F012/F013	JBE Junction-box electronics	●
6 Series	F006/F012/F013	ACSM Crash Safety Module	●
6 Series	F006/F012/F013	SZL Switch centre, steering column	●
6 Series	F006/F012/F013	TR SVC allround-view camera	●
6 Series	F006/F012/F013	SME Accumulator-management electronics	●
6 Series	F006/F012/F013	SWW Lane change warning	●
6 Series	F006/F012/F013	HKL Automatic luggage compartment lid actuation	●
6 Series	F006/F012/F013	SVT Servotronic	●
6 Series	F006/F012/F013	GHAS Regulated differential lock	●
6 Series	F006/F012/F013	DME Digital Motor Electronics	●
6 Series	F006/F012/F013	DME Digital Motor Electronics 2	●
6 Series	F006/F012/F013	AL active steering	●
6 Series	F006/F012/F013	EKPS Fuel-pump control	●

Series	Model Series	Systems	Coding
6 Series	F006/F012/F013	EGS transmission management	●
6 Series	F006/F012/F013	VTG Transfer case	●
6 Series	F006/F012/F013	ICM Integrated Chassis Management	●
6 Series	F006/F012/F013	RDC Tyre pressure control	●
6 Series	F006/F012/F013	ACC Active Cruise Control	●
6 Series	F006/F012/F013	CTM Convertible-top module	●
6 Series	F006/F012/F013	RSE Rear Seat Entertainment	●
6 Series	F006/F012/F013	DSC Dynamic Stability Control	●
6 Series	F006/F012/F013	EMF Parking brake	●
6 Series	F006/F012/F013	HSR Rear-axle slip-angle control	●
6 Series	F006/F012/F013	PMA Parking assistant	●
6 Series	F006/F012/F013	EPS Electronic Power Steering	●
6 Series	F006/F012/F013	DVDC DVD Changer	●
6 Series	F006/F012/F013	CBX-MEDIA Combox Multimedia	●
6 Series	F006/F012/F013	AMPT Top Hi-Fi amplifier	●
6 Series	F006/F012/F013	EHC Electronic Ride-Height Control	●
6 Series	F006/F012/F013	VDM Vertical Dynamics Management	●
6 Series	F006/F012/F013	HUD Head-Up Display	●
6 Series	F006/F012/F013	ASD Active Sound Design	●
6 Series	F006/F012/F013	CAS Car Access System	●
6 Series	F006/F012/F013	VM Video Module	●
6 Series	F006/F012/F013	EMALI Electric-motor reel, left	●
6 Series	F006/F012/F013	EMARE Electric-motor reel, right	●
6 Series	F006/F012/F013	SINE Siren and tilt sensor	●
6 Series	F006/F012/F013	ULF-SBX-H Interface box high	●
6 Series	F006/F012/F013	FZD Function centre, roof	●
6 Series	F006/F012/F013	NVE Night Vision Electronics	●
6 Series	F006/F012/F013	KAFAS Camera-based driver-assistance systems	●
6 Series	F006/F012/F013	GWS Gear selector switch	●
6 Series	F006/F012/F013	FLA High Beam Assist	●
6 Series	F006/F012/F013	INSTR Instrument cluster	●
6 Series	F006/F012/F013	CBX-ECALL Combox emergency call	●
6 Series	F006/F012/F013	CIC Car Information Computer	●
6 Series	F006/F012/F013	PDC Park Distance Control	●
6 Series	F006/F012/F013	CON Controller	●
6 Series	F006/F012/F013	HKL Rear-lid lift	●
6 Series	F006/F012/F013	SMFA Seat module, driver	●
6 Series	F006/F012/F013	SMBF Seat module, passenger	●
6 Series	F006/F012/F013	AHM Trailer module	●
6 Series	F006/F012/F013	FRM Footwell module	●
6 Series	F006/F012/F013	CID Central Information Display	●
6 Series	F006/F012/F013	FD Rear-compartment display	●
6 Series	F006/F012/F013	FD2 Rear-compartment display 2	●
6 Series	F006/F012/F013	VDM2 Vertical dynamics management	●
6 Series	F006/F012/F013	IHKA Integrated automatic heating/air conditioning	●
6 Series	F006/F012/F013	FKA Rear heater/air conditioning	●
6 Series	F006/F012/F013	EDCSVL Damper satellite, front left	●
6 Series	F006/F012/F013	EDCSVR Damper satellite, front right	●
6 Series	F006/F012/F013	EDCSHL Damper satellite, rear left	●
6 Series	F006/F012/F013	EDCSHR Damper satellite, rear right	●
2 Series	F022	ACSM Crash Safety Module	●
2 Series	F022	TR SVC allround-view camera	●
2 Series	F022	SME Accumulator-management electronics	●
2 Series	F022	SWW Lane change warning	●

Series	Model Series	Systems	Coding
2 Series	F022	HKL Automatic luggage compartment lid actuation	●
2 Series	F022	GHAS Regulated differential lock	●
2 Series	F022	DME Digital Motor Electronics	●
2 Series	F022	EKPS Fuel-pump control	●
2 Series	F022	EGS transmission management	●
2 Series	F022	VTG Transfer case	●
2 Series	F022	ICM Integrated Chassis Management	●
2 Series	F022	ACC Active Cruise Control	●
2 Series	F022	CTM Convertible-top module	●
2 Series	F022	DSC Dynamic Stability Control	●
2 Series	F022	PMA Parking assistant	●
2 Series	F022	EPS Electronic Power Steering	●
2 Series	F022	DVDC DVD Changer	●
2 Series	F022	CBX-MEDIA Combox Multimedia	●
2 Series	F022	AMPT Top Hi-Fi amplifier	●
2 Series	F022	ASD Active Sound Design	●
2 Series	F022	CAS Car Access System	●
2 Series	F022	VM Video Module	●
2 Series	F022	EMALI Electric-motor reel, left	●
2 Series	F022	EMARE Electric-motor reel, right	●
2 Series	F022	SINE Siren and tilt sensor	●
2 Series	F022	FZD Function centre, roof	●
2 Series	F022	KAFAS Camera-based driver-assistance systems	●
2 Series	F022	FLA High Beam Assist	●
2 Series	F022	INSTR Instrument cluster	●
2 Series	F022	CBX-ECALL Combox emergency call	●
2 Series	F022	CIC Car Information Computer	●
2 Series	F022	CON Controller	●
2 Series	F022	SMFA Seat module, driver	●
2 Series	F022	SMBF Seat module, passenger	●
2 Series	F022	AHM Trailer module	●
2 Series	F022	FRM Footwell module	●
2 Series	F022	VDM2 Vertical dynamics management	●
2 Series	F022	IHKA Integrated automatic heating/air conditioning	●
3 Series	F030/F031/F034/F035	ACSM Crash Safety Module	●
3 Series	F030/F031/F034/F035	TR SVC allround-view camera	●
3 Series	F030/F031/F034/F035	SME Accumulator-management electronics	●
3 Series	F030/F031/F034/F035	SWW Lane change warning	●
3 Series	F030/F031/F034/F035	HKL Automatic luggage compartment lid actuation	●
3 Series	F030/F031/F034/F035	GHAS Regulated differential lock	●
3 Series	F030/F031/F034/F035	DME Digital Motor Electronics	●
3 Series	F030/F031/F034/F035	EKPS Fuel-pump control	●
3 Series	F030/F031/F034/F035	EGS transmission management	●
3 Series	F030/F031/F034/F035	VTG Transfer case	●
3 Series	F030/F031/F034/F035	ICM Integrated Chassis Management	●
3 Series	F030/F031/F034/F035	ACC Active Cruise Control	●
3 Series	F030/F031/F034/F035	CTM Convertible-top module	●
3 Series	F030/F031/F034/F035	DSC Dynamic Stability Control	●
3 Series	F030/F031/F034/F035	PMA Parking assistant	●
3 Series	F030/F031/F034/F035	EPS Electronic Power Steering	●
3 Series	F030/F031/F034/F035	DVDC DVD Changer	●
3 Series	F030/F031/F034/F035	CBX-MEDIA Combox Multimedia	●
3 Series	F030/F031/F034/F035	AMPT Top Hi-Fi amplifier	●
3 Series	F030/F031/F034/F035	ASD Active Sound Design	●

Series	Model Series	Systems	Coding
3 Series	F030/F031/F034/F035	CAS Car Access System	●
3 Series	F030/F031/F034/F035	VM Video Module	●
3 Series	F030/F031/F034/F035	EMALI Electric-motor reel, left	●
3 Series	F030/F031/F034/F035	EMARE Electric-motor reel, right	●
3 Series	F030/F031/F034/F035	SINE Siren and tilt sensor	●
3 Series	F030/F031/F034/F035	FZD Function centre, roof	●
3 Series	F030/F031/F034/F035	KAFAS Camera-based driver-assistance systems	●
3 Series	F030/F031/F034/F035	FLA High Beam Assist	●
3 Series	F030/F031/F034/F035	INSTR Instrument cluster	●
3 Series	F030/F031/F034/F035	CBX-ECALL Combox emergency call	●
3 Series	F030/F031/F034/F035	CIC Car Information Computer	●
3 Series	F030/F031/F034/F035	CON Controller	●
3 Series	F030/F031/F034/F035	SMFA Seat module, driver	●
3 Series	F030/F031/F034/F035	SMBF Seat module, passenger	●
3 Series	F030/F031/F034/F035	AHM Trailer module	●
3 Series	F030/F031/F034/F035	FRM Footwell module	●
3 Series	F030/F031/F034/F035	VDM2 Vertical dynamics management	●
3 Series	F030/F031/F034/F035	IHKA Integrated automatic heating/air conditioning	●
4 Series	F032/F033	ACSM Crash Safety Module	●
4 Series	F032/F033	TR SVC allround-view camera	●
4 Series	F032/F033	SME Accumulator-management electronics	●
4 Series	F032/F033	SWW Lane change warning	●
4 Series	F032/F033	HKL Automatic luggage compartment lid actuation	●
4 Series	F032/F033	GHAS Regulated differential lock	●
4 Series	F032/F033	DME Digital Motor Electronics	●
4 Series	F032/F033	EKPS Fuel-pump control	●
4 Series	F032/F033	EGS transmission management	●
4 Series	F032/F033	VTG Transfer case	●
4 Series	F032/F033	ICM Integrated Chassis Management	●
4 Series	F032/F033	ACC Active Cruise Control	●
4 Series	F032/F033	CTM Convertible-top module	●
4 Series	F032/F033	DSC Dynamic Stability Control	●
4 Series	F032/F033	PMA Parking assistant	●
4 Series	F032/F033	EPS Electronic Power Steering	●
4 Series	F032/F033	DVDC DVD Changer	●
4 Series	F032/F033	CBX-MEDIA Combox Multimedia	●
4 Series	F032/F033	AMPT Top Hi-Fi amplifier	●
4 Series	F032/F033	ASD Active Sound Design	●
4 Series	F032/F033	CAS Car Access System	●
4 Series	F032/F033	VM Video Module	●
4 Series	F032/F033	EMALI Electric-motor reel, left	●
4 Series	F032/F033	EMARE Electric-motor reel, right	●
4 Series	F032/F033	SINE Siren and tilt sensor	●
4 Series	F032/F033	FZD Function centre, roof	●
4 Series	F032/F033	KAFAS Camera-based driver-assistance systems	●
4 Series	F032/F033	FLA High Beam Assist	●
4 Series	F032/F033	INSTR Instrument cluster	●
4 Series	F032/F033	CBX-ECALL Combox emergency call	●
4 Series	F032/F033	CIC Car Information Computer	●
4 Series	F032/F033	CON Controller	●
4 Series	F032/F033	SMFA Seat module, driver	●
4 Series	F032/F033	SMBF Seat module, passenger	●
4 Series	F032/F033	AHM Trailer module	●
4 Series	F032/F033	FRM Footwell module	●

Series	Model Series	Systems	Coding
4 Series	F032/F033	VDM2 Vertical dynamics management	●
4 Series	F032/F033	IHKA Integrated automatic heating/air conditioning	●
X Series	F015/F025	JBE Junction-box electronics	●
X Series	F015/F025	ACSM Crash Safety Module	●
X Series	F015/F025	TRVC allround-view camera	●
X Series	F015/F025	SWW Lane change warning	●
X Series	F015/F025	HKL Automatic luggage compartment lid actuation	●
X Series	F015/F025	SVT Servotronic	●
X Series	F015/F025	DME Digital Motor Electronics	●
X Series	F015/F025	DME Digital Motor Electronics 2	●
X Series	F015/F025	AL active steering	●
X Series	F015/F025	EKPS Fuel-pump control	●
X Series	F015/F025	EGS transmission management	●
X Series	F015/F025	VTG Transfer case	●
X Series	F015/F025	ICM Integrated Chassis Management	●
X Series	F015/F025	RDC Tyre pressure control	●
X Series	F015/F025	ACC Active Cruise Control	●
X Series	F015/F025	RSE Rear Seat Entertainment	●
X Series	F015/F025	DSC Dynamic Stability Control	●
X Series	F015/F025	EMF Parking brake	●
X Series	F015/F025	PMA Parking assistant	●
X Series	F015/F025	EPS Electronic Power Steering	●
X Series	F015/F025	DVDC DVD Changer	●
X Series	F015/F025	CBX-MEDIA Combox Multimedia	●
X Series	F015/F025	AMPT Top Hi-Fi amplifier	●
X Series	F015/F025	EHC Electronic Ride-Height Control	●
X Series	F015/F025	VDM Vertical Dynamics Management	●
X Series	F015/F025	HUD Head-Up Display	●
X Series	F015/F025	ASD Active Sound Design	●
X Series	F015/F025	CAS Car Access System	●
X Series	F015/F025	VM Video Module	●
X Series	F015/F025	EMALI Electric-motor reel, left	●
X Series	F015/F025	EMARE Electric-motor reel, right	●
X Series	F015/F025	FZD Function centre, roof	●
X Series	F015/F025	NVE Night Vision Electronics	●
X Series	F015/F025	KAFAS Camera-based driver-assistance systems	●
X Series	F015/F025	GWS Gear selector switch	●
X Series	F015/F025	FLA High Beam Assist	●
X Series	F015/F025	INSTR Instrument cluster	●
X Series	F015/F025	CBX-ECALL Combox emergency call	●
X Series	F015/F025	CIC Car Information Computer	●
X Series	F015/F025	PDC Park Distance Control	●
X Series	F015/F025	CON Controller	●
X Series	F015/F025	HKL Rear-lid lift	●
X Series	F015/F025	SMFA Seat module, driver	●
X Series	F015/F025	SMBF Seat module, passenger	●
X Series	F015/F025	AHM Trailer module	●
X Series	F015/F025	FRM Footwell module	●
X Series	F015/F025	CID Central Information Display	●
X Series	F015/F025	VDM2 Vertical dynamics management	●
X Series	F015/F025	IHKA Integrated automatic heating/air conditioning	●
X Series	F015/F025	FKA Rear heater/air conditioning	●