MaxiSys_Subaru_V1.80 Fuction List (Note:For reference only)

NOTES:

• This function is supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version.

As for special function please refer to the special function table.

System Name	Read Codes	Erase Codes	Live Data	Special Function
Engine Control System	•	•	•	0001, 0002, 0003, 0004, 0005
Transmission Control System	•	•	•	0005
Brake Control System	•	•	•	0006, 0007
Integ.unit mode	•	•	•	0008, 0009
Airbag System	•	•	0	0010
CAN SYSTEM	•	0	0	0011
Cruise Control System	•	0	•	0003
Keyless access system	•	•	•	
Power Steering System	•	•	•	0007
Tire Pressure Monitor	•	•	•	0013
Occupant Detection System	0	0	0	0012
Parking Brake System	•	•	•	0007, 0014
Air Condition System	•	•	•	0007, 0015, 0016