

MaxiSys_Maybach_V6.66 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F053 F069 F054 F0DA F0DB F0DC F0DD F0DE F0DF F0E0 F0E1 F0E2 F05D F05E F05F F0E3 F0E4 F063 F064 F062
Up to 08/2006	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F053 F054 F055 F056 F057 F058 F059 F05A F05B F05C F05D F05E F05F F060 F061 F062 F063 F064 F062 F002
Up to 08/2006	240	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F154
Up to 08/2006	240	Drive	SGR-Radar sensors control unit	●	●	●	●	●	●	○			
Up to 08/2006	240	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F0E7
Up to 08/2006	240	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
Up to 08/2006	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●		C067 C13F C04B	F009 F073 F00C F00D F00E F00F F04F F183
Up to 08/2006	240	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
Up to 08/2006	240	Chassis	SBC-Right Sensotronic Brake Control	●	●	●	●	●	○	○			
Up to 08/2006	240	Chassis	ESP-Electronic stability	●	●	●	●	●	●	●			F019
Up to 08/2006	240	Chassis	AIRmatic	●	●	●	●	●	○	●			F051 F0BF F113
Up to 08/2006	240	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●		C001	
Up to 08/2006	240	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
Up to 08/2006	240	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
Up to 08/2006	240	Body	AB-Airbag	●	●	●	●	●	●	○	●		C01C C01D C08C C023 C093 C094 C095 C01F C096 C097 C024 C062 C059 C098
Up to 08/2006	240	Body	WSS-Weight sensing system	●	●	●	●	●	○	○	●		
Up to 08/2006	240	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	○			
Up to 08/2006	240	Body	Dr-side SAM-Driver signal acquisition and actuation	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	240	Body	Rear SAM 1-Rear signal acquisition and actuation	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	Rear SAM 2-Rear signal acquisition and actuation	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
Up to 08/2006	240	Body	VBF (Front control panel)-Front control panel	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	BCG-Remote control (Rear control field)	●	●	●	●	●	○	●			F025
Up to 08/2006	240	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	CRN-Center roof node	●	●	○	●	●	○	●			
Up to 08/2006	240	Body	PSE-Pneumatic system equipment	●	●	●	●	●	○	●			
Up to 08/2006	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A6	F110
Up to 08/2006	240	Body	System diagnosis (CAN)	●	●	●	●	○	●	○			
Up to 08/2006	240	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
Up to 08/2006	240	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 08/2006	240	Information and communication	ICM-Instrument cluster	●	●	●	●	●	○	●			
Up to 08/2006	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 08/2006	240	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 08/2006	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
Up to 08/2006	240	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 08/2006	240	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
Up to 08/2006	240	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C099 C0A7	
Up to 08/2006	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
Up to 08/2006	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 08/2006	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●			
Up to 08/2006	240	Information and communication	TV-TV tuner(REAR)	●	●	○	●	●	●	○			
Up to 08/2006	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	CDC-CD changer(REAR)	●	●	○	●	●	●	○			
Up to 08/2006	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○	○			
Up to 08/2006	240	Information and communication	KTR-Right headphone transmitter	●	●	○	●	●	○	○			
Up to 08/2006	240	Information and communication	GPS box	●	●	○	●	●	●	○			
Up to 08/2006	240	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	240	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 08/2006	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 08/2006	240	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	●	●	○	●	●	●	●			
Up to 08/2006	240	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	○	●	●	○	●			
Up to 08/2006	240	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●			
Up to 08/2006	240	Seats and doors	PWC-Partition wall control module	●	●	●	●	●	○	○			
Up to 08/2006	240	Seats and doors	LDCA-Electric left door closing assist	●	●	●	●	●	●	○			
Up to 08/2006	240	Seats and doors	RDCA-Electric right door closing assist	●	●	●	●	●	●	○			
Up to 08/2006	240	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	240	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	○	●			F025
Up to 08/2006	240	Air conditioning	REAR AC-Rear air conditioning	●	●	●	●	●	○	●			
Up to 08/2006	240	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F10B
Up to 08/2006	240	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●	●		F025
As of 09/2006	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F053 F069 F054 F0DA F0DB F0DC F0DD F0DE F0DF F0E0 F0E1 F0E2 F05D F05E F05F F0E3 F0E4 F063 F064 F062
As of 09/2006	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F053 F054 F055 F056 F057 F058 F059 F05A F05B F05C F05D F05E F05F F060 F061 F062 F063 F064 F062 F002
As of 09/2006	240	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F154
As of 09/2006	240	Drive	SGR-Radar sensors control unit	●	●	●	●	●	●	○			
As of 09/2006	240	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
As of 09/2006	240	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●			F011 F075 F008 F009 F00B F130 F073 F131 F07C F07F F132 F091
As of 09/2006	240	Drive	FSCU-Fuel pump	●	●	●	●	○	●	●		C066	
As of 09/2006	240	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
As of 09/2006	240	Chassis	SBC-Right Sensotronic Brake Control	●	●	●	●	●	○	○			
As of 09/2006	240	Chassis	ESP-Electronic stability	●	●	●	●	●	●	●			F019
As of 09/2006	240	Chassis	AIRmatic	●	●	●	●	●	○	●			F051 F0BF F113
As of 09/2006	240	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●		C001	
As of 09/2006	240	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
As of 09/2006	240	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
As of 09/2006	240	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C060 C094 C023 C097 C020 C01F C0E5 C141 C024 C062	
As of 09/2006	240	Body	WSS-Weight sensing system	●	●	●	●	●	○	○	●		
As of 09/2006	240	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	○			
As of 09/2006	240	Body	Dr-side SAM-Driver signal acquisition and actuation	●	●	●	●	●	○	●			
As of 09/2006	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2006	240	Body	Rear SAM 1-Rear signal acquisition and actuation	●	●	●	●	●	○	●			
As of 09/2006	240	Body	Rear SAM 2-Rear signal acquisition and actuation	●	●	●	●	●	○	●			
As of 09/2006	240	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 09/2006	240	Body	VBF (Front control panel)-Front control panel	●	●	●	●	●	○	●			
As of 09/2006	240	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●			
As of 09/2006	240	Body	BCG-Remote control (Rear control field)	●	●	●	●	●	○	●			F025
As of 09/2006	240	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
As of 09/2006	240	Body	CRN-Center roof node	●	●	○	●	●	○	●			
As of 09/2006	240	Body	PSE-Pneumatic system equipment	●	●	●	●	●	○	●			
As of 09/2006	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A6	F110
As of 09/2006	240	Body	System diagnosis (CAN)	●	●	●	●	○	●	○			
As of 09/2006	240	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 09/2006	240	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 09/2006	240	Information and communication	ICM-Instrument cluster	●	●	●	●	●	○	●			
As of 09/2006	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 09/2006	240	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 09/2006	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2006	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 09/2006	240	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 09/2006	240	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 09/2006	240	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C099 C0A7	
As of 09/2006	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
As of 09/2006	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 09/2006	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●			
As of 09/2006	240	Information and communication	TV-TV tuner(REAR)	●	●	○	●	●	●	○			
As of 09/2006	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	CDC-CD changer(REAR)	●	●	○	●	●	●	○			
As of 09/2006	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○	○			
As of 09/2006	240	Information and communication	KTR-Right headphone transmitter	●	●	○	●	●	○	○			
As of 09/2006	240	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 09/2006	240	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			

Model year	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2006	240	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 09/2006	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 09/2006	240	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	●	●	○	●	●	●	●			
As of 09/2006	240	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	○	●	●	○	●			
As of 09/2006	240	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●			
As of 09/2006	240	Seats and doors	PWC-Partition wall control module	●	●	●	●	●	○	○			
As of 09/2006	240	Seats and doors	LDCA-Electric left door closing assist	●	●	●	●	●	●	○			
As of 09/2006	240	Seats and doors	RDCA-Electric right door closing assist	●	●	●	●	●	●	○			
As of 09/2006	240	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	

Specil_Function

Index	Specil Function Name	Index	Specil Function Name
F001	Operational check	F002	Switch off solenoid valve for torque converter lockup clutch.
F003	Actual values of flush counter	F004	Actual values: Oil level check
F005	Oil color and oil smell	F006	Abrasion in transmission oil
F007	Learning of the throttle valve stop	F008	Activate fuel pump.
F009	Teach in of drive authorization system	F00A	Performing sensor rotor adaptation
F00B	Resetting of mixture adaptation	F00C	Ignition
F00D	Fuel quantity	F00E	Idling specified speed with selector lever in position P or N
F00F	Idling specified speed with gear engaged	F010	Electric suction fan for engine or air
F011	Variant coding	F012	Extension of run-on time
F013	Adjustment of injector injection quantities	F014	Reset quantity mean value adaptation data.
F015	Replace component Diesel particulate filter.	F016	Regeneration of diesel particulate filter when driving
F017	Diesel particulate filter Used Program	F018	Standstill test
F019	Road test	F01A	Tire pressure loss warner
F01B	Vehicle data	F01C	Modification year or model year
F01D	All codes	F01E	Disable key or key track.
F01F	Once again authorize key or key track.	F020	Program replacement keys.
F021	Activate control module N73 (EIS [EZS] control unit).	F022	Activate control module N26/5 (Electric steering lock control module).
F023	Writing of the VIN	F024	Carry out control unit reset.
F025	Read coding and change if necessary.	F026	Zero position adjustment
F027	Set reading of main odometer.	F028	Setting days since initial registration
F029	ASSYST settings	F02A	Control module reset
F02B	Special equipment	F02C	Internal ASSYST PLUS data
F02D	Configuration of oil grade selection	F02E	Restart of optical ring
F02F	Normalizing of positioning motors	F030	Check of adjustment range of positioning
F031	Teach-in of actuator motors after actuator motor replacement	F032	Breaking-in procedure after replacement of refrigerant compressor
F033	Teach-in process after replacement of component Diesel particulate filter	F034	Teaching in the diesel particulate filter after replacing the engine control unit
F035	Teach-in of diesel particulate filter after replacement of engine control unit without transfer of values	F036	Teach-in process after replacement of component B28/8 (Pressure differential sensor (DPF))
F037	Teach-in process after replacement of component G3/1 (O2 sensor downstream TWC)	F038	Teach-in process after replacement of component Y74 (Pressure control valve)
F039	Teach-in process after replacement of component Y100/2 (Boost pressure regulator)	F03A	Reset values for HFM drift compensation.
F03B	Resetting air filter learned values after air filter replacement	F03C	Changing the language version(LINGUATRONIC)
F03D	Program brake assist	F03E	CO2 setting
F03F	Maximum governed speed	F040	Test terminal 15 connection from and .
F041	M12/1s3 (Down final shutoff microswitch)	F042	Air exit temperature at rear roof
F043	Resetting adaptation values	F044	Retarder specified torque
F045	Test cable - and switch for , repair or replace if necessary.	F046	Both fuses o.k.?
F047	'PTO' solenoid valves	F048	The actual value indicates the current status of the starter lockout ().
F049	Screw connections of unit pumps for cylinders Switch on rear lamps. to	F04A	Calibration
F04B	Premature flame detection	F04C	Program CNG compressed natural gas Mode
F04D	Resetting of mixture adaptation(CNG compressed natural gas)	F04E	Idle speed set value
F04F	CO setting for vehicles without TWC	F050	CO setting for vehicles without TWC(Natural
F051	Initial startup with automatic takeover of settings of previous control unit	F052	Initial startup with manual settings input for new control unit,For example: The previous control unit can no longer be
F053	Definition	F054	Important information on adaptation limit
F055	Adaptation values of shift :1-2:	F056	Adaptation values of shift :2-3:
F057	Adaptation values of shift :3-4:	F058	Adaptation values of shift :4-5:
F059	Adaptation values of shift :5-4:	F05A	Adaptation values of shift :4-3:

Index	Specil Function Name	Index	Specil Function Name
F05B	Adaptation values of shift :3-2:	F05C	Adaptation values of shift :2-1:
F05D	Display all adaptation data.	F05E	Resetting of adaptation data
F05F	Performing adaptation	F060	Adaptation via coolant temperature
F061	Adaptation via torque ranges	F062	Help
F063	Warranty or goodwill processing	F064	Actual values: Oil level check
F065	Switch off the incline recognition for dynamometer mode.	F066	Detach the transport protection of control module ETC, personalize or activate the
F067	Learning process: Y3/8sl (Selection range sensor (VGS))	F068	Learning to the drive authorization system
F069	Assignment of hydraulic shift elements	F06A	Resetting of adaptation data(Torque converter lockup clutch)
F06B	Adaptation of torque converter lockup	F06C	Performing adaptation(Wet start-off clutch
F06D	Upshifts	F06E	Downshifts
F06F	Reverse gear	F070	Learning of the recirculated air flap stop
F071	Resetting of sensor adaptation	F072	Sensor rotor adaptation
F073	Default initialization	F074	Quick test of mixture adaptation
F075	Correction programming	F076	Teach-in process after engine replacement
F077	Teach in ethanol portion in fuel.	F078	Resetting the cold-start adaptation values
F079	Resetting the reading of the counter for ethanol teach-in processes	F07A	Readiness-Codes
F07B	Test values of emissions test	F07C	Measures for initiating the fault path
F07D	Notes on emissions inspection (OBD I/M	F07E	Readiness for exhaust emissions inspection
F07F	Notes on readiness	F080	Teach-in of camshaft positions
F081	Coding according to plant data	F082	Resetting of adaptation data
F083	Readiness for exhaust emissions inspection	F084	SCN(Software Calibration Number)
F085	CVN(Calibration verification number)	F086	Type approval number
F087	Lambda control, upstream TWC	F088	Lambda control, downstream TWC
F089	Fuel pump	F08A	Teach-in process for component M16/45 (EGR [ARF] actuator motors)
F08B	Initiation of self-adjustment	F08C	Correction programming of ignition
F08D	Correction programming of fuel quantity	F08E	Correction programming of the CO setting(For vehicles with no catalytic
F08F	Desensibilize shutoff threshold of smooth engine running.	F090	Readiness-Codes
F091	Notes on Emissions inspection (OBD I/M	F092	Perform calibration.
F093	Detach the transport protection of control module ISM, personalize or activate the	F094	Refill AdBlue.
F095	Erasing adaptation values after replacement of AdBlue fluid	F096	Teach-in process after replacement of component Y129 (AdBlue?metering valve)
F097	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit).	F098	Regeneration of diesel particulate filter
F099	Teach in component Y94 (Quantity control	F09A	Resetting the lambda values
F09B	Rapid teach-in of zero quantity calibration values for calibration point 230 bar	F09C	Rapid teach-in of zero quantity calibration values for calibration point 600 bar
F09D	Drive authorization(Personalizing)	F09E	Drive authorization(Activating)
F09F	Carry out the following procedure in order to include a new system in the list:	F0A0	System pressure in brake circuit 2
FOA1	H4/4 (Right rear door speaker group)	FOA2	Test fuel pump, replace if necessary.
FOA3	Teach in component M16/6 (Throttle valve	FOA4	Teach in component M55 (Inlet port shutoff
FOA5	Teach in component Y77/1 (Charge pressure positioner).	FOA6	Purge control Diesel particulate filter
FOA7	Rapid teach-in of zero quantity calibration values	FOA8	Teach-in process after replacement of component Y74 (Pressure control valve)
FOA9	Variant coding according to factory data	FOAA	Drive authorization
FOAB	Teach-in process after replacement of component G3/2 (O2 sensor upstream of KAT)	FOAC	Teach-in process after replacement of component Diesel oxidation catalytic
FOAD	Teach-in process after replacement of component SCR-Catalytic converter	FOAE	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR catalytic converter)
FOAF	Teach-in process after replacement of component N37/7b1 (NOx sensor downstream of diesel particulate filter)	FOB0	Teach-in process after replacement of component N37/8b1 (NOx sensor downstream of SCR catalytic converter)
FOB1	Teach-in process after replacement of component Y129 (AdBlue?metering valve)	FOB2	Teach-in of SCR exhaust aftertreatment system after replacement of engine control unit without transfer of values

Index	Specil Function Name	Index	Specil Function Name
FOB3	Teach-in process after replacement of component SCR-Catalytic converter	FOB4	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR catalytic converter)
FOB5	Teach-in process after replacement of component B28/16 (DPF differential pressure)	FOB6	Teach-in process after replacement of component NOx sensor upstream of SCR
FOB7	Teach-in process after replacement of component NOx sensor downstream of SCR	FOB8	Teach-in process after replacement of component Y27/9 (Exhaust gas recirculation)
FOB9	Resetting AdBlue quality factor	FOBA	Tire pressure loss warner(Activating)
FOBB	Erase zero point offset error of component N49 (Steering angle sensor).	FOBC	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of intake valves
FOBD	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of separation valves	FOBE	Write wheel electronics identification number.
FOBF	Initial startup with manual settings input for new control unit/Level calibration	FOC0	Level calibration
FOC1	Check the correctness of the MB part	FOC2	'OPEN' lock switch
FOC3	Control unit UNLOCK	FOC4	Control unit LOCK
FOC5	Resetting menu settings to manufacturer default settings	FOC6	Increase main odometer reading.
FOC7	Read coding.	FOC8	Adaptation data of power upshifts
FOC9	Adaptation data deceleration upshifts	FOCA	Adaptation data power downshifts
FOCB	Adaptation data deceleration downshifts	FOCC	Adaptation data filling pressure and
FOCD	Adaptation stop values	FOCE	Notes on combinations of adaptation data
FOCF	Acceleration upshift from gear 1 to 2	FOD0	Acceleration upshift from gear 2 to 3
FOD1	Acceleration upshift from gear 3 to 4	FOD2	Acceleration upshift from gear 4 to 5
FOD3	Decelerate downshifts from 5 to 4	FOD4	Decelerate downshifts from 4 to 3
FOD5	Additional information regarding oil level	FOD6	Actual values: Oil level check
FOD7	Electric emergency running	FOD8	Mechanical-hydraulic emergency running
FOD9	Reset Distronic option.	FODA	Important information on the combination possibilities for adapation end stop values
FODB	Adaptation values of shift 1-2:	FODC	Adaptation values of shift 2-3:
FODD	Adaptation values of shift 3-4:	FODE	Adaptation values of shift 4-5:
FODF	Adaptation values of shift 5-4:	FOE0	Adaptation values of shift 4-3:
FOE1	Adaptation values of shift 3-2:	FOE2	Adaptation values of shift 2-1:
FOE3	Performing adaptation on vehicles with torque converter lockup clutch engagement	FOE4	Performing adaptation on vehicles with torque converter lockup clutch engagement
FOE5	Settings	FOE6	Acceleration of sensor rotor adaptation
FOE7	Control unit adaptations	FOE8	Teaching in of swirl flap stop
FOE9	Exhaust gas recirculation valve teach-in	FOEA	Check sensor adaptation.
FOEB	Secondary air injection	FOEC	Diagnosis of O2 sensors
FOED	Exhaust gas recirculation diagnosis	FOEE	Selfadaptation of mixture formation
FOEF	Extension of run-on time DAS 3	F0F0	Erase zero point offset error of component N49 (Steering angle sensor).
FOF1	Erase zero point offset error of component B24/15 (Rotary speed and lateral	FOF2	Disable key or key track with the workshop key.
FOF3	Activate control module N73 (EIS [EZS] control unit).	FOF4	Windshield adaptation
FOF5	Adaptation of the light sensor	FOF6	Adaptation:Windshield Green glass
FOF7	Normalization of the tilting/sliding roof's obstruction sensor	FOF8	Trip computer settings
FOF9	Set main odometer back.	FOFA	Instrument cluster settings
FOFB	Normalizing of forward/back adjustment	FOFC	Normalizing of height adjustment at front
FOFD	Normalizing of height adjustment at rear	FOFE	Normalizing of head restraint adjustment
FOFF	Normalizing of backrest adjustment	F100	Adjust parameter for backrest adjustment.
F101	Parameterization of function for moving front passenger seat out of way when folding down rear seat	F102	Readjust adjustment parameters.
F103	Setting parameters for collision avoidance With this routine, the parameters for the compensating movement for collisions between the backrest and the rear panel can	F104	Resetting the parameters for collision avoidance to the default value The standard parameters for the control unit will be restored.

Index	Specil Function Name	Index	Specil Function Name
F105	Deactivate collision avoidance. If the collision avoidance feature is the subject of a customer complaint because the seat cannot be moved to a desired position, the collision avoidance feature can be	F106	The collision avoidance feature prevents the seat from colliding with surrounding elements (such as the headliner or rear wall) during seat adjustment by limiting the range of adjustment or triggering
F107	Parameterize easy entry/exit.	F108	Increase fore/aft adjustment range to rear.
F109	Parameterization of function for moving driver seat out of way when folding down	F10A	CO2 setting (cold setting of combustion air blower)
F10B	Learning component A8/3 (STH radio remote control transmitter)	F10C	Diesel particulate filter Purge control
F10D	Diesel particulate filter New Initializing	F10E	Self-adaptation
F10F	Assignment of control modules to plug	F110	Zero position adjustment of axle or level
F111	CNG compressed natural gas Mode	F112	Resetting of mixture adaptation CNG compressed natural gas
F113	Pneumatic test of component A9/1 (AIRmatic	F114	PML speed-sensitive power steering
F115	Key assignment or key track assignment to a	F116	Telematic service 'Remote door unlocking'
F117	Parameterization and windshield adaptation	F118	Adaptation:Windshield Green glass-Only for customer complaints concerning the lights' switch-on thresholds!
F119	Panoramic sliding roof	F11A	Sliding/tilting roof
F11B	Automatic interior mirror dimming	F11C	Tourist mode(Symmetrical light
F11D	EP: Reset operating hours counter.	F11E	Setting main odometer forward and back
F11F	Current brake lining thickness	F120	Air cushion calibration
F121	Short stroke parameter	F122	Delay of rear wiper startup after wiper/wash function is turned on
F123	Duration of wipe cycle	F124	Voltage threshold for vehicle power supply emergency mode
F125	Intermediate position Rear-end door	F126	Initializing Diesel particulate filter
F127	Prevention of diesel particulate filter	F128	Replace component NOx storage catalytic
F129	Replace component Y74 (Pressure control	F12A	Replace component M16/6 (Throttle valve
F12B	Replacement of component Diesel particulate filter on left	F12C	Replacement of component Diesel particulate filter on right
F12D	Replacement of an exhaust-relevant component on the left bank	F12E	Replacement of an exhaust-relevant component on the right bank
F12F	Replacement of control module N80 (Steering column module)	F130	Reset lambda adaptation
F131	Readiness for exhaust emissions inspection	F132	Readiness-Codes
F133	Calibration of control unit ABR	F134	Reset compressor operating time
F135	Pneumatic test of component A9/1y1 (AIRmatic pressure release valve)	F136	Pneumatic test of component Y36/6y1 (Left front level control valve)
F137	Pneumatic test of component Y36/6y2 (Right front level control valve)	F138	Pneumatic test of component Y36/6y3 (Left rear level control valve)
F139	Pneumatic test of component Y36/6y4 (Right rear level control valve)	F13A	Pneumatic test of component Y36/6y5 (AIRmatic central reservoir charge valve)
F13B	Leakage test between compressor and valve block	F13C	Leakage test between valve block and suspension struts
F13D	Leakage test between valve block and central reservoir	F13E	Steering column module
F13F	Teach-in process for anti-pinch protection function of panoramic sliding sunroof/Roller sun blind	F140	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or vice versa.
F141	Resetting operating hours counter	F142	Perform self-test 'B84/2 (Night View Assist camera)'
F143	Calibration Reset	F144	Average mileage per day
F145	Initialization of power closing	F146	Normalization of all seat adjustment motors
F147	Adapt obstruction protection.	F148	Normalizing Rear left and right
F149	Denormalization and normalization of trunk lid control	F14A	Teach-in of rotary potentiometers for the air outlets
F14B	Learning component A8/3 (STH radio remote control transmitter)	F14C	Calibration of control unit N47-5 (ESP control unit)
F14D	Complete or correct VIN.	F14E	Denormalization due to VIN deletion
F14F	Interrupt driving test.	F150	Calibration of control unit RBS
F151	Calibration of component B37/1 (Pedal angle sensor)	F152	Erase zero point offset error of component B24/15 (Micromechanical yaw rate sensor AY

Index	Specil Function Name	Index	Specil Function Name
F153	Calibration of component Vacuum pump brake booster	F154	Detach the transport protection of control module N15/5 (Electronic selector lever module control unit), personalize or
F155	Read coding and transfer to the new control	F156	Learning process
F157	Resetting of variant locking	F158	Calibration of the plunger travel sensors
F159	Load adjustment	F15A	Raise and lower the suspension struts at
F15B	Raise and lower the suspension struts at medium speed	F15C	Raise and lower the suspension struts at high speed
F15D	Activate electronic ignition switch.	F15E	Rain sensor
F15F	Setting of limit position of excess force	F160	Coding of the close-via-tilt function
F161	Coding of sliding/tilting roof function of 'automatic operation'	F162	Assign transmitter card to key track.
F163	Assign Keyless Go key to key track.	F164	Set time.
F165	Normalization of fore/aft adjustment of left seat	F166	Normalization of inclination adjustment of left seat cushion
F167	Normalization of fore/aft adjustment of right seat	F168	Normalization of inclination adjustment of right seat cushion
F169	Reduce the longitudinal travel with the retaining clip installed on the fore/aft	F16A	Forward/back adjustment
F16B	Height at front	F16C	Height at rear
F16D	Seat cushion depth	F16E	Backrest
F16F	Head restraint	F170	Change of adjusted temperature
F171	Blower	F172	Evaporator temperature
F173	Ventilation of heat exchangers	F174	Test of left heating capacity
F175	Test of right heating capacity	F176	Refrigerant circuit test
F177	Defroster button	F178	Pushbutton for rear window defroster
F179	Rest button	F17A	ON/OFF button
F17B	Right air distribution	F17C	EC button
F17D	Right temperature button	F17E	Blower button
F17F	Left temperature button	F180	REC pushbutton
F181	Left air distribution	F182	Activated charcoal filter button
F183	Dwell time	F184	Teaching-in of rotary potentiometer for center nozzle and side outlets
F185	Reset of calibrations	F186	Calibration of plunger travel
F187	Calibration of component B24/12 (ABC lateral acceleration sensor)	F188	Keyboard test
F189	CAN signal failure of brake wear at 2nd rear axle right	F18A	Teach in control unit ''N30/6 (Regenerative braking system control unit)'' again.
F18B	ESP calibration at standstill	F18C	Teach-in process after replacement of component Diesel particulate filter
F18D	Calibration of control unit RBS	F18E	Teach-in process for obstruction sensor of tilting/sliding roof
F18F	Normalization of tilting/sliding roof	F190	Normalization of panoramic sliding roof
F191	Teach-in process for anti-pinch protection function of panoramic sliding sunroof	F192	Re-initialization of AdBlue range
F193	Intermediate position Rear-end door	F194	Denormalization and normalization of rear-end door closing.
F195	Transmitter key / Transponder key	F196	Test of remote control key
F197	Test of immobilizer	F198	Learn radio code of a new transmitter key.
F199	Correction programming of AC compressor	F19A	Erase crash memory.
F19B	Perform windscreen adaptation for rain	F19C	Revocably deactivate key.
F19D	Reactivate key.	F19E	Irrevocably deactivate key.
F19F	Learn replacement key.	F1A0	Teach in used diesel particulate filter.
F1A1	Teach in new diesel particulate filter.		

Coding Special_Function

Index	Specil Function Name	Index	Specil Function Name
C001	Read coding and change if necessary.	C002	Coding
C003	Control unit replacement	C004	Display of coding data
C005	Vehicle data	C006	Modification year or model year
C007	All codes	C008	Central gateway functionality
C009	Vehicle speed signal threshold for automatic locking	C00A	Turn signal confirmation for opening and closing via transmitter key
C00B	Telematic service 'Remote door unlocking' (TELE AID)	C00C	Fuel cell or electric drive
C00D	Modification year or model year Interior CAN	C00E	Modification year or model year Engine CAN bus
C00F	Series and engine version	C010	National version
C011	Driving lights	C012	Transmission
C013	Telecommunications	C014	Climate control
C015	Washer system	C016	Headlamp cleaning system
C017	Parktronic	C018	Convenience systems
C019	Wipers	C01A	Trailer
C01B	Special vehicles	C01C	Chassis number
C01D	Steering variant	C01E	Seat belt buckle switch(FRONT)
C01F	Seat belt reminder warning for front passenger	C020	Seat mat type 'Passenger'
C021	Passenger airbag	C022	Emergency tensioning retractor(FRONT)
C023	Side airbags	C024	Control unit is released.
C025	Parameterization and windshield adaptation	C026	ATA basic function
C027	ATA alarm signal siren	C028	Basic setting(N10 (SAM control unit))
C029	Rear foglight(National version)	C02A	Light sensor
C02B	Programming of vehicle equipment	C02C	Special equipment
C02D	Current menu setting	C02E	Customer-specific settings
C02F	Engine type	C030	Specified configuration of MOST components
C031	Apply actual configuration of the MOST components as the specified configuration.	C032	Radio parameters
C033	Additional settings	C034	Fan setting
C035	Station memory	C036	Restart of optical ring
C037	Installation state	C038	Operating principle Fan
C039	Navigation	C03A	Navigation parameters
C03B	TV parameters(Shut off criteria)	C03C	TV/DVD deactivation(Valid for Hongkong)
C03D	Rear screen	C03E	DVD country code
C03F	Fan(EXTERNAL)	C040	Fan(INTERNAL)
C041	Read coding and change if necessary. (Only for special protection vehicles)	C042	Read coding and change if necessary. (Customer settings)
C043	Power window parameters	C044	Fault monitoring at output E6/5 (Left exterior mirror turn signal lamp):Deactivating
C045	Fault monitoring at output E6/6 (Right exterior mirror turn signal lamp):Deactivating	C046	This setting should only be changed if requested by customer.
C047	Workshop coding	C048	Variant coding according to factory data
C049	SCN(Software Calibration Number)	C04A	Type approval number
C04B	CVN(Calibration verification number)	C04C	Read coding and transfer to the new control unit.
C04D	License plate bracket	C04E	Warning signal-Configuration
C04F	Trailer coupling	C050	ROELight Configuration
C051	Information on redocumentation of equipment codes for SCN coding	C052	Information on coding
C053	Language settings	C054	Navigation data
C055	AUX input	C056	Video AUX jack
C057	Display coded vehicle data.	C058	Disposal detonation
C059	Vehicle equipment	C05A	Settings
C05B	Coding for weight-optimized running boards	C05C	Side airbag deactivation [USA]
C05D	Special protection	C05E	Seat fittings
C05F	Seat belt buckles	C060	Emergency tensioning retractor
C061	Check parameterization.	C062	Control unit LOCK
C063	Diagnosis to plant specifications:Read coding and change if necessary.	C064	Zero position adjustment
C065	Diagnosis to plant specifications	C066	Read coding.
C067	Coding according to plant data	C068	SCN(Software Calibration Number) CVN(Calibration verification number)

Index	Specil Function Name	Index	Specil Function Name
C069	Reset parameter Variant coding.	C06A	Learning processes
C06B	Control unit UNLOCK	C06C	Steering version
C06D	Special settings	C06E	Menu item '' is found in main menu '' (menu item '').
C06F	Set status CAN bus	C070	Headlamp range adjustment
C071	Automatic driving lights on	C072	COMAND or AUDIO
C073	Wiper system	C074	Rear window screen
C075	Distronic	C076	ATA interior motion sensor
C077	ATA towing sensor	C078	Trailer recognition
C079	Trailer lighting	C07A	Special vehicle multifunction control module (SVMCM)
C07B	Lane recognition	C07C	Sound system
C07D	Key assignment or key track assignment to a memory block number	C07E	Automatic closing of front windows
C07F	Automatic closing of rear windows	C080	Standard setting: Climate control
C081	Pollutant-dependent switchover to recirculated air	C082	Temperature correction (only valid for temperature increase)
C083	Manual recirculated air control	C084	Sun sensor
C085	Temperature correction	C086	Seat adjustment
C087	Windscreen heater	C088	Trailer recognition/Trailer lighting
C089	Keyless Go	C08A	Version: Interior CAN bus
C08B	Setting of basic ventilation	C08C	Vehicle model
C08D	Side airbags[FRONT PASSENGER]	C08E	Interior rearview mirror
C08F	Sliding/tilting roof	C090	Panoramic sliding roof
C091	Roller sun blind	C092	Closing of tilting/sliding roof when it rains
C093	Kneebags	C094	Buckle emergency tensioning retractor
C095	Automatic child seat recognition(ACSR [AKSE])/Seat occupied recognition	C096	Rear seat belts
C097	Window airbags	C098	Test of seat mat components
C099	National variant coding	C09A	Codings specific for instrument cluster
C09B	Configuration of menu items in multifunction display	C09C	Fuel tank version
C09D	Factory settings	C09E	Configuration for key 1
C09F	Configuration for key 2	COA0	Configuration for key 3
COA1	Trip computer settings	COA2	Coding according to plant data:Read coding and change if necessary.
COA3	Vehicle version	COA4	Rear warning elements
COA5	PTS switch	COA6	Zero position adjustment of axle or level sensors
COA7	PAL/NTSC	COA8	'Driver' automatic seat adjustment with memory
COA9	Stationary heater	COAA	Convenience closing
COAB	Reset coding.	COAC	Engine version
COAD	Equipment	COAE	Footwell lighting
COAF	Oil cooler relay	COB0	Gear display
COB1	Curve illumination	COB2	Headlamp cleaning system
COB3	Turning lamps	COB4	'Refrigerant' pressure sensor
COB5	Status of terminal via CAN bus	COB6	Signal Terminal 61
COB7	Coding of model series	COB8	Coding Modification year
COB9	Model designation(Only with code 336)	COBA	Radiator blind
COBB	Side lamp Version	COBC	Front seat heater
COBD	Battery sensor	COBE	Battery sensor LIN bus
COBF	Rear head restraint lowering	COC0	Deactivate ATA function.
COC1	National version of ATA function	COC2	Volume control Warning buzzer(USA)
COC3	Spotlight Trunk lid	COC4	Diesel particulate filter
COC5	Equipment version	COC6	Flashing stop lamp
COC7	Variant coding	COC8	Automatic interior mirror dimming
COC9	Adaptation:Windshield Green glass-Only for customer complaints concerning the lights' switch-on thresholds!	COCA	Tilting/sliding roof memory feature
COCB	Automatic closing function	COCC	Anti-throbbing position
COCD	PRE-SAFE	COCE	Key-dependent storage
COCF	Oil level indicator	COD0	Standard variant coding
COD1	Setting of trip computer constants	COD2	Brake data
COD3	Configuration of oil grade selection	COD4	Service work sequence

Index	Specil Function Name	Index	Specil Function Name
COD5	Program vehicle parameters.	COD6	Menu item 'Read coding and transfer to the new control unit.' is found in main menu 'Rear-end door closing control module' (menu item 'Initial startup').
COD7	CAN reception data	COD8	Delete coding.
COD9	Set control module to base function.	CODA	Read the coding of control module .
CODB	Higher-priority alarm options	CODC	Silent alarm
CODD	Full alarm	CODE	Radio help call
CODF	Odometer	COE0	Additional equipment
COE1	Options	COE2	Advanced options
COE3	Run-on times	COE4	Undervoltage value
COE5	NECK-PRO head restraint	COE6	Interior lamp-Actuation
COE7	Interior emergency illumination	COE8	Convenience function Rear side blind Rear window screen
COE9	Convenience function Sliding/tilting roof	COEA	Close-via-tilt function
COEB	Anti-pinch protection	COEC	ATA Volume control: Warning buzzer (USA) (The coding is set according to the customer's request.)
COED	ATA National variant coding	COEE	ATA Volume control: Warning buzzer (USA)
COEF	Cigarette lighter	COF0	Rear foglight
COF1	Closing the panoramic sliding sunroof during rain	COF2	Automatic opening and closing of panoramic sliding sunroof
COF3	Actual configuration of MOST and telematics CAN bus control units	COF4	Specified configuration of MOST and telematics CAN bus control units
COF5	Menu settings	COF6	Specified configuration of Telematics CAN bus control units
COF7	TV DVD Shut off criteria	COF8	Activate or deactivate navigation
COF9	Menu settings(Only development data)	COFA	Adopt the actual configuration of the MOST and telematics CAN bus control units as the specified configuration.
COFB	Automatically adjust vehicle-specific and special equipment-specific codings.	COFC	Display of all COMAND codings
COFD	SPLITVIEW(USA Canada)	COFE	Activation Video AUX jack(Only for special protection vehicles)
COFF	Mercedes-Benz Contact	C100	Service call(Development data)
C101	Workshop coding1	C102	Engine model coding
C103	CO2 setting of combustion air blower	C104	Vehicle power supply emergency operation
C105	Undervoltage shutoff threshold	C106	Flashing of LED in switch N72/1s30 (STH/HB [ZUH]/residual heat button) due to
C107	Settings: Ventilation time, Settings: Heating time	C108	Auxiliary heating
C109	Special vehicle special protection(B6/B7):Read coding and change if necessary.	C10A	Special vehicle special protection(B4):Read coding and change if necessary.
C10B	AIRmatic/ABC active body control	C10C	Rear air conditioning
C10D	Stationary heater or Telestart	C10E	Cellular telephone
C10F	Engine cooling	C110	Automatic dimming mirror
C111	Power locking	C112	ATA interior motion / towing sensor
C113	Voice control system	C114	Multifunction steering wheel
C115	Tire pressure monitor	C116	CGW N93 (Central gateway control unit)
C117	Adaptation of electronic ignition switch to vehicle model/Turn signal confirmation for opening and closing via transmitter key	C118	Adaptation of electronic ignition switch to vehicle model
C119	Suction fan control	C11A	Initializing:Steering column module
C11B	Alarm siren:Reset coding.	C11C	Rain sensor
C11D	Steering column module	C11E	Activated/Deactivated
C11F	Signal	C120	Positions
C121	Temperature	C122	Cycles
C123	Rear screen	C124	Electric rear window curtain
C125	Miscellaneous	C126	Setting of limit position of excess force limiter
C127	Coding of the close-via-tilt function	C128	Coding of sliding/tilting roof function of 'automatic operation'
C129	Factory settings Trunk lid remote closing	C12A	Trunk lid remote release
C12B	Trunk lid remote closing	C12C	Trunk interior button
C12D	Head restraint adjustment	C12E	Multicontour backrests
C12F	Central locking	C130	Childproof locks

Index	Specil Function Name	Index	Specil Function Name
C131	Emergency opening	C132	Presafe
C133	Adaptation of the light sensor amplification factor	C134	Display coding
C135	Key-dependent configurations	C136	National variant coding for vehicles without special protection' GUARD'
C137	National variant coding for vehicles with special protection' GUARD'	C138	RDK tire pressure control
C139	Bus system-Telematic	C13A	ASSYST settings
C13B	Duration of actuation:Mirror housing	C13C	Readjust adjustment parameters.
C13D	Activate or deactivate easy entry/exit.	C13E	MAXCOOL
C13F	SCN(Software Calibration Number)	C140	Control unit adaptations
C141	Pvprofuse	C142	Fuel tank characteristic curve
C143	Setting main odometer forward and back	C144	Easy Entry
C145	Installation of control unit in vehicles prior to model refinement 2008	C146	Windshield adaptation
C147	Speed-sensitive power steering	C148	ESP-Trailer stabilization
C149	Check coding of national version.	C14A	Relocking/Vehicle speed threshold for automatic locking
C14B	Parameterization	C14C	Read coding and change if necessary. (Sliding/tilting roof)
C14D	Read coding and change if necessary. (Panoramic sliding roof)	C14E	Daytime running lamps Japan variant
C14F	Rear power windows	C150	Basic setting
C151	Standard Drive/ Full hybrid drive	C152	Front windscreen wipers/ Washer nozzle heater/ Seat heater/ Power window PRE-SAFE/ Foglights/ Turning lamps
C153	Modification year	C154	Equipment Special equipment code Acoustic lock feedback
C155	Easy Entry/ Rear seat belt buckle switch(Code U01)	C156	Rear-end door lock
C157	EDW anti-theft alarm	C158	Light
C159	Trailer coupling/ Spare wheel carrier	C15A	Model series
C15B	LED' Trailer lighting'	C15C	Relays Seat adjustment
C15D	Ambiance lighting(Code 877)	C15E	Control module reset
C15F	Internal ASSYST PLUS data	C160	Volume
C161	Pushbutton	C162	Assignment of control unit to model series
C163	Special equipment 'Spare wheel carrier'	C164	All coding settings
C165	Workshop coding2	C166	Coding of control module A6 (Stationary
C167	Flashing of LED in switch due to undervoltageN72/1s30 (STH switch)	C168	Settings: Ventilation time, Settings: Heating time